

Model 43i

Instruction Manual

Pulsed Fluorescence SO₂ Analyzer

Part Number 101589-00

14Jan2008



CE

Thermo
SCIENTIFIC

© 2007 Thermo Fisher Scientific Inc. All rights reserved.

Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.

Thermo Fisher Scientific
Air Quality Instruments
27 Forge Parkway
Franklin, MA 02038
1-508-520-0430
www.thermo.com/aqi

WEEE Compliance

This product is required to comply with the European Union's Waste Electrical & Electronic Equipment (WEEE) Directive 2002/96/EC. It is marked with the following symbol:



Thermo Fisher Scientific has contracted with one or more recycling/disposal companies in each EU Member State, and this product should be disposed of or recycled through them. Further information on Thermo Fisher Scientific's compliance with these Directives, the recyclers in your country, and information on Thermo Fisher Scientific products which may assist the detection of substances subject to the RoHS Directive are available at: www.thermo.com/WEEERoHS.

Equivalent Method Designation

The Thermo Scientific Model 43i is designated by the United States Environmental Protection Agency (USEPA) as an Equivalent Method for SO₂, as set forth in the U.S. Environmental Protection Agency regulations at Title 40, Part 53 of the U.S. Code of Federal Regulations.

Designated Equivalent Method Number: EQSA-0486-060

EPA Designation Date: April 10, 1986 (amended for Model 43i)

The Model 43i meets EPA designation requirements when operated as follows:

Range	50 to 1000 ppb
Averaging Time	10 to 300 seconds
Temperature Range	20 to 30 °C
Line Voltage	90 to 110 Vac @50/60 Hertz
	105 to 125 Vac @50/60 Hertz
	210 to 250 Vac @50/60 Hertz
Pressure Compensation	ON or OFF
Temperature Compensation	ON or OFF
Flow Rate	0.5 to 1.0 LPM
RS-232/RS-485 Interface	

With or without the following options:

Teflon® Particulate Filter
Rack Mounts
High Flow Rate
Internal Zero/Span and Sample Valves
Internal Permeation Span Source
I/O Expansion Board

About This Manual

This manual provides information about installing, operating, maintaining, and servicing the Model 43*i*. It also contains important alerts to ensure safe operation and prevent equipment damage. The manual is organized into the following chapters and appendixes to provide direct access to specific operation and service information.





- Chapter 1 “Introduction” provides an overview of the product features, describes the principle of operation, and lists the specifications.
- Chapter 2 “Installation” describes how to unpack, setup, and start-up the analyzer.
- Chapter 3 “Operation” describes the front panel display, the front panel pushbuttons, and the menu-driven software.
- Chapter 4 “Calibration” provides the procedures for calibrating the analyzer and describes the required equipment.
- Chapter 5 “Preventive Maintenance” provides maintenance procedures to ensure reliable and consistent instrument operation.
- Chapter 6 “Troubleshooting” presents guidelines for diagnosing analyzer failures, isolating faults, and includes recommended actions for restoring proper operation.
- Chapter 7 “Servicing” presents safety alerts for technicians working on the analyzer, step-by-step instructions for repairing and replacing components, and a replacement parts list. It also includes contact information for product support and technical information.
- Chapter 8 “System Description” describes the function and location of the system components, provides an overview of the software structure, and includes a description of the system electronics and input/output connections.
- Chapter 9 “Optional Equipment” describes the optional equipment that can be used with this analyzer.
- Appendix A “Warranty” is a copy of the warranty statement.
- Appendix B “C-Link Protocol Commands” provides a description of the C-Link protocol commands that can be used to remotely control an analyzer using a host device such as a PC or datalogger.

- Appendix C “MODBUS Protocol” provides a description of the MODBUS Protocol Interface and is supported both over RS-232/485 (RTU protocol) as well as TCP/IP over Ethernet.
- Appendix D “Geysitech (Bayern-Hessen) Protocol” provides a description of the Geysitech (Bayern-Hessen or BH) Protocol Interface and is supported both over RS-232/485 as well as TCP/IP over Ethernet.



Safety and Equipment Damage Alerts

This manual contains important information to alert you to potential safety hazards and risks of equipment damage. Refer to the following types of alerts you may see in this manual.

Safety and Equipment Damage Alert Descriptions

Alert	Description
 DANGER	A hazard is present that will result in death or serious personal injury if the warning is ignored. ▲
 WARNING	A hazard is present or an unsafe practice can result in serious personal injury if the warning is ignored. ▲
 CAUTION	The hazard or unsafe practice could result in minor to moderate personal injury if the warning is ignored. ▲
 Equipment Damage	The hazard or unsafe practice could result in property damage if the warning is ignored. ▲

Safety and Equipment Damage Alerts in this Manual

Alert	Description
 WARNING	<p>If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲</p> <p>The service procedures in this manual are restricted to qualified service personnel only. ▲</p> <p>The Model 43i is supplied with a three-wire grounding cord. Under no circumstances should this grounding system be defeated. ▲</p>
 Equipment Damage	<p>Do not attempt to lift the analyzer by the cover or other external fittings. ▲</p> <p>Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component. If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged,</p>

Alert	Description
	the chassis is not at earth ground. ▲
	This adjustment should only be performed by an instrument service technician. ▲
	Handle all printed circuit boards by the edges only. ▲
	Do not remove the panel or frame from the LCD module. ▲
	The LCD module polarizing plate is very fragile, handle it carefully. ▲
	Do not wipe the LCD module polarizing plate with a dry cloth, it may easily scratch the plate. ▲
	Do not use Ketonics solvent or aromatic solvent to clean the LCD module, use a soft cloth moistened with a naphtha cleaning solvent. ▲
	Do not place the LCD module near organic solvents or corrosive gases. ▲
	Do not shake or jolt the LCD module. ▲


FCC Compliance

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. ▲

WEEE Symbol

The following symbol and description identify the WEEE marking used on the instrument and in the associated documentation.

Symbol	Description
	Marking of electrical and electronic equipment which applies to electrical and electronic equipment falling under the Directive 2002/96/EC (WEEE) and the equipment that has been put on the market after 13 August 2005. ▲

Where to Get Help

Service is available from exclusive distributors worldwide. Contact one of the phone numbers below for product support and technical information or visit us on the web at www.thermo.com/aqi.

1-866-282-0430 Toll Free

1-508-520-0430 International

Contents

Chapter 1	Introduction.....	1-1
	Principle of Operation	1-2
	Specifications	1-3
Chapter 2	Installation	2-1
	Lifting.....	2-1
	Unpacking and Inspection	2-1
	Setup.....	2-3
	Connecting External Devices	2-5
	Terminal Board PCB Assemblies.....	2-5
	I/O Terminal Board.....	2-5
	D/O Terminal Board	2-7
	25-Pin Terminal Board	2-8
	Startup	2-9
Chapter 3	Operation.....	3-1
	Display.....	3-2
	Pushbuttons	3-3
	Soft Keys.....	3-4
	Software Overview	3-4
	Power-up Screen	3-6
	Run Screen.....	3-6
	Main Menu.....	3-7
	Range Menu	3-8
	Single Range Mode	3-8
	Dual Range Mode.....	3-9
	Autorange Mode	3-10
	Gas Units	3-12
	SO ₂ Range.....	3-13
	Set Custom Ranges	3-15
	Custom Ranges	3-15
	Averaging Time.....	3-16
	Calibration Factors Menu	3-16
	SO ₂ Background	3-17
	SO ₂ Span Coefficient	3-18
	Reset User Calibration Default.....	3-19
	Calibration Menu	3-19
	Calibrate SO ₂ Background	3-19
	Calibrate SO ₂ Coefficient	3-20

Zero/Span Check Menu.....	3-20
Next Time	3-21
Period Hours.....	3-21
Zero/Span/Purge Duration Minutes	3-21
Zero/Span Averaging Time	3-22
Zero/Span Ratio.....	3-22
Instrument Controls Menu	3-23
Flash Lamp	3-23
Datalogging Settings	3-23
Select SREC/LREC.....	3-24
View Logged Data.....	3-24
Number of Records.....	3-25
Date and Time.....	3-25
Record Display.....	3-26
Erase Log	3-26
Select Content.....	3-26
Choose Item Type.....	3-27
Concentrations.....	3-27
Other Measurements.....	3-28
Analog Inputs.....	3-28
Commit Content	3-29
Reset to Default Content	3-29
Configure Datalogging.....	3-30
Logging Period Min	3-30
Memory Allocation Percent.....	3-30
Data Treatment	3-31
Communication Settings.....	3-31
Baud Rate	3-31
Serial Settings.....	3-32
Baud Rate	3-32
Data Bits	3-32
Parity	3-33
Stop Bits	3-33
Instrument ID.....	3-33
Communication Protocol.....	3-34
Streaming Data Configuration	3-34
Streaming Data Interval	3-35
Choose Item Signal	3-35
Concentrations.....	3-35
Other Measurements.....	3-36
Analog Inputs.....	3-36
RS-232/RS-485 Selection.....	3-37
TCP/IP Settings.....	3-37
Use DHCP	3-38
IP Address.....	3-38
Netmask.....	3-39

Gateway	3-39
Host Name	3-39
Network Time Protocol Server.....	3-40
I/O Configuration.....	3-40
Output Relay Settings	3-41
Logic State	3-41
Instrument State	3-42
Alarms.....	3-42
Non-Alarm	3-43
Digital Input Settings.....	3-43
Logic State	3-44
Instrument Action.....	3-44
Analog Output Configuration (Select Channel)	3-44
Allow Over/Under Range.....	3-45
Analog Output Configuration (Select Action)	3-45
Select Range.....	3-46
Minimum and Maximum Value	3-46
Choose Signal To Output	3-47
Analog Input Configuration.....	3-48
Descriptor	3-49
Units.....	3-49
Decimal Places	3-50
Number of Table Points.....	3-50
Table Point	3-51
Volts	3-51
User Value	3-51
Temperature Compensation.....	3-52
Pressure Compensation	3-52
Screen Contrast.....	3-53
Service Mode	3-53
Date/Time	3-54
Timezone.....	3-54
Diagnostics Menu	3-55
Program Versions.....	3-55
Voltages	3-56
Motherboard Voltages.....	3-56
Interface Board Voltages	3-56
I/O Board Voltages	3-57
Temperatures	3-57
Pressure.....	3-57
Sample Flow	3-58
Lamp Intensity.....	3-58
Optical Span Test	3-58
Analog Input Readings.....	3-59
Analog Input Voltages.....	3-59
Digital Inputs.....	3-60

Relay States	3-60
Test Analog Outputs.....	3-61
Set Analog Outputs.....	3-61
Instrument Configuration	3-62
Contact Information	3-62
Alarms Menu	3-62
Internal Temperature	3-63
Min and Max Internal Temperature Limits.....	3-64
Chamber Temperature.....	3-64
Min and Max Chamber Temperature Limits	3-64
Pressure.....	3-65
Min and Max Pressure Limits	3-65
Sample Flow	3-65
Min and Max Sample Flow Limits	3-66
Lamp Intensity.....	3-66
Min and Max Lamp Intensity Limits	3-66
Lamp Voltage.....	3-67
Min and Max Lamp Voltage Limits	3-67
Zero and Span Check.....	3-67
Max Zero and Span Offset	3-68
Zero and Span Auto Calibration	3-68
SO ₂ Concentration.....	3-68
Min and Max SO ₂ Concentration Limits	3-69
Min Trigger	3-69
Service Menu	3-70
Flash Voltage Adjustment	3-70
Initial Flash Reference.....	3-71
PMT Voltage Adjustment	3-71
Range Mode Select.....	3-72
Pressure Calibration	3-72
Calibrate Pressure Zero	3-73
Calibrate Pressure Span	3-73
Restore Default Pressure Calibration.....	3-74
Flow Calibration	3-74
Calibrate Flow Zero	3-75
Calibrate Flow Span.....	3-75
Restore Default Flow Calibration.....	3-76
Input Board Test.....	3-76
Temperature Calibration.....	3-77
Analog Output Calibration	3-77
Analog Output Calibrate Zero	3-78
Analog Output Calibrate Full-Scale	3-78
Analog Input Calibration	3-79
Analog Input Calibration Zero.....	3-79
Analog Input Calibrate Full-Scale	3-80
Permeation Oven Settings	3-80

Calibrate Gas Thermistor	3-81
Water Bath.....	3-81
Resistor	3-81
Calibrate Oven Thermistor	3-82
Permeation Oven Setpoint	3-82
Factory Calibrate Gas Thermistor	3-82
Low and High Points	3-83
Set Defaults.....	3-83
Factory Calibrate Oven Thermistor.....	3-83
Low and High Points	3-84
Set Defaults.....	3-84
Extended Ranges	3-84
Dilution Ratio.....	3-85
Display Pixel Test	3-85
Restore User Defaults.....	3-85
Password	3-86
Set Password	3-86
Lock Instrument	3-87
Change Password	3-87
Remove Password.....	3-88
Unlock Instrument.....	3-88

Chapter 4	Calibration.....	4-1
	Zero Gas Generation.....	4-1
	Commercial Heatless Air Dryers	4-1
	Absorbing Column.....	4-2
	Calibration Gas Generation	4-2
	Cylinder Gas Dilution.....	4-2
	Commercial Precision Dilution Systems.....	4-3
	Permeation Tube System.....	4-3
	Commercial Permeation Systems	4-4
	Multi-Point Calibration	4-5
	Multipoint Calibration in Dual/Auto Range Mode.....	4-7
	Zero/Span Check	4-10

Chapter 5	Preventive Maintenance	5-1
	Safety Precautions	5-1
	Replacement Parts.....	5-2
	Cleaning the Outside Case	5-2
	Visual Inspection and Cleaning.....	5-2
	Cleaning the Mirrors.....	5-2
	Capillary Inspection and Replacement	5-3
	Fan Filter Inspection and Cleaning	5-5
	Sample Particulate Filter Inspection	5-5
	Lamp Voltage Check.....	5-6

Leak Test	5-6
Pump Rebuilding.....	5-7

Chapter 6	Troubleshooting.....	6-1
	Safety Precautions	6-1
	Troubleshooting Guides.....	6-1
	Board-Level Connection Diagrams	6-10
	Connector Pin Descriptions	6-12
	Service Locations.....	6-24

Chapter 7	Servicing	7-1
	Safety Precautions	7-1
	Firmware Updates	7-2
	Accessing the Service Mode.....	7-2
	Replacement Parts List	7-3
	Cable List.....	7-4
	External Device Connection Components	7-4
	Removing the Measurement Bench and Lowering the Partition Panel	7-6
	Fuse Replacement	7-8
	Pump Replacement	7-9
	Fan Replacement.....	7-10
	Optical Bench Replacement	7-11
	Cleaning the Mirrors.....	7-13
	Flash Lamp Replacement	7-13
	Flash Lamp Voltage Adjustment	7-14
	Flash Trigger Assembly Replacement	7-15
	Flash Intensity Assembly Replacement	7-16
	Photomultiplier Tube Replacement	7-17
	PMT High Voltage Power Supply Replacement.....	7-18
	PMT Voltage Adjustment	7-19
	DC Power Supply Replacement	7-20
	Analog Output Testing	7-21
	Analog Output Calibration	7-24
	Analog Input Calibration	7-25
	Calibrating the Input Channels to Zero Volts	7-25
	Calibrating the Input Channels to Full Scale.....	7-26
	Pressure Transducer Assembly Replacement.....	7-27
	Pressure Transducer Calibration.....	7-28
	Flow Transducer Replacement	7-30
	Flow Transducer Calibration.....	7-31
	Heater Assembly Replacement	7-33
	Kicker Replacement	7-34
	Heated Kicker Replacement	7-35
	Thermistor Replacement	7-36
	Ambient Temperature Calibration	7-37

Input Board Replacement	7-39
I/O Expansion Board (Optional) Replacement	7-40
Digital Output Board Replacement.....	7-41
Motherboard Replacement.....	7-42
Measurement Interface Board Replacement	7-43
Front Panel Board Replacement.....	7-44
LCD Module Replacement	7-45
Service Locations.....	7-46

Chapter 8

System Description	8-1
Hardware	8-1
Hydrocarbon Kicker	8-2
Heated Hydrocarbon Kicker (Optional).....	8-2
Optics	8-3
Flash Lamp	8-3
Condensing Lens.....	8-3
Mirror Assembly	8-3
Light Baffle	8-3
Flash Lamp Trigger Assembly	8-3
Reaction Chamber	8-3
Bandpass Filter.....	8-4
Photomultiplier Tube	8-4
Photodetector.....	8-4
Flow Sensor.....	8-4
Pressure Transducer	8-4
Capillary	8-4
Vacuum Pump.....	8-4
Software	8-4
Instrument Control.....	8-4
Monitoring Signals.....	8-5
Measurement Calculations	8-5
Output Communication	8-5
Electronics	8-6
Motherboard.....	8-6
External Connectors.....	8-6
Internal Connectors	8-6
Measurement Interface Board	8-7
Measurement Interface Board Connectors.....	8-7
Flow Sensor Assembly	8-7
Pressure Sensor Assembly	8-7
Bench Heater	8-8
PMT Power Supply Assembly	8-8
Diagnostic LED	8-8
Input Board	8-8
Digital Output Board.....	8-8
Front Panel Connector Board	8-8

Flash Trigger Board.....	8-9
Flash Intensity Board	8-9
I/O Expansion Board (Optional)	8-9
I/O Components.....	8-9
Analog Voltage Outputs.....	8-9
Analog Current Outputs (Optional)	8-10
Analog Voltage Inputs (Optional)	8-10
Digital Relay Outputs	8-10
Digital Inputs.....	8-10
Serial Ports	8-11
RS-232 Connection	8-11
RS-485 Connection	8-12
Ethernet Connection.....	8-12
External Accessory Connector	8-12
Internal Zero/Span and Sample Valves.....	9-1

Chapter 9

Optional Equipment.....	9-1
Internal Permeation Span Source	9-1
Permeation Tube Installation	9-2
Computation of Concentrations	9-3
Oven Installation and Configuration.....	9-3
Permeation Tube Oven Calibration	9-5
Setting Perm Oven Temperature.....	9-5
Setting Temperature with Water Bath.....	9-6
Setting Temperature with Known Resistance	9-7
Determining Permeation Rate by Weight Loss.....	9-7
Determining Release Rate by Transfer Standard.....	9-8
Heated Hydrocarbon Kicker	9-9
Teflon Particulate Filter	9-9
I/O Expansion Board Assembly.....	9-9
25-Pin Terminal Board Assembly.....	9-9
Terminal Block and Cable Kits	9-9
Cables	9-10
Mounting Options.....	9-11

Appendix A	Warranty.....	A-1
-------------------	----------------------	------------

Appendix B	C-Link Protocol Commands.....	B-1
	Instrument Identification Number.....	B-1
	Commands	B-2
	Accessing Streaming Data	B-2
	Entering Units in PPB	B-2
	Commands List.....	B-2
	Measurements	B-8
	Alarms.....	B-11

Diagnostics	B-15
Datalogging.....	B-16
Calibration	B-24
Keys/Display	B-26
Measurement Configuration	B-28
Hardware Configuration	B-32
Communications Configuration	B-35
I/O Configuration.....	B-39
Record Layout Definition	B-43
Format Specifier for ASCII Responses.....	B-43
Format Specifier for Binary Responses	B-44
Format Specifier for Front-Panel Layout	B-44
Text	B-45
Value String	B-45
Value Source	B-45
Alarm Information	B-45
Translation Table.....	B-45
Selection Table.....	B-46
Button Designator.....	B-46
Examples.....	B-46

Appendix C

MODBUS Protocol	C-1
Serial Communication Parameters	C-1
TCP Communication Parameters	C-2
Application Data Unit Definition	C-2
Slave Address.....	C-2
MBAP Header	C-2
Function Code.....	C-3
Data.....	C-3
Error Check	C-3
Function Codes.....	C-3
(0x01/0x02) Read Coils / Read Inputs	C-3
(0x03/0x04) Read Holding Registers / Read Input Registers	C-5
(0x03/0x04) Read Holding Registers / Read Input Registers	C-5
(0x05) Force (Write) Single Coil.....	C-7
MODBUS Commands Supported	C-8

Appendix D

Geysitech (Bayern-Hessen) Protocol	D-1
Serial Communication Parameters	D-1
TCP Communication Parameters	D-2
Instrument Address	D-2
Abbreviations Used	D-2
Basic Command Structure	D-2
Block Checksum <BCC>	D-3
Geysitech Commands	D-3

Contents

Instrument Control Command (ST)	D-3
Data Sampling/Data Query Command (DA).....	D-4
Measurements reported in response to DA command	D-6
Single Range Mode	D-6
Dual/Auto Range Mode.....	D-6
Operating and Error Status	D-7

Figures

Figure 1–1. Model 43i Flow Schematic.....	1-3
Figure 2–1. Remove the Packing Material	2-2
Figure 2–2. Removing the Shipping Screws	2-2
Figure 2–3. Rear Panel.....	2-4
Figure 2–4. Atmospheric Dump Bypass Plumbing	2-5
Figure 2–5. I/O Terminal Board Views	2-6
Figure 2–6. D/O Terminal Board Views.....	2-7
Figure 2–7. 25-Pin Terminal Board Views.....	2-8
Figure 3–1. Front Panel Display.....	3-2
Figure 3–2. Front Panel Pushbuttons.....	3-3
Figure 3–3. Flowchart of Menu-Driven Software	3-5
Figure 3–4. Pinout of Rear Panel Connector in Single Range Mode.....	3-8
Figure 3–5. Pinout of Rear Panel Connector in Dual Range Mode.....	3-10
Figure 3–6. Analog Output in Autorange Mode.....	3-11
Figure 3–7. Pin-Out of Rear Panel Connector in Auto-Range Mode	3-12
Figure 4–1. Cylinder Gas Dilution System.....	4-3
Figure 4–2. Permeation Tube System	4-4
Figure 5–1. Inspecting and Replacing the Capillary.....	5-4
Figure 5–2. Capillary Assembly	5-4
Figure 5–3. Inspecting and Cleaning the Fan	5-5
Figure 5–4. Rebuilding the Pump.....	5-8
Figure 6–1. Board-Level Connection Diagram - Common Electronics	6-10
Figure 6–2. Board-Level Connection Diagram – Measurement System	6-11
Figure 7–1. Properly Grounded Antistatic Wrist Strap	7-2
Figure 7–2. Model 43i Component Layout.....	7-6
Figure 7–3. Removing the Measurement Bench and Lowering the Partition Panel	7-7
Figure 7–4. Replacing the Pump.....	7-10
Figure 7–5. Replacing the Fan	7-11
Figure 7–6. Replacing the Optical Bench	7-12
Figure 7–7. Replacing the Flash Lamp and Flash Trigger Assembly	7-14
Figure 7–8. Replacing the Flash Intensity Assembly	7-17
Figure 7–9. Replacing the PMT	7-18
Figure 7–10. Replacing the PMT High Voltage Power Supply (HVPS)	7-19
Figure 7–11. Replacing the DC Power Supply.....	7-21
Figure 7–12. Rear Panel Analog Input and Output Pins.....	7-23

Figure 7–13. Replacing the Pressure Transducer Assembly	7-28
Figure 7–14. Replacing the Flow Transducer	7-31
Figure 7–15. Replacing the Heater Assembly	7-34
Figure 7–16. Replacing the Kicker Assembly (Standard Kicker)	7-35
Figure 7–17. Replacing the Kicker Assembly (Optional Heated Kicker)	7-36
Figure 7–18. Replacing the Thermistor.....	7-37
Figure 7–19. Replacing the Input Board	7-39
Figure 7–20. Replacing the I/O Expansion Board (Optional)	7-41
Figure 7–21. Rear Panel Board Connectors	7-41
Figure 7–22. Replacing the Measurement Interface Board	7-44
Figure 7–23. Replacing the Front Panel Board and the LCD Module.....	7-45
Figure 8–1. Hardware Components	8-2
Figure 9–1. Internal Permeation Span Source Flow Diagram	9-2
Figure 9–2. Cal Oven Therm Resistor Screen	9-5
Figure 9–3. Cal Gas Therm Bath Screen	9-6
Figure 9–4. Cal Gas Therm Resistor Screen	9-7
Figure 9–5. Rack Mount Option Assembly	9-12
Figure 9–6. Bench Mounting	9-13
Figure 9–7. EIA Rack Mounting	9-14
Figure 9–8. Retrofit Rack Mounting.....	9-15
Figure B–1. Flags	B-11

Tables

Table 1–1. Model 43i Specifications.....	1-3
Table 1–2. Model 43i Optional Permeation Oven Specifications.....	1-5
Table 2–1. I/O Terminal Board Pin Descriptions	2-6
Table 2–2. D/O Terminal Board Pin Descriptions.....	2-7
Table 2–3. 25-Pin Terminal Board Pin Descriptions.....	2-8
Table 3–1. Front Panel Pushbuttons.....	3-3
Table 3–2. Default Analog Outputs in Single Range Mode.....	3-9
Table 3–3. Default Analog Outputs in Dual Range Mode	3-10
Table 3–4. Default Analog Outputs in Auto Range Mode	3-12
Table 3–5. Standard Ranges.....	3-14
Table 3–6. Extended Ranges	3-14
Table 3–7. Analog Output Zero to Full Scale Values	3-47
Table 3–8. Signal Types Group Choices.....	3-48
Table 6–1. Troubleshooting - Power-Up Failures.....	6-2
Table 6–2. Troubleshooting - Calibration Failures	6-3
Table 6–3. Troubleshooting - Measurement Failures	6-5
Table 6–4. Troubleshooting - Alarm Messages.....	6-8
Table 6–5. Motherboard Connector Pin Descriptions.....	6-12
Table 6–6. Measurement Interface Board Connector Pin Descriptions	6-16
Table 6–7. Front Panel Board Connector Pin Diagram	6-19
Table 6–8. I/O Expansion Board (Optional) Connector Pin Descriptions	6-21
Table 6–9. Digital Output Board Connector Pin Descriptions.....	6-22
Table 6–10. Input Board Connector Pin Descriptions	6-23
Table 6–11. Flash Trigger Pack Pin Descriptions	6-24
Table 6–12. Flash Intensity Assembly Pin Descriptions	6-24
Table 7–1. Replacement Parts.....	7-3
Table 7–2. Model 43i Cables	7-4
Table 7–3. External Device Connection Components	7-4
Table 7–4. Analog Output Channels and Rear Panel Pin Connections.....	7-23
Table 7–5. Analog Input Channels and Rear Panel Pin Connections.....	7-24
Table 8–1. RS-232 DB Connector Pin Configurations	8-12
Table 8–2. RS-485 DB Connector Pin Configuration.....	8-12
Table 9–1. Cable Options.....	9-10
Table 9–2. Color Codes for 25-Pin and 37-Pin Cables	9-10
Table 9–3. Mounting Options	9-11
Table B–1. C-Link Protocol Commands	B-3

Table B–2. Averaging Times.....	B-8
Table B–3. Alarm Trigger Values.....	B-14
Table B–4. Record Output Formats.....	B-20
Table B–5. Stream Time Values	B-24
Table B–6. Standard Ranges	B-28
Table B–7. Extended Ranges	B-29
Table B–8. Contrast Level.....	B-32
Table B–9. Reply Termination Formats	B-37
Table B–10. Analog Current Output Range Values.....	B-39
Table B–11. Analog Voltage Output Range Values	B-40
Table B–12. Default Output Assignment.....	B-41
Table C–1. Read Registers for 43 <i>i</i>	C-8
Table C–2. Write Coils for 43 <i>i</i>	C-9
Table C–3. Read Coils for 43 <i>i</i>	C-10
Table D–1. Operating Status for Model 43 <i>i</i>	D-7
Table D–2. Error Status for Model 43 <i>i</i>	D-7

Chapter 1

Introduction

The Model 43*i* Pulsed Fluorescence Analyzer combines proven detection technology, easy to use menu-driven software, and advanced diagnostics to offer unsurpassed flexibility and reliability. The Model 43*i* has the following features:

- 320 x 240 graphics display
- Menu-driven software
- Field programmable ranges
- User-selectable single/dual/auto range modes
- Multiple user-defined analog outputs
- Analog input options
- High sensitivity
- Fast response time
- Linearity through all ranges
- Internal sample pump
- Totally self contained
- Insensitive to changes in flow and ambient temperature
- User-selectable digital input/output capabilities
- Standard communications features include RS232/485 and Ethernet
- C-Link, MODBUS, Geysitech (Bayern-Hessen), streaming data, and NTP (Network Time Protocol) protocols. Simultaneous connections from different locations over Ethernet.

For details of the analyzer's principle of operation and product specifications, see the following topics:

- "Principle of Operation" on page 1-2 describes the analyzer's operating principles.
- "Specifications" on page 1-3 provides a list of the analyzer's performance specifications.

Thermo Fisher Scientific is pleased to supply this pulsed fluorescence SO₂ analyzer. We are committed to the manufacture of instruments exhibiting high standards of quality, performance, and workmanship. Service personnel are available for assistance with any questions or problems that may arise in the use of this analyzer. For more information on servicing, see the “Servicing” chapter.

Principle of Operation

The Model 43*i* operates on the principle that SO₂ molecules absorb ultraviolet (UV) light and become excited at one wavelength, then decay to a lower energy state emitting UV light at a different wavelength. Specifically,



The sample is drawn into the Model 43 *i* through the SAMPLE bulkhead, as shown in **Figure 1–1**. The sample flows through a hydrocarbon “kicker,” which removes hydrocarbons from the sample by forcing the hydrocarbon molecules to permeate through the tube wall. The SO₂ molecules pass through the hydrocarbon “kicker” unaffected.

The sample then flows into the fluorescence chamber, where pulsating UV light excites the SO₂ molecules. The condensing lens focuses the pulsating UV light into the mirror assembly. The mirror assembly contains four selective mirrors that reflect only the wavelengths which excite SO₂ molecules.

As the excited SO₂ molecules decay to lower energy states they emit UV light that is proportional to the SO₂ concentration. The bandpass filter allows only the wavelengths emitted by the excited SO₂ molecules to reach the photomultiplier tube (PMT). The PMT detects the UV light emission from the decaying SO₂ molecules. The photodetector, located at the back of the fluorescence chamber, continuously monitors the pulsating UV light source and is connected to a circuit that compensates for fluctuations in the UV light.

As the sample leaves the optical chamber, it passes through a flow sensor, a capillary, and the “shell” side of the hydrocarbon kicker. The sample then flows to the pump and is exhausted out the EXHAUST bulkhead of the analyzer. The Model 43*i* outputs the SO₂ concentration to the front panel display and the analog outputs, and also makes the data available over the serial or Ethernet connection.




Figure 1–1. Model 43i Flow Schematic

Specifications

Table 1–1. Model 43i Specifications

Preset ranges	0-0.05, 0.1, 0.2, 0.5, 1, 2, 5 and 10 ppm 0.02, 0.5, 1, 2, 5, 10, 20 and 25 mg/m ³
Extended Ranges	0-0.5, 1, 2, 5, 10, 20, 50 and 100 ppm 0-2, 5, 10, 20, 50, 100, 200 and 250 mg/m ³
Custom ranges	0-0.05 to 10 ppm (0-0.5 to 100 ppm in extended range) 0-0.2 to 25 mg/m ³ (0-2 to 250 mg/m ³ in extended range)
Zero noise	1.0 ppm RMS (10 second averaging time) 0.5 ppm RMS (60 second averaging time) 0.25 ppm RMS (300 second averaging time)
Lower detectable limit	2 ppb (10 second averaging time) 1 ppb (60 second averaging time) 0.5 ppb (300 second averaging time)
Zero drift (24 hour)	< 1 ppb
Span drift	± 1% full-scale per week
Response time	80 sec (10 second averaging time) 110 sec (60 second averaging time) 320 sec (300 second averaging time)

Linearity	± 1% of full-scale
Sample flow rate	0.5 lpm (standard) 1.0 lpm (optional)
Interferences (EPA levels)	Less than lower detectable limit except for the following: NO < 3 ppb, M-Xylene < 1ppb, H ₂ O < 3% of reading
Operating temperature	15–35 °C (may be safely operated over the range of 0–45 °C) ¹
Power requirements	100 VAC @ 50/60 Hz 115 VAC @ 50/60 Hz 220-240 VAC @ 50/60 Hz 165 watts
Physical dimensions	16.75" (W) X 8.62" (H) X 23" (D)
Weight	Approximately 48 lbs.
Analog outputs	6 voltage outputs; 0–100 mV, 1, 5, 10 V (user selectable), 5% of full-scale over/under range (user selectable), 12 bit resolution, measurement output user selectable per channel
Digital outputs	1 power fail relay Form C, 10 digital relays Form A, user selectable alarm output, relay logic, 100 mA @ 200 VDC
Digital inputs	16 digital inputs, user select programmable, TTL level, pulled high
Serial Ports	1 RS-232 or RS-485 with two connectors, baud rate 1200–115200, data bits, parity, and stop bits, protocols: C-Link, MODBUS, Geysitech (Bayern-Hessen), and streaming data (all user selectable)
Ethernet connection	RJ45 connector for 10 Mbs Ethernet connection, static, or dynamic TCP/IP addressing

¹In non-condensing environments. Performance specifications based on operation within 20–30 °C range.

Table 1–2. Model 43i Optional Permeation Oven Specifications

Temperature control	Single Point 45 °C
Temperature stability	± 0.1 °C
Warm-up time	1 hour (permeation device can take 24 to 48 hours to stabilize)
Carrier gas flow	≈ 70 scc/min
Chamber size	Accepts permeation tubes up to 9 cm in total length; 1 cm in diameter
Temperature range	20–30 °C
Physical dimensions	Contained inside the Model 43i
Power requirements	120 VAC @ 50/60 Hz, 50 watts (in addition to the standard Model 43i)
Weight	Approximately five pounds (in addition to standard Model 43i)

Chapter 2

Installation

Installation of the Model 43*i* includes lifting the instrument, unpacking and inspection, connecting sample, zero, span, and exhaust lines, and attaching the analog outputs to a recording device. The installation should always be followed by instrument calibration as described in the “Calibration” chapter of this manual.

This chapter provides the following recommendations and procedures for installing the instrument:

- Lifting on page 2-1
- Unpacking and Inspection on page 2-1
- Setup on page 2-3
- Connecting External Devices on page 2-5
- Startup on page 2-9

Lifting

When lifting the instrument, use a procedure appropriate to lifting a heavy object, such as, bending at the knees while keeping your back straight and upright. Grasp the instrument at the bottom in the front and at the rear of the unit. Although one person can lift the unit, it is desirable to have two persons lifting, one by grasping the bottom in the front and the other by grasping the bottom in the rear.



Equipment Damage Do not attempt to lift the instrument by the cover or other external fittings. ▲

Unpacking and Inspection

The Model 43*i* is shipped complete in one container. If there is obvious damage to the shipping container when you receive the instrument, notify the carrier immediately and hold for inspection. The carrier is responsible for any damage incurred during shipment.

Use the following procedure to unpack and inspect the instrument.

1. Remove the instrument from the shipping container and set it on a table or bench that allows easy access to both the front and rear.

2. Remove the cover to expose the internal components.

3. Remove the packing material (**Figure 2-1**).




Figure 2-1. Remove the Packing Material

4. Remove the three shipping screws from the pump (**Figure 2-2**).




Figure 2-2. Removing the Shipping Screws

5. Check for possible damage during shipment.

6. Check that all connectors and circuit boards are firmly attached.
7. Re-install the cover.
8. Remove any protective plastic material from the case exterior.

Setup

Use the following procedure to setup the instrument.

1. Connect the sample line to the SAMPLE bulkhead on the rear panel (**Figure 2-3**) Ensure that the sample line is not contaminated by dirty, wet, or incompatible materials. All tubing should be constructed of FEP Teflon, 316 stainless steel, borosilicate glass, or similar tubing with an OD of 1/4-inch and a minimum ID of 1/8-inch. The length of the tubing should be less than 10 feet.

Note Gas must be delivered to the instrument free of particulates. It may be necessary to use the Teflon particulate filter as described in “Teflon Particulate Filter” on page 9-9. ▲

If the sample may contain particulates larger than 5 microns, it should be filtered before introducing it to the instrument. Use a filter (such as Teflon) that does not interact with SO₂ in the sample. If a sample filter is used, all calibrations and span checks must be performed through the filter. The filter element should be replaced regularly to prevent the absorption of SO₂ by trapped material on the filter. ▲

Note Gas must be delivered to the instrument at atmospheric pressure. It may be necessary to use an atmospheric bypass plumbing arrangement as shown in **Figure 2-4** if gas pressure is greater than atmospheric pressure. ▲

2. Connect the EXHAUST bulkhead to a suitable vent. The exhaust line should be 1/4-inch OD with a minimum ID of 1/8-inch. The length of the exhaust line should be less than 10 feet. Verify that there is no restriction in this line.
3. Connect a suitable recording device to the rear panel connector. For detailed information about connecting to the instrument, refer to:
 - “Connecting External Devices” on page 2-5
 - “External Device Connection Components” on page 7-4.

“Terminal Block and Cable Kits” on page 9-9

“Instrument Controls > I/O Configuration” in the “Operation” chapter.

For detailed information about troubleshooting a connection, refer to “Analog Output Testing” on page 7-21.

4. Plug the instrument into an outlet of the appropriate voltage and frequency.



WARNING The Model 43i is supplied with a three-wire grounding cord. Under no circumstances should this grounding system be defeated. ▲




Figure 2–3. Rear Panel




Figure 2–4. Atmospheric Dump Bypass Plumbing

Connecting External Devices

Several components are available for connecting external devices to *i*Series instruments.

These connection options include:

- Individual terminal board PCB assemblies
- Terminal block and cable kits (optional)
- Individual cables (optional)

For detailed information on the optional connection components, refer to the “Optional Equipment” chapter. For associated part numbers, refer to the “Servicing” chapter.

Terminal Board PCB Assemblies

The following terminal board PCB assemblies are available for *i*Series instruments:

- I/O terminal board PCB assembly, 37 pin (standard)
- D/O terminal board PCB assembly, 37 pin (standard)
- 25-pin terminal board PCB assembly, (included with optional I/O Expansion Board)

I/O Terminal Board

Figure 2–5 shows the recommended method for attaching the cable to the terminal board using the included tie-down and spacer. **Table 2–1** identifies the connector pins and associated signals.

Note All of the I/O available in the instrument are not brought out on this terminal board, if more I/O is desired, an alternative means of connection is required. ▲




Figure 2–5. I/O Terminal Board Views

Table 2–1. I/O Terminal Board Pin Descriptions

Pin	Signal Description	Pin	Signal Description
1	Analog1	13	Power_Fail_NC
2	Analog ground	14	Power_Fail_COM
3	Analog2	15	Power_Fail_NO
4	Analog ground	16	TTL_Input1
5	Analog3	17	TTL_Input2
6	Analog ground	18	TTL_Input3
7	Analog4	19	TTL_Input4
8	Analog ground	20	Digital ground
9	Analog5	21	TTL_Input5
10	Analog ground	22	TTL_Input6
11	Analog6	23	TTL_Input7
12	Analog ground	24	Digital ground

D/O Terminal Board

Figure 2–6 shows the recommended method for attaching the cable to the terminal board using the included tie-down and spacer. **Table 2–2** identifies the connector pins and associated signals.




Figure 2–6. D/O Terminal Board Views

Table 2–2. D/O Terminal Board Pin Descriptions

Pin	Signal Description	Pin	Signal Description
1	Relay1_ContactA	13	Relay7_ContactA
2	Relay1_ContactB	14	Relay7_ContactB
3	Relay2_ContactA	15	Relay8_ContactA
4	Relay2_ContactB	16	Relay8_ContactB
5	Relay3_ContactA	17	Relay9_ContactA
6	Relay3_ContactB	18	Relay9_ContactB
7	Relay4_ContactA	19	Relay10_ContactA
8	Relay4_ContactB	20	Relay10_ContactB
9	Relay5_ContactA	21	Not Used
10	Relay5_ContactB	22	+24V
11	Relay6_ContactA	23	Not Used
12	Relay6_ContactB	24	+24V

25-Pin Terminal Board The 25-pin terminal board is included with the optional I/O Expansion Board.




Figure 2–7. 25-Pin Terminal Board Views

Table 2–3. 25-Pin Terminal Board Pin Descriptions

Pin	Signal Description	Pin	Signal Description
1	IOut1	13	Analog_In1
2	Isolated ground	14	Analog_In2
3	IOut2	15	Analog_In3
4	Isolated ground	16	GNDD
5	IOut3	17	Analog_In4
6	Isolated ground	18	Analog_In5
7	IOut4	19	Analog_In6
8	Isolated ground	20	GNDD
9	IOut5	21	Analog_In7
10	Isolated ground	22	Analog_In8
11	IOut6	23	GNDD
12	Isolated ground	24	GNDD

Startup

Use the following procedure when starting the instrument.

1. Turn the power ON.
2. Allow 30 minutes for the instrument to stabilize.
3. Set instrument parameters such as operating ranges and averaging times to appropriate settings. For more information about instrument parameters, see the “Operation” chapter.
4. Before beginning actual monitoring, perform a multipoint calibration as described in the “Calibration” chapter.



Chapter 3

Operation

This chapter describes the front panel display, front panel pushbuttons, and menu-driven software.

- “Display” on page 3-2 describes the LCD graphics display.
- “Pushbuttons” on page 3-3 describes the various front panel pushbuttons and the expected key actions for each.
- “Software Overview” on page 3-4 describes the menu-driven software and submenus.
- “Range Menu” on page 3-8 describes the gas units, SO₂ range, and custom ranges.
- “Averaging Time” on page 3-16 describes the averaging period applied to SO₂ measurements.
- “Calibration Factors Menu” on page 3-16 describes the calibration factors used to correct SO₂ measurement readings.
- “Calibration Menu” on page 3-19 describes manual and automatic calibration of zero and span.
- “Instrument Controls Menu” on page 3-23 describes the instrument hardware control and configuration.
- “Diagnostics Menu” on page 3-55 describes the diagnostic information and functions.
- “Alarms Menu” on page 3-62 describes a list of items that are monitored by the analyzer.
- “Service Menu” on page 3-70 describes service related menu items.
- “Password” on page 3-86 describes how to enter/change a password and lock/unlock the analyzer.

Display

The 320 x 240 graphics liquid-crystal display (LCD) shows the sample concentrations, instrument parameters, instrument controls, help, and error messages. Some menus contain more items than can be displayed at one time. For these menus, use  and  to move the cursor up and down to each item.




Figure 3–1. Front Panel Display



CAUTION If the LCD panel breaks, do not let the liquid crystal contact your skin or clothes. If the liquid crystal contacts your skin or clothes, wash it off immediately using soap and water. ▲

Pushbuttons

The Pushbuttons allow the user to traverse the various screens/menus. **Table 3–1** lists the front panel pushbuttons and their functions.





Figure 3–2. Front Panel Pushbuttons

Table 3–1. Front Panel Pushbuttons


Key Name	Function
= Soft Keys	The (soft keys) are used to provide shortcuts that allow the user to jump to user-selectable menu screens. For more information on processing soft keys, see "Soft Keys".
= Run	The is used to display the Run screen. The Run screen normally displays the SO ₂ concentration.
= Menu	The is used to display the Main Menu when in the Run screen, or back up one level in the menu system. For more information about the Main Menu, see "Main Menu" later in this chapter.
= Help	The is context-sensitive, that is, it provides additional information about the screen that is being displayed. Press for a brief explanation about the current screen or menu. Help messages are displayed using lower case letters to easily distinguish them from the operating screens. To exit a help screen, press or to return to the previous screen, or to return to the Run screen.
= Up, Down = Left, Right	The four arrow pushbuttons (, , , and) move the cursor up, down, left, and right or change values and states in specific screens.
= Enter	The is used to select a menu item, accept/set/save a change, and/or toggle on/off functions.

Soft Keys

The Soft Keys are multi-functional keys that use part of the display to identify their function at any moment. The function of the soft keys allows immediate access to the menu structure and most often used menus and screens. They are located directly underneath the display and as the keys' functions change this is indicated by user-defined labels in the lower part of the display, so that the user knows what the keys are to be used for.

To change a soft key, place the menu cursor ">" on the item of the selected menu or screen you wish to set. Press  followed by the selected soft key within 1 second of pressing the right-arrow key. The edit soft key prompt will be displayed for configuration for the new label.


Note Not all menu items may be assigned to soft keys. If a particular menu or screen item cannot be assigned, the key assignment screen will not come up upon entering right-arrow-soft key combinations. All items under the Service menu (including the menu itself) cannot be assigned soft keys. ▲



```
EDIT SOFT KEY PROMPT:
CURRENTLY:RANGE
          RANGE
BCDEFGHIJKLMN  BKSP
OPQRSTUVWXYZ   PAGE
0123456789 . / - SAVE

RANGE  AVG  DIAGS  ALARM
```

Software Overview

The Model 43i utilizes the menu-driven software as illustrated by the flowchart in **Figure 3-3**. The Power-Up screen, shown at the top of the flowchart, is displayed each time the instrument is turned on. This screen is displayed while the instrument is warming up and performing self-checks. After the warm-up period, the Run screen is automatically displayed. The Run screen is the normal operating screen. It displays the SO₂ concentration, depending on operating mode. From the Run screen, the Main Menu can be displayed by pressing . The Main Menu contains a list of submenus. Each submenu contains related instrument settings. This chapter describes each submenu and screen in detail. Refer to the appropriate sections for more information.




Figure 3–3. Flowchart of Menu-Driven Software

Power-up Screen

The Power-up screen is displayed when power is applied to the Model 43i. This screen is displayed while the internal components are warming up and diagnostic checks are being performed.



Run Screen

The Run screen displays the SO₂ concentration. The status bar displays the time (24-hour format), the password (lock) icon, service (wrench) icon, alarm (bell) icon, and optional zero/span sample solenoid valve status, if installed.

Status Bar Icons



The password (lock) icon indicates that no parameter changes can be made from the front panel.




The alarm (bell) icon indicates that an alarm is active.

The service (wrench) icon indicates that the instrument is in the service mode.






The word "SAMPLE" on the bottom left of the display indicates the analyzer has the span/zero valve option and is in "SAMPLE" mode. Other modes appear in the same area of the display as "ZERO" or "SPAN". For more information about the optional solenoid valves, see Chapter 9, "Optional Equipment".

When operating in dual or auto range mode two sets of coefficients are used to calculate the CO "High" and "Low" concentrations. Also, two averaging times are used—one for each range. The title bar indicates which range concentrations are displayed. The words "LOW RANGE CONCENTRATION" on the top of the display indicates that the low concentration is displayed. In dual range mode, pressing the  and  arrows will toggle between high and low concentrations. The example that follows shows the Run screen in single range mode.



Main Menu

The Main Menu contains a number of submenus. Instrument parameters and features are divided into these submenus according to their function. The concentration appears above the main menu and submenus in every screen. The SERVICE menu is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” later in this chapter.

- Use  and  to move the cursor up and down.
- Press  to select a choice.
- Press  to return to the top of the Main Menu or  to return to the Run screen.

```

MAIN MENU:
>RANGE
AVERAGING TIME
CALIBRATION FACTORS
CALIBRATION
INSTRUMENT CONTROLS
DIAGNOSTICS
ALARMS
                                ↓
RANGE  AVG  DIAGS  ALARM

SERVICE
PASSWORD
  
```

Range Menu

The Range menu allows the operator to select the gas units, SO₂ ranges, and to set the custom ranges. The screens that follow show the range menu in single mode and dual/autorange modes. The only difference between the screens are the words “HI” and “LO” to indicate which range is displayed. For more information about the single, dual and auto range modes, see “Single Range Mode”, “Dual Range Mode”, and “Autorange Mode.”

In the Main Menu, choose **Range**.

```

RANGE:
>GAS UNITS          PPB
SO2 RANGE          100.0
SET CUSTOM RANGES

RANGE  AVG  DIAGS  ALARM
  
```

```

RANGE:
>GAS UNITS          PPB
HI SO2 RANGE        1000
LO SO2 RANGE        100.0
SET CUSTOM RANGES

RANGE  AVG  DIAGS  ALARM
  
```

Single Range Mode

In the single range mode, there is one range, one averaging time, and one span coefficient.

By default, two SO₂ analog outputs are arranged on the rear panel connector as shown in **Figure 3-4**. See **Table 3-2** for channels and pin connections. Single range mode may be selected from the “Range Mode Select” in the “Service Menu”, later in this chapter.




Figure 3-4. Pinout of Rear Panel Connector in Single Range Mode

Table 3–2. Default Analog Outputs in Single Range Mode

Channel	Connector Pin	I/O Terminal Pin	Description
1	14	1	SO ₂ Analog Output
2	33	3	SO ₂ Analog Output
3	15	5	None
4	34	7	None
5	17	9	None
6	36	11	None
Ground	16, 18, 19, 35, 37	2, 4, 6, 8, 10, 12	Signal Ground

Note All channels are user definable. If any customization has been made to the analog output configuration, the default selections may not apply. ▲

Dual Range Mode

In the dual range mode, there are two independent analog outputs. These are labelled simply as the “High Range” and the “Low Range”. Each channel has its own analog output range, averaging time, and span coefficient.

This enables the sample concentration reading to be sent to the analog outputs at two different ranges. For example, the low SO₂ analog output can be set to output concentrations from 0 to 50 ppb and the high SO₂ analog output set to output concentrations from 0 to 100 ppb.

In addition, each SO₂ analog output has a span coefficient. There are two span coefficients so that each range can be calibrated separately. This is necessary if the two ranges are not close to one another. For example, the low SO₂ range is set to 0–50 ppb and the high SO₂ range is set to 0–10000 ppb.

By default, in the dual range mode, the analog outputs are arranged on the rear panel connector as shown in **Figure 3–5**. See **Table 3–3** for channels and pin connections. Dual range mode may be selected from the “Range Mode Select” in the “Service Menu”, later in this chapter.




Figure 3–5. Pinout of Rear Panel Connector in Dual Range Mode

Table 3–3. Default Analog Outputs in Dual Range Mode

Channel	Connector Pin	I/O Terminal Pin	Description
1	14	1	SO ₂ High Range
2	33	3	SO ₂ Low Range
3	15	5	None
4	34	7	None
5	17	9	None
6	36	11	None
Ground	16, 18, 19, 35, 37	2, 4, 6, 8, 10, 12	Signal Ground

Note All channels are user definable. If any customization has been made to the analog output configuration, the default selections may not apply. ▲

Autorange Mode The autorange mode switches the SO₂ analog outputs between high and low ranges, depending on the concentration level. The high and low ranges are defined in the Range menu.

For example, suppose the low range is set to 50 ppb and the high range is set to 100 ppb (**Figure 3–6**). Sample concentrations below 50 ppb are output based on low range selection and sample concentrations above 50 ppb are output based on high range selection. When the low range is active, the status output is at 0 volts. When the high range is active, the status output is at half of full-scale.

When the high range is active, the concentration must drop to 95% of the low SO₂ range for the low range to become active.

In addition, each SO₂ analog output has a span coefficient. There are two span coefficients so that each range can be calibrated separately. This is necessary if the two ranges are not close to one another. For example, the low SO₂ range is set to 0–50 ppb and the high SO₂ range is set to 0–10000 ppb.




Figure 3–6. Analog Output in Autorange Mode

By default, in the autorange mode, the analog outputs are arranged on the rear panel connector as shown in **Figure 3–7**. See **Table 3–4** for channels and pin connections. Autorange mode may be selected from “Range Mode Select” in the “Service Menu” later in this chapter.




Figure 3–7. Pin-Out of Rear Panel Connector in Auto-Range Mode

Table 3–4. Default Analog Outputs in Auto Range Mode

Channel	Connector Pin	I/O Terminal Pin	Description
1	14	1	SO ₂ Analog Output
2	33	3	SO ₂ Status Output half-scale = high range zero scale = low range
3	15	5	None
4	34	7	None
5	17	9	None
6	36	11	None
Ground	16, 18, 19, 35, 37	2, 4, 6, 8, 10, 12	Signal Ground

Note All channels are user definable. If any customization has been made to the analog output configuration, the default selections may not apply. ▲

Gas Units

The Gas Units screen defines how the SO₂ concentration readings are expressed. Gas units of parts per billion (ppb), or micrograms per cubic meter ($\mu\text{g}/\text{m}^3$) are available. The $\mu\text{g}/\text{m}^3$ gas concentration is calculated using a standard pressure of 760 mmHg and a standard temperature of 20 °C.

When switching the selected units from ppb or ppm to $\mu\text{g}/\text{m}^3$ or mg/m^3 , the analog ranges all default to the highest range in that mode. For example, when switching from mg/m^3 to ppm, all the ranges default to 10 ppm.

Therefore, whenever you change units, you should also check the range settings.

In the Main Menu, choose Range > **Gas Units**.

Note If the units change from ppb or ppm to $\mu\text{g}/\text{m}^3$ or mg/m^3 or vice versa, the instrument should be re-calibrated, particularly if the user's standard temperature is different from 20 °C. A display warning will appear that ranges will be defaulted and calibration parameters reset. ▲

```

GAS UNITS:
CURRENTLY:      PPB
SET TO:         UG/M3 ?
AND SET RANGES AND CAL TO
DEFAULT SETTING
↑↓ CHANGE VALUE  ← SAVE
RANGE  AVG  DIAGS  ALARM
  
```

SO₂ Range The SO₂ Range screen defines the concentration range of the analog outputs. For example, a SO₂ range of 0–50 ppb restricts the analog output to concentrations between 0 and 50 ppb.

The display shows the current SO₂ range. The next line of the display is used to change the range. The range screen is similar for the single, dual, and autorange modes. The only difference between the screens are the words “High” or “Low” displayed to indicate which range is displayed. The example that follows shows the SO₂ range screen in single mode. For more information about the dual and autorange modes, see “Single Range Mode”, “Dual Range Mode”, and “Autorange Mode” earlier in this chapter.

Table 3–5 lists the available standard ranges. **Table 3–6** lists the extended ranges. When switching from standard to extended ranges, the PMT voltage must be readjusted. For more information, about readjusting the PMT voltage, see the “Servicing” chapter.

In the Main Menu, choose Range > **SO₂ Range**.



Table 3–5. Standard Ranges

ppb	ppm	µg/m ³	mg/m ³
50	0.05	200	0.2
100	0.10	500	0.5
200	0.20	1000	1
500	0.50	2000	2
1000	1	5000	5
2000	2	10000	10
5000	5	20000	20
10000	10	25000	25
C1	C1	C1	C1
C2	C2	C2	C2
C3	C3	C3	C3

C1, C2, and C3 are custom ranges. For more information about custom ranges, see “Set Custom Ranges” that follows.

Table 3–6. Extended Ranges

ppb	ppm	µg/m ³	mg/m ³
500	0.5	2000	2
1000	1	5000	5
2000	2	10000	10
5000	5	20000	20
10000	10	50000	50
20000	20	100000	100
50000	50	200000	200
100000	100	250000	250
C1	C1	C1	C1
C2	C2	C2	C2

ppb	ppm	$\mu\text{g}/\text{m}^3$	mg/m^3
C3	C3	C3	C3

Set Custom Ranges

The Set Custom Ranges menu lists three custom ranges: C1, C2, and C3. Custom ranges are user-defined ranges. Any value between 50 ppb (0.05 ppm) and 10000 ppb (10 ppm) can be specified as a range. In the $\mu\text{g}/\text{m}^3$ (mg/m^3) mode, any value between 200 $\mu\text{g}/\text{m}^3$ (0.2 mg/m^3) and 25000 $\mu\text{g}/\text{m}^3$ (25 mg/m^3) can be specified as a range.

In the extended range mode, any value between 500 ppb (0.5 ppm) and 100000 ppb (100 ppm) can be specified as a range. In the $\mu\text{g}/\text{m}^3$ (mg/m^3) mode, any value between 2000 $\mu\text{g}/\text{m}^3$ (2 mg/m^3) and 250000 $\mu\text{g}/\text{m}^3$ (250 mg/m^3) can be specified as a range.

In the Main Menu, choose Range > **Set Custom Ranges**.

```

CUSTOM RANGES:
>CUSTOM RANGE 1      55.6
CUSTOM RANGE 2       75.0
CUSTOM RANGE 3      125.0

RANGE  AVG  DIAGS  ALARM

```

Custom Ranges

The Custom Ranges screen is used to define the custom ranges.

The display shows the current custom range. The next line of the display is used to set the range. To use the custom full-scale range, be sure to select it (Custom range 1, 2, or 3) in the SO₂ Range screen. For more information about selecting ranges, see “SO₂ Range” described previously.

In the Main Menu, choose Range > Set Custom Ranges > **Custom range 1**, 2, or 3.

```

CUSTOM RANGE 1:
CURRENTLY:      55.5
SET TO:         000055.5 ?

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM


```

Averaging Time

The Averaging Time defines a time period (1 to 300 seconds) during which SO₂ measurements are taken. The average concentration of the readings are calculated for that time period. The front panel display and analog outputs are updated every 10 seconds for averaging times between 10 and 300 seconds. For averaging times of 1, 2, and 5 seconds, the front panel display and analog outputs are updated every second. An averaging time of 10 seconds, for example, means that the average concentration of the last 10 seconds will be output at each update. An averaging time of 300 seconds means that the moving average concentration of the last 300 seconds will be output at each update. Therefore, the lower the averaging time the faster the front panel display and analog outputs respond to concentration changes. Longer averaging times are typically used to smooth output data.

The Averaging Time screen for the single range mode is shown below. In the dual and auto range modes, an averaging time menu is displayed before the averaging time screen. This additional menu is needed because the dual and autorange modes have two averaging times (high and low). The averaging time screen functions the same way in the single, dual, and autorange modes. The following averaging times are available: 1, 2, 5, 10, 20, 30, 60, 90, 120, 180, 240, and 300 seconds.

In the Main Menu, choose **Averaging Time**.



```
AVERAGING TIME:
CURRENTLY:      30 SEC
SET TO:         10 SEC ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Calibration Factors Menu

Calibration factors are used to correct the SO₂ concentration readings that the instrument generates using its own internal calibration data. The Calibration Factors menu displays the calibration factors. The screens that follow show the calibration factors menu in single mode and dual/autorange modes. The only differences between the screens are the words “HI” and “LO” to indicate which range is displayed.

Normally, the instrument is calibrated automatically using the commands listed in the Calibration menu described later in this chapter. However, the instrument can also be calibrated manually using the Calibration Factors menu.

To manually calibrate the instrument, see “SO₂ Background” and “SO₂ Span Coefficient” that follows for more information.

In the Main Menu, choose **Calibration Factors**.

```

CALIBRATION FACTORS:
>SO2 BKG          0.00
SO2 COEF          1.000
RESET USER CAL DEFAULTS

RANGE  AVG  DIAGS  ALARM

```

```

CALIBRATION FACTORS:
>SO2 BKG          35.7
HI SO2 COEF       1.000
LO SO2 COEF       1.000
RESET USER CAL DEFAULTS

RANGE  AVG  DIAGS  ALARM





```

SO₂ Background

The SO₂ Background correction is determined during zero calibration. The SO₂ background is the amount of signal read by the analyzer while sampling zero air. Although the background is expressed in terms of concentration, the background signal is actually the combination of electrical noise and scattered light. Before the analyzer sets the SO₂ reading to zero, it stores this value as the SO₂ background correction.

The SO₂ Background screen is used to perform a manual adjustment of the instruments zero background. As such, the instrument should sample zero air until stable readings are obtained. The display shows the current SO₂ reading. This reading is the SO₂ background signal. The next line of the display shows the SO₂ background correction that is stored in memory and is being used to correct the SO₂ reading. That is, the SO₂ background correction is subtracted from the SO₂ reading.

In the example that follows, the analyzer is reading 25.7 ppb of SO₂ while sampling zero air. The SO₂ background correction is 0.0 ppb. That is, the analyzer is not applying a zero background correction. The question mark is used as a prompt to change the background correction. In this case the background correction must be increased to 25.7 ppb in order for the SO₂ reading to be at 0 ppb.

To set the SO₂ reading in the example that follows to zero, use  to increment the SO₂ background correction to 25.7 ppb. As the SO₂ background correction is increased, the SO₂ concentration is decreased. At this point, however, no real changes have been made. To escape this screen without saving any changes, press  to return to the Calibration Factors menu or  to return to the Run screen. Press  to actually set the SO₂ reading to 0 ppb and store the new background correction of 25.7 ppb.

In the Main Menu, choose Calibration Factors > **SO₂ Bkg**.

```
SO2 BACKGROUND:
  SO2:          25.7
SET BKG TO:      0.0 ?



  ↑↓ INC/DEC
  ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

SO₂ Span Coefficient

The SO₂ span coefficient is usually calculated by the instrument processor during calibration. The span coefficients are used to correct the SO₂ readings and normally has a value near 1.000.

The SO₂ Span Coefficient screen allow the SO₂ span coefficient to be manually changed while sampling span gas of known concentration.

The display shows the current SO₂ concentration reading. The next line of the display shows the SO₂ span coefficient that is stored in memory and is being used to correct the SO₂ concentration. Notice that as the span coefficient value is changed, the current SO₂ concentration reading on the above line also changes. However, no real changes are made to the value stored in memory until  is pressed. Only proposed changes, as indicated by a question mark prompt, are displayed until  is pressed.

In dual or autorange modes, “HIGH” or “LOW” is displayed to indicate the calibration of the high or low coefficient.

The example that follows shows the coefficient screen in dual or auto range mode.

Note The concentration value will show ERROR if the measured concentration is not a valid span value (either higher than the selected range, or 0 or lower). ▲

In the Main Menu, choose Calibration Factors > **Hi SO₂ Coef.**

```
HIGH SO2 COEFFICIENT:
  HIGH SO2:      400
SET COEF TO:     1.000 ?

  ↑↓ INC/DEC
  ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Reset User Calibration Default

The Reset User Calibration Default screen allows the user to reset the calibration configuration values to factory defaults.

In the Main Menu, choose Calibration Factors > **Reset User Cal Defaults**.

```
RESTORE DEFAULT CAL:
                        ← RESTORE

RANGE  AVG  DIAGS  ALARM
```

```
RESTORE DEFAULT CAL:
                        ← RESTORE
ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM RESTORE

RANGE  AVG  DIAGS  ALARM
```

Calibration Menu

The Calibration menu is used to calibrate zero and span. The calibration menu is similar for the single, dual, and autorange mode as shown below. The dual and autorange modes have two SO₂ span factors (“HI” and “LO”). This allows each range to be calibrated separately. This is necessary if the two ranges used are not close to one another. For example, a low SO₂ range of 500 ppb and a high SO₂ range of 10 ppm. For more information about calibration, see the “Calibration” chapter.

In the Main Menu, choose **Calibration**.

```
CALIBRATION:
>CAL SO2 BACKGROUND
CAL SO2 COEFFICIENT
ZERO/SPAN CHECK

RANGE  AVG  DIAGS  ALARM
```

```
CALIBRATION:
>CAL SO2 BACKGROUND
CAL HI SO2 COEFFICIENT
CAL LO SO2 COEFFICIENT

RANGE  AVG  DIAGS  ALARM
```

Calibrate SO₂ Background

The Calibrate SO₂ Background screen is used to adjust the SO₂ background, or perform a “zero calibration”. Before performing a zero calibration, ensure the analyzer samples zero air for at least 5 minutes.

It is important to note the averaging time when calibrating. The longer the averaging time, the more accurate the calibration will be. To be most accurate, use the 300-second averaging time. For more information about calibration, see Chapter 4, “Calibration”.

In the Main Menu, choose Calibration > **Cal SO₂ Background**.

```
SO2 BACKGROUND:
  SO2:          25.7
CURRENTLY:      0.0 ?
      ← SET SO2 TO ZERO

RANGE  AVG  DIAGS  ALARM
```

Calibrate SO₂ Coefficient

The Calibrate SO₂ Coefficient screen is used to adjust the SO₂ coefficient and enter the span concentration. The display shows the current SO₂ concentration reading and the current SO₂ range. The next line of the display is where the SO₂ calibration gas concentration is entered.

The SO₂ span coefficient is calculated, stored, and used to correct the current SO₂ reading. For more information about calibration, see Chapter 4, “Calibration”. In dual or auto range modes, “HIGH” or “LOW” is displayed to indicate the calibration of the high or low coefficient.

In the Main Menu, choose Calibration > Cal SO₂ Coefficient.

```
CALIBRATE SO2:
  SO2:          400
SPAN CONC:      0001.000 ?
      ↔ MOVE CURSOR
      ↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM
```

Zero/Span Check Menu

The Zero/Span Check menu is available with the zero/span valve option. It is used to program the instrument to perform fully automated zero and span check or adjustments. Total Duration Hr is the sum of zero, span, and purge duration minutes.

Note Zero and Span Calibration Reset are toggle items that change between yes or no when selected, and present only if auto calibration is installed. ▲

In the Main Menu, choose Calibration > Zero/Span Check.

```

ZERO/SPAN CHECK:
>NEXT TIME 01JAN06 12:00
PERIOD HR 6
TOTAL DURATION HR 1.1
ZERO DURATION MIN 30
SPAN DURATION MIN 30
PURGE DURATION MIN 5
ZERO/SPAN AVG SEC 60
ZERO CAL RESET OFF↓
RANGE AVG DIAGS ALARM

SPAN CAL RESET OFF
ZERO/SPAN RATIO 1

```

Next Time

The Next Time screen is used to set the initial date and time of the zero/span check. Once the initial zero/span check is performed, the date and of the next zero/span check is calculated and displayed.

In the Main Menu, choose Calibration > Zero/Span Check > **Next Time**.

```

NEXT DATE AND TIME:
19 MAR 2005 12:34
PRESS ← TO EDIT
RANGE AVG DIAGS ALARM

```

```

NEXT DATE AND TIME:
19 MAR 2005 12:34:56
SETTING: DAYS
      → SET MONTHS
      ↑↓ CHANGE VALUE
      ← SAVE VALUE
RANGE AVG DIAGS ALARM

```

Period Hours

The Zero/Span Period Hours screen defines the period or interval between zero/span checks. Periods between 0 and 999 hours are acceptable. To turn the zero/span check off, set the period to 0.

In the Main Menu, choose Calibration > Zero/Span Check > **Period Hours**.

```

ZERO/SPAN PERIOD:
CURRENTLY: 024 HRS
SET TO: 02 HRS ?
      ↔ MOVE CURSOR
      ↑↓ CHANGE VALUE  ← SAVE
RANGE AVG DIAGS ALARM

```

Zero/Span/Purge Duration Minutes

The Zero Duration Minutes screen defines how long zero air is sampled by the instrument. The span and purge duration screens look and functions

the same way as the zero duration screen, and are used to set how long the span gas and sample gas are sampled by the instrument. Durations between 0 and 60 minutes are acceptable. Each time a zero/span check occurs the zero check is done first, followed by the span check. To perform just a zero check, set the span and purge duration screens to 0 (off). The same applies to perform just a span or purge check.

In the Main Menu, choose Calibration > Zero/Span Check > **Zero, Span or Purge Duration Min.**

```
ZERO DURATION:
CURRENTLY:      30 MIN
SET TO:         31 MIN ?

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE ← SAVE

RANGE  AVG  DIAGS  ALARM
```

Zero/Span Averaging Time

The Zero/Span Averaging Time screen allows the user to adjust the zero/span averaging time. The zero/span averaging time is used by the analyzer only when performing an automatic zero, or span check, or calibration. The analyzer's averaging time is used for all other functions. The following averaging times are available: 1, 2, 5, 10, 20, 30, 60, 90, 120, 180, 240, and 300 seconds.

In the Main Menu, choose Calibration > Zero/Span Check > **Zero/Span Avg Sec.**

```
ZERO/SPAN AVERAGING TIME:
CURRENTLY:      60 SEC
SET TO:         90 SEC ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Zero/Span Ratio

The Zero/Span Ratio screen is used to adjust the ratio of zeros to spans. For example, if this value is set to 1, a span check will follow every zero check. If this value is set to 3, there will be two zero checks between each zero/span check. This value may be set from 1 to 10, with 1 as default.

In the Main Menu, choose Calibration > Zero/Span Check > **Zero/Span Ratio.**

```

ZERO/SPAN RATIO:
CURRENTLY:      1 : 1
SET TO:         3 : 1 ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM

```

Instrument Controls Menu

The Instrument Controls menu contains a number of items. The software controls listed in this menu enable control of the listed instrument functions.

In the Main Menu, choose **Instrument Controls**.

```

INSTRUMENT CONTROLS:
>FLASH LAMP
  DATALOGGING SETTINGS
  COMMUNICATION SETTINGS
  I/O CONFIGURATION
  TEMPERATURE COMPENSATION
  PRESSURE COMPENSATION
  SCREEN CONTRAST      ↓

RANGE  AVG  DIAGS  ALARM

SERVICE MODE
DATE/TIME
TIMEZONE

```

Flash Lamp

The Flash Lamp screen is used to turn the flash lamp on or off. The flash lamp must be off when using the optical span test LED. For more information about the optical span test LED, see “Optical Span Test” later in this chapter.

In the Main Menu, choose Instrument Controls > **Flash Lamp**.

```

FLASH LAMP:
CURRENTLY:      ON
SET TO:         OFF ?

      ← TOGGLE VALUE

RANGE  AVG  DIAGS  ALARM

```

Datalogging Settings

The *i*Series instruments include a built-in data logging capability as a standard feature. The operator is allowed to create two different types of records, which for historical reasons are named lrecs and srecs. Each record

can contain up to 32 different fields or data items, and records can be created at user-defined intervals ranging from 1 to 60 minutes.

Record generation is tied to the instrument's real-time clock. For example, if the logging period for srecs is set to 30 minutes, a new srec will be generated on every hour and every half hour (10:00, 10:30, 11:00 ...). Lrecs and srecs can be interleaved. For example, an srec containing just the current concentration level could be generated every five minutes while an lrec containing a full set of diagnostic data could be generated once every hour.

The analyzer's computer system includes three megabytes of flash memory which is enough to store a full lrec containing 32 data items and a full srec containing 32 items once each minute for a week (>20,000 total records). If logging is limited to the minimum content of date, time, concentration and error flags, the analyzer can store data once each minute for four months (>190,000 records).

In the Main Menu, choose Instrument Controls > **Datalogging Settings**.

```

DATALOGGING SETTINGS:
>SELECT SREC/LREC      SREC
VIEW LOGGED DATA
ERASE LOG
SELECT CONTENT
COMMIT CONTENT
RESET TO DEFAULT CONTENT
CONFIGURE DATALOGGING

RANGE  AVG  DIAGS  ALARM
  
```

Select SREC/LREC

The Select SREC/LREC is used to select short record or long record format for other operations in this menu.

In the Main Menu, choose Instrument Controls > Datalogging Settings > **Select SREC/LREC**.

```

SEL LOG TYPE:
CURRENTLY:      SREC
SET TO:         LREC

← TOGGLE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

View Logged Data

The View Logged Data screen is used to select the start point to view the logged data by number or records or date and time.

In the Main Menu, choose Instrument Controls > Datalogging Settings > Select SREC or LREC > **View Logged Data**.

```

SELECT START POINT BY:
      SET TO: # OF RECS

      ↑↓ CHANGE      ← ACCEPT
RANGE  AVG  DIAGS  ALARM
  
```

Number of Records

The Number of Records screen is used to select the starting record to display the number of records back to view.

```

SET # BACK FROM CURRENT:
TOTAL LRECS:      000000
                  20

      ↔ MOVE CURSOR
      ↑↓ CHANGE VALUE  ← SAVE
RANGE  AVG  DIAGS  ALARM
  
```

The Record Display screen (read only) displays the selected records.

```

time    date    flags
10:01  06/20/05  FC0088900
10:02  06/20/05  FC0088900
10:03  06/20/05  FC0088900
10:04  06/20/05  FC0088900
      ↑↓ PGUP/DN  ↔ PAN L/R
RANGE  AVG  DIAGS  ALARM
  
```

Date and Time

The Date and Time screen is used to set a start date and time for which to view logged data. For example, if “20 JUN 2005 10:00” is entered, then the first logged data record that is displayed is the first record after this time. If set to one minute logging, this would be at “20 JUN 2005 10:01”.

```

DATE AND TIME:
20 JUN 2005 10:00
↑↓ CHG DAYS
➡ SET CURSOR TO MONTHS
⬅ ACCEPT AS SHOWN

RANGE  AVG  DIAGS  ALARM

```

Record Display The Record Display screen (read only) displays the selected records.

```

time    date    flags
10:01  06/20/05  FC0088900
10:02  06/20/05  FC0088900
10:03  06/20/05  FC0088900
10:04  06/20/05  FC0088900
↑↓ PGUP/DN  ⬅➡ PAN L/R

RANGE  AVG  DIAGS  ALARM

```

Erase Log The Erase Log is used to erase all saved data for the selected record type (not all short records and long records).

In the Main Menu, choose Instrument Controls > Datalogging Settings > **Erase Log**.

```

ERASE LREC LOG FILE DATA?
                               ⬅ ERASE

RANGE  AVG  DIAGS  ALARM

```

```

ERASE LREC LOG FILE DATA?
                               ⬅ ERASE
ARE YOU SURE YOU WANT TO?
PRESS ➡ TO CONFIRM ERASURE

RANGE  AVG  DIAGS  ALARM

```

Select Content The Select Content submenu displays a list of 32 record fields to use and a submenu list of the analog output signal group choices to choose from. Choices are Concentrations, Other Measurements, and Analog Inputs (if the I/O expansion board is installed). This is a temporary list of items for the selected record type that must be committed via the datalogging menu before the changes will apply. Note that committing any changes to this list will erase all currently logged data, as the format of the stored data is changed.

In the Main Menu, choose Instrument Controls > Datalogging Settings > **Select Content**.

```

LREC FIELDS:
>FIELD 1          SO2
FIELD 2          HISO2
FIELD 3          INTT
FIELD 4          RCTT
FIELD 5          PRES
FIELD 6          SMPLFL
FIELD 7          PMTV  ↓
RANGE  AVG  DIAGS  ALARM
  
```

Choose Item Type

The Choose Item Type submenu is a list of the type of data that can be logged for the current field. Choices are Concentrations, Other Measurements, and Analog Inputs (if the I/O expansion board is installed).


In the Main Menu, choose Instrument Controls > Datalogging Settings > Select Content > **Field 1-32**.

```

DATA IN SREC FIELD 1:
CONCENTRATIONS
OTHER MEASUREMENTS
ANALOG INPUTS
RANGE  AVG  DIAGS  ALARM
  
```

Note The ANALOG INPUTS item is only displayed if the I/O Expansion Board option is installed. ▲

Concentrations

The Concentrations screen allows the user to select the output signal that is tied to the selected field item. The selected item is shown by “<--” after it. Note that at this point, pressing  indicates that these are proposed changes as opposed to implemented changes. To change the selected record format and erase record log file data, see “Commit Content” that follows. Range Status is visible only in auto range mode.


In the Main Menu, choose Instrument Controls > Datalogging Settings > Select Content > Select Field > **Concentrations**.

```

CONCENTRATIONS:
>NONE
SO2 <--
LO SO2
HI SO2
RANGE (SO2)

RANGE  AVG  DIAGS  ALARM
  
```

Other Measurements

The Other Measurements screen allows the user to select the output signal that is tied to the selected field item. The selected item is shown by “<--” after it. Items displayed are determined by the options installed. Note that at this point, pressing  indicates that these are proposed changes as opposed to implemented changes. To change the selected record format and erase record log file data, see “Commit Content” that follows.


In the Main Menu, choose Instrument Controls > Datalogging Settings > Select Content > Select Field > **Other Measurements**.

```

OTHER MEASUREMENTS:
>NONE
INT TEMP <--
CHAMBER TEMP
PERM OVN GAS
PERM OVN HTR
CHAMBER PRES
SAMPLE FLOW
↓

RANGE  AVG  DIAGS  ALARM
  
```

Analog Inputs

The Analog Inputs screen allows the user to select the output signal (none or analog inputs 1-8) that is tied to the selected field item. The selected item is shown by “<--” after it. Note that at this point, pressing  indicates that these are proposed changes as opposed to implemented changes. To change the selected record format and erase record log file data, see “Commit Content” that follows.

In the Main Menu, choose Instrument Controls > Datalogging Settings > Select Content > Select Field > **Analog Inputs**.

```

ANALOG INPUTS:
>NONE
INPUT 1
INPUT 2
INPUT 3
INPUT 4
INPUT 5
INPUT 6
                                     <---
                                     ↓
RANGE  AVG  DIAGS  ALARM
INPUT 7
INPUT 8
  
```

Commit Content The Commit Content screen is used to save the selected output signal that is tied to the selected field item. If no changes have been made “NO CHANGES TO RECORD LIST!” will appear. For more information about selecting the analog output signal group choices, see “Commit Content” in this chapter.

In the Main Menu, choose Instrument Controls > Datalogging Settings > **Select Content**.

```

CHANGE LREC DATA AND
ERASE LREC LOG FILE DATA?
                                ← COMMIT
RANGE  AVG  DIAGS  ALARM
  
```

```

CHANGE LREC DATA AND
ERASE LREC LOG FILE DATA?
                                ← COMMIT
ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM ERASURE
RANGE  AVG  DIAGS  ALARM
  
```

Reset to Default Content The Reset to Default Content screen is used to reset all of the datalogging field items to default values for the selected record type. For more information, about selecting the content of logged data fields, see “Select Content” described previously.

In the Main Menu, choose Instrument Controls > Datalogging Settings > **Reset to Default Content**.

```

RESET LREC DATA AND
ERASE LREC LOG FILE DATA?
                                ← RESET
RANGE  AVG  DIAGS  ALARM
  
```

```

RESET LREC DATA AND
ERASE LREC LOG FILE DATA?
                                ← RESET
ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM RESET
RANGE  AVG  DIAGS  ALARM
  
```

Configure Datalogging

The Configure Datalogging menu deals with datalogging configuration for the currently selected record type.

In the Main Menu, choose Instrument Controls > Datalogging Settings > **Configure Datalogging**.

```
DATALOGGING SETTINGS:
>LOGGING PERIOD MIN    OFF
MEMORY ALLOCATION %     50
DATA TREATMENT         AVG

RANGE  AVG  DIAGS ALARM
```

Logging Period Min

The Logging Period Min screen is used to select the logging period in minutes for the record format (srec or lrec). List of choices include: off, 1, 5, 15, 30, and 60 minutes (default).

In the Main Menu, choose Instrument Controls > Datalogging Settings > Configure Datalogging > **Logging Period Min**.

```
SET PERIOD FOR SREC:
CURRENTLY:           OFF MIN
SET TO:              60 MIN ?

↑↓ CHANGE VALUE    ← SAVE

RANGE  AVG  DIAGS ALARM
```

Memory Allocation Percent

The Memory Allocation Percent screen is used to select the percentage of each record type for both srecs and lrecs. Percentages between 0 and 100% are available in increments of 10. Changing this value results in log erasure for both short records and long records.

In the Main Menu, choose Instrument Controls > Datalogging Settings > Configure Datalogging > **Memory Allocation %**.

```
SET PERCENT SRECS:
CURRENTLY:           50 %
SET TO:              100 % ?

↑↓ CHANGE VALUE    ← SAVE

RANGE  AVG  DIAGS ALARM
```

Data Treatment

The Data Treatment screen is used to select the data type for the selected record type: whether the data should be averaged over the interval, the minimum or maximum measured during the interval, or the current value (last value measured). Data treatment doesn't apply to all data, just to the concentration measurement. All other data points log the current value at the end of the interval.

In the Main Menu, choose Instrument Controls > Datalogging Settings > Configure Datalogging > **Data Treatment**.

```

SET   LREC DATA TYPE:
CURRENTLY:          AVG
SET TO:             CUR ?

↑↓ CHANGE VALUE    ← SAVE

RANGE  AVG  DIAGS  ALARM

```

Communication Settings

The communication Settings menu is used with communications control and configuration.

In the Main Menu, choose Instrument Controls > **Communication Settings**.

```

COMMUNICATION SETTINGS:
>SERIAL SETTINGS
INSTRUMENT ID
COMMUNICATION PROTOCOL
STREAMING DATA CONFIG
TCP/IP SETTINGS

RANGE  AVG  DIAGS  ALARM

```

Baud Rate

The Baud Rate screen is used to set the RS-232/RS-485 interface baud rate. Baud rates of 1200, 2400, 4800, and 9600, 19200, 38400, 57600, and 115200 are available.

In the Main Menu, choose Instrument Controls > Communication Settings > **Baud Rate**.

```

BAUD RATE:
CURRENTLY:      9600
SET TO:        57600 ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Serial Settings

The Serial Settings menu is used for serial communications control and configuration. In the Main Menu, choose Instrument Controls > Communication Settings > **Serial Settings**.

```

SERIAL SETTINGS:
>BAUD RATE      9600
DATA BITS       8
PARITY          NONE
STOP BITS       1
RS-232/485 SEL  RS-232

RANGE  AVG  DIAGS  ALARM
  
```

Baud Rate

The Baud Rate screen is used to set the RS-232/RS485 interface baud rate. Baud rates of 1200, 2400, 4800, 9600, 19200, 38400, 57600 and 115200 are available. The analyzer's default baud rate is set to 9600 to provide backwards compatibility with the older C-series analyzers.

```

BAUD RATE:
CURRENTLY:      9600
SET TO:        19200 ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Data Bits

The Data Bits Screen is used to set the number of serial data bits. Selections of 7 or 8 are available (defaults to 8).

```

DATA BITS:
CURRENTLY:      8
SET TO:        7      ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```


Parity

The Parity screen is used to select the parity bit for the serial port. Selections of NONE, EVEN, or ODD are available (defaults to NONE).

```

PARITY:
CURRENTLY:      NONE
SET TO:         NONE

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Stop Bits

The Stop Bits screen is used to select the number of stop bits for the serial port. Selections of 1 and 2 are available (defaults to 1).

```

STOP BITS:
CURRENTLY:      1
SET TO:         2      ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Instrument ID

The Instrument ID screen allows the operator to edit the instrument ID. The ID is used to identify the instrument when using the C-Link or MODBUS protocols to control the instrument or collect data. It may be necessary to edit the ID number if two or more of the same instruments are connected to one computer. Valid Instrument ID numbers are from 0 to 127. The Model 43*i* has a default Instrument ID of 43. For more information about the Instrument ID, see Appendix B “C-Link Protocol Commands” or Appendix C “MODBUS Protocol”.

In the Main Menu, choose Instrument Controls > Communication Settings > **Instrument ID**.

```

INSTRUMENT ID:
CURRENTLY:      43
SET TO:         50 ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Communication Protocol

The Communication Protocol screen is used to change the instrument communication protocol for serial communications.

In the Main Menu, choose Instrument Controls > Communication Settings > **Communication Protocol**.

```
COMMUNICATION PROTOCOL:
CURRENTLY:      CLINK
SET TO:         STREAMING ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Streaming Data Configuration

The Streaming Data Configuration menu is used to allow for configuration of the 8 streaming data output items, streaming interval, current data format, and current timestamp setting. The Choose Item Signal submenu displays a list of the analog output signal group choices to choose from. Choices are Concentrations, Other Measurements, and Analog Inputs (if the I/O expansion board option is installed).

Note Add Labels, Prepend Timestamp, and Add Flags are toggle items that change between yes or no when selected. ▲

In the Main Menu, choose Instrument Controls > Communication Settings > **Streaming Data Config**.

```
STREAMING DATA CONFIG:
>INTERVAL          10 SEC
ADD LABELS         NO
PREPEND TIMESTAMP  YES
ADD FLAGS          NO
ITEM 1             SO2
ITEM 2             INTT
ITEM 3             RCTT
ITEM 4             PRES ↓

RANGE  AVG  DIAGS  ALARM

ITEM 5             SMPLFL
ITEM 6             NONE
ITEM 7             NONE
ITEM 8             NONE
```

Streaming Data Interval

The Streaming Data Interval screen is used to adjust the streaming data interval. The following interval times are available: 1, 2, 5, 10, 20, 30, 60, 90, 120, 180, 240, and 300 seconds.

In the Main Menu, choose Instrument Controls > Communication Settings > Streaming Data Config > **Streaming Data Interval**.

```

STREAMING DATA INTERVAL:
CURRENTLY:      30 SEC
SET TO:        10 SEC ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Choose Item Signal

The Choose Signal screen displays a submenu list of the analog output signal group choices. Group choices are Concentrations, Other Measurements, and Analog Inputs (if the I/O expansion board is installed).

In the Main Menu, choose Instrument Controls > Communication Settings > Streaming Data Config > **Item 1-8**.

```

CONCENTRATIONS
OTHER MEASUREMENTS
ANALOG INPUTS

RANGE  AVG  DIAGS  ALARM
  
```

Concentrations

The Concentrations screen allows the user to select the output signal that is tied to the selected streaming data item. The selected item is shown by “<--” after it. In dual or auto range mode, “HI” or “LO” is displayed to indicate high or low concentrations. Range Status is also visible in auto range mode

In the Main Menu, choose Instrument Controls > Communication Settings > Streaming Data Config > Select Item > **Concentrations**.

```
CONCENTRATIONS:
>NONE
SO2                                     <---
```

```
RANGE    AVG    DIAGS  ALARM
```

Other Measurements

The Other Measurements screen allows the user to select the output signal that is tied to the selected streaming data item. The selected item is shown by “<--” after it. In dual or auto range mode, “HI” or “LO” is displayed to indicate high or low range concentrations.

In the Main Menu, choose Instrument Controls > Communication Settings > Streaming Data Config > Select Item > **Other Measurements**.

```
OTHER MEASUREMENTS:
>NONE
INT TEMP          <--
CHAMBER TEMP
PERM OVN GAS
PERM OVN HTR
CHAMBER PRES
SAMPLE FLOW      ↓
RANGE   AVG     DIAGS ALARM
```

```
PMT VOLTS
FLASH VOLTS
FLASH REF
```

Analog Inputs

The Analog Inputs screen allows the user to select the analog input signal (none or analog inputs 1-8) that is tied to the selected streaming data item. The selected item is shown by "<--" after it.

In the Main Menu, choose Instrument Controls > Communication Settings > Streaming Data Config > Select Item > **Analog Inputs**.

```

ANALOG INPUTS:
>NONE
INPUT 1
INPUT 2
INPUT 3
INPUT 4
INPUT 5
INPUT 6
      <---
      ↓
RANGE  AVG  DIAGS  ALARM
INPUT 7
INPUT 8
  
```

RS-232/RS-485 Selection

The RS-232/RS-485 Selection screen allows the user to choose between the RS-232 or RS-485 specification for serial communication.



Equipment Damage Disconnect the serial cable before changing RS-232 and RS-485 selection to prevent damage to any equipment currently connected to the analyzer. ▲

In the Main Menu, choose Instrument Controls > Communication Settings > **RS-232/RS-485 Selection**.

```

RS-232/RS-485 SELECTION:
** WARNING **
DISCONNECT THE SERIAL
CABLES BEFORE CHANGING
THE SELECTION!
      ← TO CONTINUE
RANGE  AVG  DIAGS  ALARM
  
```

```

RS-232/RS-485 SELECTION:
CURRENTLY:      RS-232
SET TO:         RS-485 ?
MAKE SURE THAT THE CABLE
IS OFF: PRESS → TO CONFIRM
      ← TOGGLE VALUE
RANGE  AVG  DIAGS  ALARM
  
```

TCP/IP Settings

The TCP/IP Settings menu is used for defining TCP/IP settings.

Note The instrument power must be cycled after this parameter has been changed for the change to take effect. ▲

In the Main Menu, choose Instrument Controls > Communication Settings > **TCP/IP Settings**.

```

TCP/IP SETTINGS:
>USE DHCP                OFF
IP ADDRESS 192.168.1.200
NETMASK    255.255.255.0
GATEWAY    192.168.1.1
HOST NAME   iSeries
NTP SERVER  192.168.1.15

RANGE  AVG  DIAGS  ALARM

```

Use DHCP

The Use DHCP screen is used to specify whether to use DHCP or not. When DHCP is enabled, the network dynamically provides an IP address for the instrument. The instrument's power must be cycled for a change to this parameter to take affect.

In the Main Menu, choose Instrument Controls > Communication Settings > TCP/IP Settings > **Use DCHP**.

```

DHCP:
CURRENTLY:                OFF
SET TO:                   ON ?

← TOGGLE VALUE
CYCLE POWER TO CHANGE DHCP

RANGE  AVG  DIAGS  ALARM

```

IP Address

The IP Address screen is used to edit the IP address. The IP address can only be changed when DHCP is OFF. For more information on DHCP, see "Use DHCP" above.

In the Main Menu, choose Instrument Controls > Communication Settings > TCP/IP Settings > **IP Address**.

```

IP ADDRESS:
CURRENT: 192.168.1.200
SET TO:  192.168.001.01
          ↔ MOVE CURSOR
          ↑↓ CHANGE VALUE
          ← SAVE

RANGE  AVG  DIAGS  ALARM

```

Netmask The Netmask screen is used to edit the netmask. The netmask is used to determine the subnet for which the instrument can directly communicate to other devices on. The netmask can only be changed when DHCP is OFF. For more information on DHCP, see “Use DHCP” in this chapter.

In the Main Menu, choose Instrument Controls > Communication Settings > TCP/IP Settings > **Netmask**.

```

NETMASK:
CURRENT: 255.255.255.0
SET TO:  255.255.255.00
          ↔ MOVE CURSOR
          ↑↓ CHANGE VALUE
          ← SAVE
RANGE  AVG  DIAGS  ALARM

```

Gateway The Default Gateway screen is used to edit the gateway address. The default gateway can only be changed when DHCP is OFF. For more information on DHCP, see “Use DHCP” in this chapter. Any traffic to addresses that are not on the local subnet will be routed through this address.

In the Main Menu, choose Instrument Controls > Communication Settings > TCP/IP Settings > **Gateway**.

```

GATEWAY:
CURRENT: 192.168.1.1
SET TO:  192.168.001.00
          ↔ MOVE CURSOR
          ↑↓ CHANGE VALUE
          ← SAVE
RANGE  AVG  DIAGS  ALARM

```

Host Name The host name screen is used to edit the host name. When DHCP is enabled, this name is reported to the DHCP server.

In the Main Menu, choose Instrument Controls > Communication Settings > TCP/IP Settings > **Host Name**.

```
HOST NAME:
CURRENT:  ISERIES
          ISERIES ?
          ABCDEFGHIJKLMNOP BKSP
          OPQRSTUVWXYZ      PAGE
          0123456789 . / -  SAVE

RANGE  AVG  DIAGS  ALARM
```

Network Time Protocol Server

The Network Time Protocol (NTP) Server screen is used to edit the IP address of the NTP server. An NTP server may be used to periodically synchronize the instrument's real-time clock with a standard. More information about the NTP servers and a list of public servers may be found at <http://www.ntp.org>.

In the Main Menu, choose Instrument Controls > Communication Settings > TCP/IP Settings > NTP Server.

```
NTP SERVER IP ADDRESS:
CURRENT: 192.168.1.20
SET TO:  192.168.001.01
          ↔ MOVE CURSOR
          ↑↓ CHANGE VALUE
          ← SAVE

RANGE  AVG  DIAGS  ALARM
```

I/O Configuration

The I/O Configuration menu deals with configuration of the analyzer's I/O system. The analog input configuration is displayed only if the I/O expansion board option is installed.

Note The digital outputs may take up to one second after the assigned state occurs to show up on the outputs. ▲

Note Analog Input Config is only displayed if the optional I/O Expansion Board is installed. ▲

In the Main Menu, choose Instrument Controls > I/O Configuration.


```

I/O CONFIGURATION:
>OUTPUT RELAY SETTINGS
DIGITAL INPUT SETTINGS
ANALOG OUTPUT CONFIG
ANALOG INPUT CONFIG

RANGE  AVG  DIAGS  ALARM
  
```

Output Relay Settings

The Output Relay Settings menu displays a list of the 10 digital output relays available, and allows the user to select the instrument parameter or logic state to change for the relay selected.

In the Main Menu, choose Instrument Controls > I/O Configuration > Output Relay Settings > **1-10**.

```


OUTPUT RELAY SETTINGS:
>1  NOP      CONC ALARM
2   NOP      LOCAL/REMOTE
3   NOP      UNITS
4   NOP      GEN  ALARM
5   NOP      NONE
6   NOP      NONE
7   NOP      SO2  MODE  ↓

RANGE  AVG  DIAGS  ALARM

8   NOP      NONE
9   NOP      NONE
10  NOP      NONE
  
```

Logic State

The Logic State screen is used to change the I/O relay to either normally open or normally closed.

Press  to toggle and set the logic state between open and closed.

```

OUTPUT RELAY SETUP:
>LOGIC STATE      OPEN
INSTRUMENT STATE

RANGE  AVG  DIAGS  ALARM
  
```

Instrument State The Instrument State submenu allows the user to select the instrument state that is tied to the selected relay output. A submenu lists signal types of either alarm and non-alarm to choose from.

In the Main Menu, choose Instrument Controls > I/O Configuration > Output Relay Settings > Select Relay > **Instrument State**.

```
CHOOSE SIGNAL TYPE:
>ALARMS
  NON-ALARM

RANGE  AVG  DIAGS  ALARM
```

Alarms The Alarms status screen allows the user to select the alarm status for the selected relay output. The selected item is shown by “<--” after it.

In the Main Menu, choose Instrument Controls > I/O Configuration > Output Relay Settings > Select Relay > Instrument State > **Alarms**.

Note The I/O BD STATUS alarm is only present if the I/O expansion board is installed. ZERO CHK/CAL and SPAN CHK/CAL are only present if autozero/span check is enabled. ▲

```
ALARM STATUS ITEMS:
>NONE <--
  GEN ALARM
  SO2 CONC MAX
  SO2 CONC MIN
  INT TEMP
  CHAMB TEMP
  PRESSURE
  RANGE  AVG  DIAGS  ALARM

SAMPLE FLOW
FLASH REF
FLASH VOLTS
MB STATUS
MIB STATUS
I/O BD STATUS
CONC ALARM
ZERO CHK/CAL
SPAN CHK/CAL
```

Non-Alarm

The Non-Alarm status screen allows the user to select the non-alarm status for the selected relay output. The selected item is shown by “<--” after it.

In the Main Menu, choose Instrument Controls > I/O Configuration > Output Relay Settings > Relay 1-10 > Instrument State > **Non-Alarm**.

```

NON ALARM STATUS ITEMS:
>NONE                <--
AUTORANGE
LOCAL/REMOTE
SERVICE
UNITS
ZERO MODE
SPAN MODE
↓
RANGE  AVG  DIAGS  ALARM
SAMPLE MODE
SO2 MODE
PURGE MODE

```

Digital Input Settings

The Digital Input Settings menu displays a list of the 16 digital inputs available, and allows the user to select the instrument parameter or logic state to change for the relay selected.

Note The digital inputs must be asserted for at least one second for the action to be activated. ▲

Note Not all of the I/O available in the instrument is brought out on the supplied terminal board, if more I/O is desired, an alternative means of connection is required. ▲

In the Main Menu, choose Instrument Controls > I/O Configuration > Digital Input Settings.

```

DIGITAL INPUT SETTINGS:
>1      NOP      SO2
2      NOP      SET BACKGROUND
3      NOP      CAL TO SPAN
4      NOP      AOUTS TO ZERO
5      NOP      AOUTS TO FS
6      NOP      NONE
7      NOP      NONE
↓
RANGE  AVG  DIAGS  ALARM


8      NOP      NONE
9      NOP      NONE
10     NOP      NONE
11     NOP      NONE

```

12	NOP	NONE
13	NOP	NONE
14	NOP	NONE
15	NOP	NONE
16	NOP	NONE

Logic State

The Logic State screen is used to change the I/O relay to either normally open or normally closed. The default state is open, which indicates that a relay connected between the digital input pin and ground is normally open and closes to trigger the digital input action. If nothing is connected to the digital input pin, the state should be left at open to prevent the action from being triggered.

Press  to toggle and set the logic state open or closed.

```

DIGITAL INPUT SETUP:
>LOGIC STATE      OPEN
INSTRUMENT ACTION

RANGE  AVG  DIAGS  ALARM
  
```

Instrument Action

The Instrument Action screen allows the user to select the instrument state that is tied to the selected digital input.

In the Main Menu, choose Instrument Controls > I/O Configuration > Digital Input Settings > Select Relay > **Instrument State**.

```

CHOOSE ACTION:
>NONE             <---
ZERO MODE
SPAN MODE

SET BACKGROUND
CAL TO LO SPAN
AOUTS TO ZERO      ↓

RANGE  AVG  DIAGS  ALARM

AOUTS TO FS
CAL TO HI SPAN
  
```

Analog Output Configuration (Select Channel)

The Analog Output Configuration menu displays a list of the analog output channels available for configuration. Channel choices include all voltage channels, all current channels, individual voltage channels 1–6, and

individual current channels 1–6 (if the I/O expansion board option is installed).

In the Main Menu, choose Instrument Controls > I/O Configuration > **Analog Output Config.**

```

OUTPUT CHANNELS:
>ALLOW OVER/UNDER RANGE
ALL VOLTAGE CHANNELS
ALL CURRENT CHANNELS
VOLTAGE CHANNEL 1
VOLTAGE CHANNEL 2
↓
RANGE  AVG  DIAGS  ALARM

```

Allow Over/Under Range

The Allow Over/Under Range screen is used to select whether or not the analog outputs are allowed to exceed the maximum selected value of 100 mV, 1 V, 5 V, 10 V, or 20 mA or the minimum selected value of 0 V, 0 mA, or 4 mA. By default, this parameter is set to on and 5% over and under range is allowed for all analog output channels.

- In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Output Config > **Allow Over/Under Range.**

```

ALLOW OVER/UNDER RANGE:
CURRENTLY:                ON
SET TO:                   OFF  ?
                            ← TOGGLE VALUE
RANGE  AVG  DIAGS  ALARM

```

Analog Output Configuration (Select Action)

The Analog Output Configuration menu displays a list of the analog output configuration choices, from which the user selects the parameter to adjust for the selected output channel. Configuration choices include selecting range, setting minimum/maximum values, and choosing the signal to output.

- In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Output Config > **All Voltage Channels, All Current Channels, Voltage Channel 1–6 or Current Channel 1–6.**

```

ANALOG OUTPUT CONFIG:
>SELECT RANGE
  SET MINIMUM VALUE
  SET MAXIMUM VALUE
  CHOOSE SIGNAL TO OUTPUT

RANGE  AVG  DIAGS  ALARM
  
```

Select Range

The Select Range screen is used to select the hardware range for the selected analog output channel. Possible ranges for the voltage outputs are: 0-100 mV, 0-1, 0-5, and 0-10 V. Possible ranges for the current outputs are: 0-20 mA and 4-20 mA.

- In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Output Config > select Channel > **Select Range**.

```

SELECT OUTPUT RANGE:
SELECTED OUTPUT:  V ALL
CURRENTLY:        0-10V
SET TO:           0-100mV ?

↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM
  
```

Minimum and Maximum Value

The Minimum Value screen is used to edit the zero (0) to full-scale (100) value in percentages for the selected analog output channel. See Table 3-7 for a list of choices. In dual or auto range mode, “HI” or “LO” is displayed to indicate high or low concentrations. Range Status is visible only in auto range mode. The minimum and maximum output value screens function the same way. The example that follows shows the set minimum value screen.

In the Main Menu, choose Instrument Controls > IO Configuration > Analog Output Config > Select Channel > **Set Minimum** or **Maximum Value**.

```

MINIMUM OUTPUT PERCENT:
SELECTED OUTPUT:  V 1
CURRENTLY:        N/A %
SET TO:           0000.0 % ?

↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM
  
```

Table 3–7. Analog Output Zero to Full Scale Values

Output	Zero % Value	Full-Scale 100% Value
SO ₂	Zero (0)	Range Setting
LO SO ₂	Zero (0)	Range Setting
HI SO ₂	Zero (0)	Range Setting
Range SO ₂	Changing the setting for this output is not recommended	
Internal Temp	User-set alarm min value	User-set alarm max value
Chamber Temp	User-set alarm min value	User-set alarm max value
Perm Oven Gas Temp	Perm Oven Gas alarm min value	Perm Oven Gas alarm max value
Perm Oven Heater Temp	Perm Oven Heater alarm min value	Perm Oven Heater alarm max value
Pressure	User-set alarm min value	User-set alarm max value
Sample Flow	User-set alarm min value	User-set alarm max value
PMT Volts	700 volts	1100 volts
Flash Voltage	User-set alarm min value	User-set alarm max value
Flash Reference	User-set alarm min value	User-set alarm max value
Everything Else	0 units	10 units

Choose Signal To Output

The Choose Signal To Output screen displays a submenu list of the analog output signal group choices. Group choices are Concentrations, Other Measurements, and Analog Inputs (if the I/O expansion board is installed). This allows the user to select the output signal to the selected output channel. In dual or auto range mode, “HI” or “LO” is displayed to indicate high or low concentrations. Range (SO₂) is visible only in auto range mode. The Concentrations screen is shown below. See Table 3-8 that follows for a list of items for each signal group choice.

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Output Config > Select Channel > **Choose Signal To Output**.

```

CHOOSE SIGNAL TYPE:
>CONCENTRATIONS
  OTHER MEASUREMENTS
  ANALOG INPUTS

RANGE  AVG  DIAGS  ALARM

```

```

CHOOSE SIGNAL -      CONC
SELECTED OUTPUT:      V1
CURRENTLY: LO SO2
SET TO: LO SO2

↑↓ CHANGE VALUE      ← SAVE

RANGE  AVG  DIAGS  ALARM

```

Table 3–8. Signal Types Group Choices

Concentrations	Other Measurements	Analog Inputs	
None	None	None	
SO2 (single/auto range only)	Internal Temperature	Analog Input 1	I/O Expansion Board installed
LO SO2 (dual range only)	Chamber Temperature	Analog Input 2	I/O Expansion Board installed
HI SO2 (dual/auto range only)	Perm Oven Gas (only if perm oven installed)	Analog Input 3	I/O Expansion Board installed
Range Status (auto range only)	Perm Oven Heater (only if perm oven installed)	Analog Input 4	I/O Expansion Board installed
	Chamber Pressure	Analog Input 5	I/O Expansion Board installed
	Sample Flow	Analog Input 6	I/O Expansion Board installed
	PMT Volts	Analog Input 7	I/O Expansion Board installed
	Flash Volts	Analog Input 8	I/O Expansion Board installed
	Flash Ref		

Analog Input Configuration

The Analog Input Configuration menu displays a list of the 8 analog input channels available for configuration. This screen is only displayed if the I/O expansion board option is installed. Configuration includes entering descriptor, units, decimal places, and choice of 2-10 table points, and corresponding number of points selected.

In the Main Menu, choose Instrument Controls > I/O Configuration > **Analog Input Config.**


```

ANALOG INPUT CONFIG:
>CHANNEL 1          IN1
CHANNEL 2          IN2
CHANNEL 3          IN3
CHANNEL 4          IN4
CHANNEL 5          IN5
CHANNEL 6          IN6
CHANNEL 7          IN7↓
  
```

RANGE AVG DIAGS ALARM

CHANNEL 8

IN8

```

ANALOG INPUT 01 CONFIG:
>DESCRIPTOR          IN1
UNITS                V
DECIMAL PLACES      2
TABLE POINTS        2
POINT 1
POINT 2
  
```

RANGE AVG DIAGS ALARM

Descriptor

The Descriptor screen allows the user to enter the descriptor for the selected analog input channel. The descriptor is used in datalogging and streaming data to report what data is being sent out. The descriptor may be from 1 to 3 characters in length, and defaults to IN1 to IN8 (user input channel number).

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > Select Channel > **Descriptor**.

```

ANALOG INPUT DESCRIPTOR:
  █
  ABCDEFGHIJKLMNOP BKSP
  OPQRSTUVWXYZ      PAGE
  0123456789 . / -  SAVE
  
```

RANGE AVG DIAGS ALARM

Units

The Units screen allows the user to enter the units for the selected analog input channel. The units are displayed on the diagnostic screen and in datalogging and streaming data. The units may be from 1 to 3 characters in length, and defaults to V (volts).

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > Select Channel > **Units**.

```
ANALOG INPUT UNITS:
      █
      ABCDEFGHIJKLMN  BKSP
      OPQRSTUVWXYZ   PAGE
      0123456789 . / -  SAVE

RANGE  AVG  DIAGS  ALARM
```

Decimal Places

The Decimal Places screen allows the user to select how many digits are displayed to the right of the decimal, from 0 to 6, with a default of 2.

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > Select Channel > **Decimal Places**.

```
DECIMAL PLACES:
CURRENTLY:          2
SET TO:             3 ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Number of Table Points

The Number of Table Points screen allows the user to select how many points are used in the analog input conversion table. The instrument uses linear interpolation between the points in this table to determine what the reading value is based on the analog input voltage. Each point in the table consists of an analog input voltage value (0-10.5 V) and a corresponding reading value. Only two points are necessary for linear inputs, however a larger number of points may be used to approximate non-linear inputs. The points range from 2 to 10, with a default of 2.

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > Select Channel > **Table Points**.

```
NUMBER OF TABLE POINTS:
CURRENTLY:          2
SET TO:             10 ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Table Point

The Table Point submenu allows the user to set up an individual table point.

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > **Table Point 1-10**.

```
TABLE POINT 01 CONFIG:
>VOLTS          0.00
USER VALUE      0.00

RANGE  AVG  DIAGS  ALARM
```

Volts

The Volts screen allows the user to set the input voltage for the selected table point in the conversion table, from 0.00 to 10.50. The default table is a two-point table with point 1: 0.00 V = 000.0 U and point 2: 10.00 V = 10.0 U.

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > Select Table Point > **Volts**.

```
TABLE POINT 01 VOLTS:
CURRENTLY:      00.00
SET TO:         00.00

↔ MOVE CURSOR
← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

User Value

The User Value screen allows the user to set the output value for the corresponding input voltage for the selected table point in the conversion table, from -9999999 to 99999999. The default table is a two-point table with point 1: 0.00 V = 000.0 U and point 2: 10.00 V = 10.0 U.

In the Main Menu, choose Instrument Controls > I/O Configuration > Analog Input Config > Select Table Point > **User Value**.

```
TABLE POINT 01 USER VAL:  
CURRENTLY:      0.00  
SET TO:         00000.00  
  
    ↔ MOVE CURSOR  
    ← SAVE VALUE  
  
RANGE  AVG  DIAGS ALARM
```

Temperature Compensation

Temperature compensation provides compensation for any changes to the instrument's output signal due to internal instrument temperature variations. The effects of internal instrument temperature changes on the analyzer's subsystems and output have been empirically determined. This empirical data is used to compensate for any changes in temperature. This compensation can be used for special applications, or when operating the instrument outside the recommended temperature range.

When temperature compensation is on, the first line of the display shows the current internal instrument temperature (measured by a thermistor on the Interface board). When temperature compensation is off, the first line of the display shows the factory standard temperature of 30 °C.

In the Main Menu, choose Instrument Controls > **Temperature Compensation**.

```
TEMPERATURE COMPENSATION:  
COMP TEMP:      30.0 °C  
CURRENTLY:      OFF  
SET TO:         ON ?  
  
    ← TOGGLE VALUE  
  
RANGE  AVG  DIAGS ALARM
```

Pressure Compensation

Pressure compensation provides compensation for any changes to the instrument's output signal due to reaction chamber pressure variations. The effects of reaction chamber pressure changes on the analyzer's subsystems and output have been empirically determined. This empirical data is used to compensate for any change in reaction chamber pressure.

When pressure compensation is on, the display represents the current pressure in the fluorescence chamber. When pressure compensation is off, the display shows the factory standard pressure of 750 mmHg.

In the Main Menu, choose Instrument Controls > **Pressure Compensation**.

```

PRESSURE COMPENSATION:
COMP PRES: 750.0 mmHg
CURRENTLY: OFF
SET TO: ON ?

      ← TOGGLE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Screen Contrast

The Screen Contrast screen is used to change the contrast of the display. Values between 0 and 100% in increments of 5 are available. Changing the screen contrast may be necessary if the instrument is operated at extreme temperatures.

In the Main Menu, choose Instrument Controls > **Screen Contrast**.

```

SCREEN CONTRAST:
CURRENTLY: 50 %
SET TO: 60 % ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Notes The optimal contrast will change with changes in temperature. ▲

The optimal contrast will change from one LCD screen to another. If the LCD screen is replaced, the contrast may need to be reset. ▲

If the display contrast is not optimal, but the content on the screen is visible, select Instrument Controls > **Screen Contrast** and adjust the screen contrast. If the content on the screen is not visible, use the “set contrast 10” C-Link command to set screen contrast to mid range, then optimize the contrast. See “Contrast Levels” in the “C-Link Protocol Commands Appendix” section of this document for more information on this command. ▲

Service Mode

The Service Mode screen is used to turn the service mode on or off. The service mode locks out any remote actions and includes parameters and functions that are useful when making adjustments or diagnosing the Model 43i. For more information about the service mode, see “Service Menu” later in this chapter.

Note The service mode should be turned off when finished, as it prevents remote operation. ▲

In the Main Menu, choose Instrument Controls > **Service Mode**.

```
SERVICE MODE:
CURRENTLY:      OFF
SET TO:         ON ?
                ◀ TOGGLE VALUE

RANGE  AVG  DIAGS  ALARM
```

Date/Time The Date/Time screen and allows the user to view and change the system date and time (24-hour format). The internal clock is powered by its own battery when instrument power is off.

In the Main Menu, choose Instrument Controls > **Date/Time**.

```
DATE AND TIME:
19 MAR 2005 12:34:56
PRESS ◀ TO EDIT

RANGE  AVG  DIAGS  ALARM
```

```
DATE AND TIME:
19 MAR 2005 12:34:56 ?
SETTING: DAYS
  ▶ SET MONTHS
  ⬆ CHANGE VALUE
  ◀ SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Timezone The Timezone screen is used to set the timezone for the NTP time server. This should be set to the timezone that the instrument is located in. If the exact timezone is not shown in the list, it may be entered via the CLINK “TZ” command (see Appendix B). The selections are: UTC (GMT), EST (GMT+5), CST (GMT+6), MST (GMT+7), PST (GMT+8), YST (GMT+9), HST (GMT+10), NST (GMT+11), DLW (GMT+12), CET (GMT-1), EET (GMT-2), BST (GMT-3), DLT (GMT-4), ECH (GMT-5), FOX (GMT-6), GLF (GMT-7), CCT (GMT-8), JST (GMT-9), GST (GMT-10), LMA (GMT-11), DLE (GMT-12), EDT (GMT+5/4), CDT (GMT+6/5), MDT (GMT+7/6), and PDT (GMT+8/7).

In the Main Menu, choose Instrument Controls > **Timezone**.

```

TIMEZONE FOR TIMESERVER:
CURRENTLY: UTC (GMT)
SET TO: UTC (GMT)

      ↕ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM

```

Diagnostics Menu

The Diagnostics menu provides access to diagnostic information and functions. This menu is useful when troubleshooting the instrument. The analog input readings and analog input voltages are only displayed if the I/O expansion board option is installed.

In the Main Menu, choose Instrument Controls > **Diagnostics**.

```

DIAGNOSTICS:
>PROGRAM VERSIONS
VOLTAGES
TEMPERATURES
PRESSURE
FLOW
LAMP INTENSITY
OPTICAL SPAN TEST      ↓

RANGE  AVG  DIAGS  ALARM

ANALOG INPUT READINGS
ANALOG INPUT VOLTAGES
DIGITAL INPUTS
RELAY STATES
TEST ANALOG OUTPUTS
INSTRUMENT CONFIGURATION
CONTACT INFORMATION

```

Program Versions

The Program Versions screen (read only) shows the version numbers of the programs installed. Prior to contacting the factory with any questions regarding the instrument, please note the product model program version numbers.

In the Main Menu, choose Diagnostics > **Program Versions**.

```

PROGRAM VERSIONS:
PRODUCT:  MODEL 43i
VERSIONS: 01.02.22.104
FIRMWARE: 07.92.19

RANGE  AVG  DIAGS  ALARM

```

Voltages

The Voltages menu displays the current diagnostic voltage readings. This screen enables the power supply to be quickly read for low or fluctuating voltages without having to use a voltage meter. The I/O board item is only displayed if the I/O expansion board is installed.

In the Main Menu, choose Diagnostics > **Voltages**.

```
VOLTAGES:
>MOTHERBOARD
INTERFACE BOARD
I/O BOARD

RANGE  AVG  DIAGS  ALARM
```

Motherboard Voltages

The Motherboard screen (read only) is used to display the current voltage readings on the motherboard.

In the Main Menu, choose Diagnostics > Voltages > **Motherboard Voltages**.

```
MOTHERBOARD VOLTAGES:
3.3 SUPPLY      3.3 V
5.0 SUPPLY      5.0 V
15.0 SUPPLY     15.0 V
24.0 SUPPLY     24.0 V
-3.3 SUPPLY     -3.3 V

RANGE  AVG  DIAGS  ALARM
```

Interface Board Voltages

The Interface Board screen (read only) is used to display the current voltage readings on the interface board.

In the Main Menu, choose Diagnostics > Voltages > **Interface Board Voltages**.


```

INTERFACE BOARD VOLTAGES:
  PMT SUPPLY      612.5 V
  FLASH SUPPLY    1000.0 V
  3.3 SUPPLY      3.3 V
  5.0 SUPPLY      5.0 V
  15.0 SUPPLY     15.0 V
  -15.0 SUPPLY    -15.0 V
  24.0 SUPPLY     24.0 V

  RANGE  AVG  DIAGS  ALARM
  
```

I/O Board Voltages

The I/O Board screen (read only) is used to display the current voltage readings on the I/O expansion board. This menu is only accessible if the I/O expansion board is installed.

In the Main Menu, choose Diagnostics > Voltages > **I/O Board Voltages**.

```

I/O BOARD VOLTAGES:
  3.3 SUPPLY      3.3 V
  5.0 SUPPLY      5.0 V
  24.0 SUPPLY     24.0 V
  -3.3 SUPPLY     -3.3 V

  RANGE  AVG  DIAGS  ALARM
  
```

Temperatures

The Temperatures screen (read only) displays the current internal instrument temperature and chamber temperature. The internal temperature is the air temperature measured by a sensor located on the interface board.

In the Main Menu, choose Diagnostics > **Temperatures**.

```

TEMPERATURES:
>INTERNAL          34.6 °C
CHAMBER            49.7 °C
PERM OVEN GAS      45.00 °C
PERM OVEN HTR      45.00 °C

  RANGE  AVG  DIAGS  ALARM
  
```

Pressure

The Pressure screen (read only) displays the current optical bench pressure. The pressure is measured by a pressure transducer in-line with the optical bench.

In the Main Menu, choose Diagnostics > **Pressure**.

PRESSURE: 753.0 mmHg

RANGE AVG DIAGS ALARM

Sample Flow

The Sample Flow screen (read only) displays the current sample flow rate. The flows is measured by an internal flow sensor.

In the Main Menu, choose Diagnostics > Flow.

SAMPLE FLOW: 0.500 LPM

RANGE AVG DIAGS ALARM

Lamp Intensity

The Lamp Intensity screen (read only) displays the current lamp intensity in Hertz. Normally the intensity would read 90%, but this number will decrease over time as the lamp degrades.

In the Main Menu, choose Diagnostics > **Lamp Intensity**.

```
LAMP INTENSITY:          90 %

RANGE  AVG  DIAGS  ALARM
```

Optical Span Test

The Optical Span Test screen is used to turn the optical span test LED on or off, and displays the SO₂ concentration reading. Within the fluorescence chamber is a light emitting diode (LED) which may be used to simulate a particular concentration of SO₂. It is designed to provide a quick and easy way of checking the optics and electronics for span drift or other problems. The difference between when the LED is ON and OFF must be greater than 50 ppb.

In the Main Menu, choose Diagnostics > **Optical Span Test**.

```

OPTICAL SPAN TEST:
  SO2:          100
CURRENTLY:      ON
SET TO:        OFF ?

      ← TOGGLE VALUE

RANGE  AVG  DIAGS  ALARM

```

Analog Input Readings

The Analog Input Readings screen (read only) displays the 8 current user-scaled analog readings (if the I/O expansion board option is installed).

In the Main Menu, choose Diagnostics > **Analog Input Readings**.

```

ANALOG INPUT READINGS:
>NO          10.2 PFB
NO2          18.2 PFB
CO2          250 PPM
FL1          20.42 LPM
WND          9.86 V
FL2          1.865 LPM
IO7          0.0 V↓

RANGE  AVG  DIAGS  ALARM

IO8          0.0 V

```

Analog Input Voltages

The Analog Input Voltages screen (read only) displays the 8 raw analog voltage readings (if the I/O expansion board option is installed).

In the Main Menu, choose Diagnostics > **Analog Input Voltages**.

```

ANALOG INPUT VOLTAGES:
>ANALOG IN 1      6.24 V
ANALOG IN 2      4.28 V
ANALOG IN 3      0.00 V
ANALOG IN 4      0.00 V
ANALOG IN 5      0.00 V
ANALOG IN 6      0.00 V
ANALOG IN 7      0.00 V↓

RANGE  AVG  DIAGS  ALARM

ANALOG IN 8      0.00 V

```

Digital Inputs

The Digital Inputs screen (read only) displays the state of the 16 digital inputs. Pull-ups are provided on all the inputs, so if nothing is connected they will read (1), if an input is brought to ground, it will read (0).


In the Main Menu, choose Diagnostics > **Digital Inputs**.

DIGITAL INPUTS:		
>INPUT	1	1
INPUT	2	1
INPUT	3	1
INPUT	4	1
INPUT	5	1
INPUT	6	1
INPUT	7	1 ↓
RANGE	AVG	DIAGS ALARM
INPUT	8	1
INPUT	9	1
INPUT	10	1
INPUT	11	1
INPUT	12	1
INPUT	13	1
INPUT	14	1
INPUT	15	1
INPUT	16	1

Relay States

The Relay States screen displays the state of the 10 digital outputs and allows toggling of the state to either on (1) or off (0). The relays are restored to their original states upon exiting this screen.

In the Main Menu, choose Diagnostics > **Relay States**.

Press  to toggle the relay state open and closed.

RELAY STATE:		
>OUTPUT	1	1
OUTPUT	2	0
OUTPUT	3	0
OUTPUT	4	1
OUTPUT	5	0
OUTPUT	6	0
OUTPUT	7	0 ↓
RANGE	AVG	DIAGS ALARM
OUTPUT	8	0
OUTPUT	9	0
OUTPUT	10	0

Test Analog Outputs

The Test Analog Outputs menu contains a number of digital to analog converter (DAC) calibration items. Channel choices include all analog outputs, 6 voltage channels, and 6 current channels (if the I/O expansion board option is installed).

In the Main Menu, choose Diagnostics > **Test Analog Outputs**.

```

TEST ANALOG OUTPUTS:
>ALL
VOLTAGE CHANNEL 1
VOLTAGE CHANNEL 2
VOLTAGE CHANNEL 3
VOLTAGE CHANNEL 4
VOLTAGE CHANNEL 5
VOLTAGE CHANNEL 6
↓
RANGE  AVG  DIAGS  ALARM

CURRENT CHANNEL 1
CURRENT CHANNEL 2
CURRENT CHANNEL 3
CURRENT CHANNEL 4
CURRENT CHANNEL 5
CURRENT CHANNEL 6

```

Set Analog Outputs

The Set Analog Outputs screen contains three choices: Set to full-scale, set to zero, or reset to normal. Full-scale sets the analog outputs to the full-scale voltage, zero sets the analog outputs to 0 volts, and normal operation. The example that follows shows the selected output state “ALL” is set to full-scale.

In the Main Menu, choose Diagnostics > Test Analog Outputs > **ALL**, **Voltage Channel 1-6**, or **Current Channel 1-6**.

```


TEST ANALOG OUTPUTS:
SETTING:
OUTPUT SET TO: FULL SCALE
↑ SET TO FULL SCALE
↓ SET TO ZERO
← RESET TO NORMAL
RANGE  AVG  DIAGS  ALARM

```

Instrument Configuration

The Instrument Configuration screen displays information on the hardware configuration of the instrument.

In the Main Menu, choose Diagnostics > **Instrument Configuration**.

Note If the analyzer is in service mode, pressing  on the item will toggle it yes or no (with the exception of dilution ratio and auto calibration, which may only be enabled at the factory). ▲

```
INSTRUMENT CONFIGURATION:
>I/O EXPANSION BOARD  YES
ZERO/SPAN VALVES      YES
PERM OVEN              NO
DILUTION               YES
AUTO CALIBRATION       YES

RANGE  AVG  DIAGS  ALARM
```

Contact Information

The Contact Information screen displays the customer service information.

In the Main Menu, choose Diagnostics > **Contact Information**.

```
CONTACT INFORMATION:


CALL CENTER: 508-520-0430

WEB:          WWW.THERMO.COM

RANGE  AVG  DIAGS  ALARM
```

Alarms Menu

The alarms menu displays a list of items that are monitored by the analyzer. If the item being monitored goes outside the lower or upper limit, the status of that item will go from “OK” to either “LOW” or “HIGH”, respectively. If the alarm is not a level alarm, the status will go from “OK” to “FAIL”. The number of alarms detected is displayed to indicate how many alarms have occurred. If no alarms are detected, the number zero is displayed.

To see the actual reading of an item and its minimum and maximum limits, move the cursor to the item and press .

Items displayed are determined by the options displayed. Zero Autocal or Span Autocal are visible only if Zero Cal Reset or Span Cal Reset are turned ON. Otherwise, Zero Check or Span Check are displayed. The motherboard status, interface board status, and I/O expansion board status (if installed) indicates that the power supplies are working and connections are successful. There are no setting screens for these alarms.

In the Main Menu, choose **Alarms**.

```

ALARMS:
ALARMS DETECTED      0
>INTERNAL TEMP      OK
CHAMBER TEMP        OK
PERM GAS TEMP       OK
PRESSURE            OK
SAMPLE FLOW         OK
LAMP INTENSITY      OK
LAMP VOLTAGE        OK↓

RANGE  AVG  DIAGS  ALARM

ZERO CHECK          OK
SPAN CHECK          OK
ZERO AUTOCAL        OK
SPAN AUTOCAL        OK
SO2 CONCENTRATION   OK
MOTHERBOARD STATUS  OK
INTERFACE STATUS    OK
I/O EXP STATUS       OK
  
```

Internal Temperature

The internal temperature screen displays the current internal temperature and sets the minimum and maximum alarm limits. Acceptable alarm limits range from 8 to 47 °C. If the internal temperature reading goes beyond either the minimum or maximum alarm limit, an alarm is activated. The word “ALARM” appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > **Internal Temp**.

```

INTERNAL TEMPERATURE:
ACTUAL              30.1 °C
>MIN                8.0 °C
MAX                47.0 °C

RANGE  AVG  DIAGS  ALARM
  
```

Min and Max Internal Temperature Limits

The Minimum Internal Temperature alarm limit screen is used to change the minimum internal temperature alarm limit. The minimum and maximum internal temperature screens function the same way.

In the Main Menu, choose Alarms > Internal Temp > **Min** or **Max**.

```
INTERNAL TEMPERATURE:
ACTUAL MIN:          15.0 °C
SET MIN TO:          10.0 °C ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Chamber Temperature

The Chamber Temperature screen displays the current chamber temperature and sets the minimum and maximum alarm limits. The chamber temperature is regulated at 45.0 degrees C. Acceptable alarm limits range from 43 to 47 °C. If the chamber temperature reading goes beyond either the minimum or maximum limit, an alarm is activated. The word alarm appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > **Chamber Temp**.

```
CHAMBER TEMPERATURE:
ACTUAL              45.4 °C
>MIN                43.0 °C
MAX                47.0 °C

RANGE  AVG  DIAGS  ALARM
```

Min and Max Chamber Temperature Limits

The Minimum Chamber Temperature alarm limit screen is used to change the minimum chamber temperature alarm limit. The minimum and maximum internal temperature screens function the same way.

In the Main Menu, choose Alarms > Chamber Temp > **Min** or **Max**.

```
CHAMBER TEMPERATURE:
ACTUAL MIN:          45.4 °C
SET MIN TO:          44.0 °C ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```


Pressure

The Pressure screen displays the current reaction chamber pressure reading and sets the minimum and maximum alarm limits. Acceptable alarm limits range from 400 to 1000 mmHg. If the pressure reading goes beyond either the minimum or maximum limit, an alarm is activated. The word “ALARM” appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > **Pressure**.

```

PRESSURE:
  ACTUAL      750.0 mmHg
  >MIN        400.0 mmHg
  MAX         1000.0 mmHg

  RANGE  AVG  DIAGS  ALARM
  
```

Min and Max Pressure Limits

The Minimum Pressure alarm limit screen is used to change the minimum pressure alarm limit. The minimum and maximum pressure screens function the same way.

In the Main Menu, choose Alarms > Pressure > **Min** or **Max**.

```

PRESSURE:
  ACTUAL MIN:  400.0 mmHg
  SET MIN TO:  500.0 mmHg?

      ↑↓ INC/DEC
      ← SAVE VALUE

  RANGE  AVG  DIAGS  ALARM
  
```

Sample Flow

The Sample Flow screen displays the current sample flow reading and sets the minimum and maximum alarm limits. Acceptable alarm limits range from 0 to 2.5 LPM. If the sample flow reading goes beyond either the minimum or maximum limit, an alarm is activated. The word “ALARM” appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > **Sample Flow**.

```
SAMPLE FLOW:
ACTUAL      0.550 LPM
>MIN       0.000 LPM
MAX        1.000 LPM

RANGE  AVG  DIAGS  ALARM
```

Min and Max Sample Flow Limits

The Minimum Sample Flow alarm limit screen is used to change the minimum sample flow alarm limit. The minimum and maximum sample flow screens function the same way.

In the Main Menu, choose Alarms > Sample Flow > **Min** or **Max**.

```
SAMPLE FLOW:
ACTUAL MIN:  0.250 LPM
SET MIN TO:  0.300 LPM ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Lamp Intensity

The Lamp Intensity screen displays the current lamp intensity reading and sets the minimum and maximum alarm limits. Acceptable alarm limits range from 20 to 100 percent. If the lamp intensity reading goes beyond either the minimum or maximum limit, an alarm is activated. The word “ALARM” appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > **Lamp Intensity**.

```
LAMP INTENSITY:
ACTUAL          90 %
>MIN           40 %
MAX           100 %

RANGE  AVG  DIAGS  ALARM
```

Min and Max Lamp Intensity Limits

The Minimum Lamp Intensity alarm limit screen is used to change the minimum lamp intensity alarm limit. The minimum and maximum lamp intensity screens function the same way.

In the Main Menu, choose Alarms > Lamp Intensity > **Min** or **Max**.

```

LAMP INTENSITY:
ACTUAL MIN:      40 %
SET MIN TO:      50 % ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM

```

Lamp Voltage

The Lamp Voltage screen displays the current lamp voltage and sets the minimum and maximum alarm limits. Acceptable alarm limits range from 500 to 1200 volts. If the lamp voltage goes beyond either the minimum or maximum limit, an alarm is activated. The word “ALARM” appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > **Lamp Voltage**.

```

LAMP VOLTAGE:
ACTUAL          800 V
>MIN            750 V
MAX            1200 V

RANGE  AVG  DIAGS  ALARM

```

Min and Max Lamp Voltage Limits

The Minimum Lamp Voltage alarm limit screen is used to change the minimum lamp voltage alarm limit. The minimum and maximum lamp voltage screens function the same way.

In the Main Menu, choose Alarms > Lamp Voltage > **Min** or **Max**.

```

LAMP VOLTAGE:
ACTUAL MIN:      750 V
SET MIN TO:      700 V ?

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM

```

Zero and Span Check

The Zero Span Check screen allows the user to view the status of the most recent zero check and set the maximum zero check offset. The zero and span check screens are visible only if the zero/span check option is enabled and function the same way.

In the Main Menu, choose Alarms > **Zero** or **Span Check**.

```
ZERO CHECK:
  ALARM:      OK
  RESPONSE:   1.0
>MAX OFFSET: 5.0

RANGE  AVG  DIAGS  ALARM
```

Max Zero and Span Offset

The Max Zero Check Offset screen is used to change the maximum zero check offset. The maximum zero and span offset screens function the same way.

In the Main Menu, choose Alarms > Zero or Span Check > **Max Offset**.

```
MAX ZERO CHECK OFFSET:
  CURRENTLY:   5.0
  SET TO:     000010.00 ?

  ←→ MOVE CURSOR
  ←  SAVE

RANGE  AVG  DIAGS  ALARM
```

Zero and Span Auto Calibration

The Zero and Span Check screen allows the user to view the status of the most recent zero/span checks and set the maximum check offsets. An alarm will be triggered if a zero or span check indicates drift that exceeds the offset value. The zero and span check screens are visible only if the zero/span check option is enabled. Their functions are similar.

In the Main Menu, choose Alarms > **Zero** or **Span Autocal**.

```
ZERO AUTO CALIBRATION:
  ALARM:      OK
  RESPONSE:   1.2

RANGE  AVG  DIAGS  ALARM
```

SO₂ Concentration

The SO₂ Concentration screen displays the current SO₂ concentration and sets the maximum alarm limit. Acceptable alarm limits range from 0 to 10000 ppm. The minimum alarm may be programmed as a floor trigger

(alarm is triggered when the concentration falls below the minimum value) or a ceiling trigger (alarm is triggered when the concentration goes above the minimum value). If the SO₂ concentration goes beyond either the minimum or maximum limit, an alarm is activated. The word “ALARM” appears in the Run screen and in the Main Menu.

In the Main Menu, choose Alarms > SO₂ Concentration.

```
SO2 CONCENTRATION:
  ACTUAL          35.7
>MIN             500.0
  MAX             500.0
  MIN TRIGGER     CEILING

RANGE  AVG  DIAGS  ALARM
```

**Min and Max SO₂
Concentration Limits**

The Minimum SO₂ Concentration alarm limit screen is used to change the minimum SO₂ concentration alarm limit. The minimum and maximum SO₂ concentration alarm limit screens function the same way.

In the Main Menu, choose Alarms > SO₂ Concentration> **Min** or **Max**.

```
SO2 CONCENTRATION:
  ACTUAL MIN:     500.0
  SET MIN TO:     000400.0 ?

      ↔ MOVE CURSOR
  ↑↓ INC/DEC  ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Min Trigger

The Minimum Trigger screen allows the user to view and set the SO₂ concentration alarm trigger type to either floor or ceiling. The minimum alarm may be programmed as a floor trigger (alarm is triggered when the concentration falls below the minimum value) or a ceiling trigger (alarm is triggered when the concentration goes above the minimum value).

In the Main Menu, choose Alarms > SO₂ Concentration > **Min Trigger**.

```
MIN TRIG(CEILING/FLOOR):  
  ACTUAL TRIGGER: CEILING  
  SET TRIGGER TO:  FLOOR ?  
  
← TOGGLE AND SAVE VALUE  
  
RANGE  AVG  DIAGS  ALARM
```

Service Menu

The Service menu appears only when the instrument is in the service mode. To put the instrument into the service mode:

In the Main Menu, choose Instrument Controls > **Service Mode**.

Advanced diagnostic functions are included in the service mode. Meaningful data should not be collected when the instrument is in the service mode. In dual or auto range modes, “HI” or “LO” multi-point calibration is displayed to indicate the calibration of the high or low concentrations.

In the Main Menu, choose **Service**.

```
SERVICE:  
>FLASH VOLTAGE ADJUSTMENT  
  INITIAL FLASH REFERENCE  
  PMT SUPPLY SETTINGS  
  RANGE MODE SELECT  
  PRESSURE CALIBRATION  
  FLOW CALIBRATION  
  INPUT BOARD TEST  
  
RANGE  AVG  DIAGS  ALARM  
  
TEMPERATURE CALIBRATION  
ANALOG OUT CALIBRATION  
ANALOG INPUT CALIBRATION  
PERM OVEN SETTINGS  
EXTENDED RANGES  
DILUTION RATIO  
DISPLAY PIXEL TEST  
RESTORE USER DEFAULTS
```

Flash Voltage Adjustment

The Flash Voltage Adjustment screen allows the user to manually adjust the flasher supply voltage. The flash voltage adjustment screen is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in this chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

In the Main Menu, choose Service > **Flash Voltage Adjustment**.

```

SET FLASH VOLTAGE - MAN:
    SUPPLY:      800 V
    COUNTS:      1400

    ↑↓ INC/DEC
    ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
  
```

Initial Flash Reference

The Initial Flash Reference allows the user to view and set the initial flash reference. The initial flash reference screen is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in this chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

In the Main Menu, choose Service > **Initial Flash Reference**.

```

SET INITIAL FLASH REF:
    CURRENT REF:  3.50 V

    ← SAVE CURRENT REF VOLTS
      AS INITIAL

RANGE  AVG  DIAGS  ALARM
  
```

PMT Voltage Adjustment

The PMT Voltage Adjustment screen is used to manually adjust the PMT supply voltage. The PMT voltage adjustment is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in this chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

In the Main Menu, choose Service > **PMT Voltage Adjustment**.

```
SET PMT VOLTAGE:
SET PMT:        600.0 V
COUNTS:        2254

      ↑↓ INC/DEC
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Range Mode Select

The Range Mode Select screen is used to switch between the various range modes: single, dual, and autorange.

In the Main Menu, choose Service > **Range Mode Select**.

```
RANGE MODE SELECT:
CURRENTLY:        SINGLE
SET TO:           DUAL ?

      ↑↓ CHANGE VALUE
      ← SAVE VALUE

RANGE  AVG  DIAGS  ALARM
```

Pressure Calibration

The Pressure Calibration menu is used to calibrate the pressure sensor to zero, span, or restore factory default values. The pressure calibration is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in this chapter.

The pressure sensor’s zero counts and span slope are displayed on the menu.

Note This adjustment should only be performed by an instrument service technician. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > **Pressure Calibration**.


```

PRESSURE SENSOR CAL:
>ZERO                100
SPAN                1.2200
SET DEFAULTS

RANGE  AVG  DIAGS  ALARM

```

Calibrate Pressure Zero

The Calibrate Pressure Zero screen calibrates the pressure sensor at zero pressure.

Note A vacuum pump must be connected to the pressure sensor before performing the zero calibration. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > Pressure Calibration > **Zero**.

```

CALIBRATE PRESSURE ZERO:
CURRENTLY:      0.0 mmHg
SET TO:         0.0 mmHg ?

CONNECT VACUUM PUMP AND
← SAVE ZERO PRESSURE

RANGE  AVG  DIAGS  ALARM

```

Calibrate Pressure Span

The Calibrate Pressure Span screen allows the user to view and set the pressure sensor calibration span point.

Note The plumbing going to the pressure sensor should be disconnected so the sensor is reading ambient pressure before performing the span calibration. The operator should use an independent barometer to measure the ambient pressure and enter the value on this screen before calibrating. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > Pressure Calibration > **Span**.

```
CALIBRATE PRESSURE SPAN:
CURRENTLY: 756.0 mmHg
SET TO: 760.0 mmHg ?

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM
```

Restore Default Pressure Calibration

The Restore Default Pressure Calibration screen allows the user to reset the configuration values to factory defaults.

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > Pressure Calibration > **Set Defaults**.

```
RESTORE DEFAULT CAL:

                        ← RESTORE

RANGE  AVG  DIAGS  ALARM
```

```
RESTORE DEFAULT CAL:

                        ← RESTORE
ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM RESTORE

RANGE  AVG  DIAGS  ALARM
```

Flow Calibration

The Flow Calibration menu is used to calibrate the flow sensor to zero, span, or restore factory default values. The flow calibration is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > **Flow Calibration**.

```

FLOW SENSOR CAL:
>ZERO          200
SPAN          1.0000
SET DEFAULTS

RANGE  AVG  DIAGS  ALARM

```

Calibrate Flow Zero

The Calibrate Flow Zero screen calibrates the flow sensor at zero flow.

Note The pump must be disconnected before performing the zero calibration. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > Flow Calibration > **Zero**.

```

CALIBRATE FLOW ZERO:
CURRENTLY:    0.000 LPM
SET TO:       0.000 LPM ?

DISCONNECT PUMP AND
← SAVE ZERO PRESSURE

RANGE  AVG  DIAGS  ALARM

```

Calibrate Flow Span

The Calibrate Flow Span screen allows the user to view and set the flow sensor calibrate span point.

Note An independent flow sensor is required to read the flow, then the operator enters the flow value on this screen to perform the calibration. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > Flow Calibration > **Span**.

```

CALIBRATE FLOW SPAN:
CURRENTLY:      0.508 LPM
SET TO:         0.508 LPM ?

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS ALARM

```

Restore Default Flow Calibration

The Restore Default Flow Calibration screen allows the user to reset the configuration values to factory defaults.

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > Flow Calibration > **Set Defaults**.

```

RESTORE DEFAULT CAL:

                        ← RESTORE

RANGE  AVG  DIAGS ALARM

```

```

RESTORE DEFAULT CAL:

                        ← RESTORE
ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM RESTORE

RANGE  AVG  DIAGS ALARM

```

Input Board Test

The Input Board Test screen is used to manually adjust the input board gain. The input board test is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

In the Main Menu, choose Service > **Input Board Test**.

```

GAIN    1  - MANUAL:
FREQ =  :    0      ?

      ↔ CHG GAIN

RANGE  AVG  DIAGS ALARM

```


Temperature Calibration

The Temperature calibration screen allows the user to view and set the ambient temperature sensor calibration. The temperature calibration is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

Note Wait at least 30 seconds for the reading to stabilize before saving the value. ▲

In the Main Menu, choose Service > **Temperature Calibration**.



Analog Output Calibration

The Analog Output Calibration menu is a selection of analog output to calibrate, and allows the user to select the calibration action zero or span. The analog output calibration is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

Notes This adjustment should only be performed by an instrument service technician. ▲

Current channels are visible only if the I/O expansion board is installed. ▲

In the Main Menu, choose Service > Analog Output Calibration > **Voltage Channel 1-6** or **Current Channel 1-6**.

```

ANALOG OUTPUT CAL:
>VOLTAGE CHANNEL 1
VOLTAGE CHANNEL 2
VOLTAGE CHANNEL 3
VOLTAGE CHANNEL 4
VOLTAGE CHANNEL 5
VOLTAGE CHANNEL 6
CURRENT CHANNEL 1
↓
RANGE  AVG  DIAGS  ALARM

```

```

CURRENT CHANNEL 2
CURRENT CHANNEL 3
CURRENT CHANNEL 4
CURRENT CHANNEL 5
CURRENT CHANNEL 6

```

```

ANALOG OUTPUT CAL:
>CALIBRATE ZERO
CALIBRATE FULL SCALE

RANGE  AVG  DIAGS  ALARM

```

Analog Output Calibrate Zero

The Analog Output Calibrate Zero screen allows the user to calibrate the zero state of the selected analog output. The operator must connect a meter to the output and adjust the output until it reads 0.0 V on the meter.

In the Main Menu, choose Service > Analog Output Calibration > Selected Channel > **Calibrate Zero**.

```

ANALOG OUTPUT CAL:  ZERO
CONNECT METER TO OUTPUT!
SELECTED OUTPUT:  V1
SET TO:  200
← SAVE VALUE  ↑↓ INC/DEC
SET OUTPUT TO:  0.0 V

RANGE  AVG  DIAGS  ALARM

```

Analog Output Calibrate Full-Scale

The Analog Output Calibrate Full-Scale screen allows the user to calibrate the full-scale state of the selected analog output. The operator must connect a meter to the output and adjust output until it reads the value shown in the set output to: field.

In the Main Menu, choose Service > Analog Output Calibration > Selected Channel > **Calibrate Full Scale**.

```

ANALOG OUTPUT CAL:  SPAN
CONNECT METER TO OUTPUT!
SELECTED OUTPUT:  V1
SET TO:  3697
← SAVE VALUE  ↑↓ INC/DEC
SET OUTPUT TO:  10 V

RANGE  AVG  DIAGS  ALARM

```

Analog Input Calibration

The Analog Input Calibration menu is a selection of analog input to calibrate, and allows the user to select the calibration action zero or span. The analog input calibration is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

Note This screen is present only when the I/O expansion board is installed. ▲

Note This adjustment should only be performed by an instrument service technician. ▲

In the Main Menu, choose Service > Analog Input Calibration > **Input Channel 1-8**.

```

ANALOG INPUT CAL:
>INPUT CHANNEL 1
INPUT CHANNEL 2
INPUT CHANNEL 3
INPUT CHANNEL 4
INPUT CHANNEL 5
INPUT CHANNEL 6
INPUT CHANNEL 7
                                ↓
RANGE  AVG  DIAGS  ALARM

```

INPUT CHANNEL 8

```

ANALOG INPUT CAL:
>CALIBRATE ZERO
CALIBRATE FULL SCALE

RANGE  AVG  DIAGS  ALARM

```

Analog Input Calibration Zero

The Analog Input Calibrate Zero screen allows the user to calibrate the zero state of the selected analog input.

In the Main Menu, choose Service > Analog Input Calibration > Select Channel > **Calibrate Zero**. (Hook up a voltage source of 0 V to the analog input channel.)

```
ANALOG INPUT CAL:  ZERO
DISCONNECT SELECTED INPUT!
SELECTED INPUT:  INPUT 1
CURRENTLY:  0.00 V ?

← CALIBRATE INPUT TO ZERO

RANGE  AVG  DIAGS  ALARM
```

Analog Input Calibrate Full-Scale

The Analog Input Calibration Full-Scale screen allows the user to calibrate the full-scale state of the selected analog input.

In the Main Menu, choose Service > Analog Input Calibration > Select Channel > **Calibrate Full Scale**. (Hook up a voltage source of 10 V to the analog input channel.)

```
ANALOG INPUT CAL:  SPAN
PROVIDE VOLTAGE TO INPUT!
SELECTED INPUT:  INPUT 1
CURRENTLY:  9.80 V
SET TO:  10.00 V ?
← CALIBRATE TO VALUE

RANGE  AVG  DIAGS  ALARM
```

Permeation Oven Settings

The Permeation Oven Settings menu is used for setting up and calibrating the permeation oven option. The permeation oven settings menu is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

Note This adjustment should only be performed by an instrument service technician. ▲

In the Main Menu, choose Service > **Perm Oven Settings**.

```
PERM OVEN SETTINGS:
>CAL GAS THERMISTOR
CAL OVEN THERMISTOR
PERM OVEN SELECTION
FACTORY CAL GAS THERM
FACTORY CAL OVEN THERM

RANGE  AVG  DIAGS  ALARM
```


Calibrate Gas Thermistor

The Calibrate Gas Thermistor submenu is used for calibrating the permeation oven gas thermistor using a water bath or known resistance.

In the Main Menu, choose Service > Perm Oven Settings > Cal Gas Thermistor > **Water Bath** or **Known Resistor**.

```

CALIBRATE GAS THERMISTOR:
>WATER BATH
  KNOWN RESISTOR

RANGE  AVE  DIAGS  ALARM
  
```

Water Bath

The Calibrate Gas Thermistor Water Bath screen allows the user to view and set the permeation oven gas temperature to a known temperature value.

```

CAL GAS THERM (BATH):
CURRENTLY:      45.80 °C
SET TO:         45.00 °C

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM
  
```

Resistor

The Calibrate Gas Thermistor Resistance screen allows the user to view and set the permeation oven gas thermistor resistance to a known resistor value.

```

CAL GAS THERM (RESISTOR):
CURRENTLY:      4367 Ohms
SET TO :        0400 Ohms

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM
  
```

Calibrate Oven Thermistor

The Calibrate Oven Thermistor menu is used to view and set the permeation oven thermistor resistance to a known resistor value.

In the Main Menu, choose Service > Perm Oven Settings > **Cal Oven Thermistor**.

```
CAL OVEN THERM (RESISTOR):  
CURRENTLY:      4367 Ohms  
SET TO :        04000 Ohms  
  
      ↔ MOVE CURSOR  
↑↓ CHANGE VALUE  ← SAVE  
  
RANGE  AVG  DIAGS  ALARM
```

Permeation Oven Setpoint

The Permeation Oven Setpoint screen is used to select the permeation oven state to not present, or the desired temperature choice of 30, 35, and 45 °C.

In the Main Menu, choose Service > Perm Oven Settings > **Perm Oven Selection**.

```
PERM OVEN SETPOINT:  
CURRENTLY:  NOT PRESENT  
SET TO:      45 °C ?  
  
      ↑↓ CHANGE VALUE  
      ← SAVE VALUE  
  
RANGE  AVG  DIAGS  ALARM
```

Factory Calibrate Gas Thermistor

The Factory Calibrate Gas Thermistor submenu is used for calibrating the permeation oven gas thermistor to either low point, high point, or set defaults.

In the Main Menu, choose Service > Perm Oven Settings > **Factory Cal Gas Therm**.

```

FACTORY CAL OVEN THERM:
>LOW POINT
HIGH POINT
SET DEFAULTS

RANGE  AVE  DIAGS  ALARM

```

Low and High Points

The Calibrate Gas Thermistor Low Point screen allows the user to view and set the permeation oven thermistor resistance. The low and high point screens function the same way.

In the Main Menu, choose Service > Perm Oven Settings > Factory Cal Gas Therm > **Low Point**.

```

CAL GAS THERM LOW POINT:
CURRENTLY: 4367 Ohms
SET TO: 0400 Ohms

↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM

```

Set Defaults

The Set Defaults screen allows the user to reset the configuration values to factory defaults.

In the Main Menu, choose Service > Perm Oven Settings > Factory Cal Gas Therm > **Set Defaults**.

```

RESTORE DEFAULT SETTINGS:
FOR PERM OVEN GAS THERM
← RESTORE

ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM RESTORE

RANGE  AVG  DIAGS  ALARM

```

Factory Calibrate Oven Thermistor

The Factory Calibrate Oven Thermistor submenu is used for calibrating the permeation oven heater thermistor to either low point, high point, or set defaults.

In the Main Menu, choose Service > Perm Oven Settings > **Factory Cal Oven Therm**.

```
FACTORY CAL OVEN THERM:
>LOW POINT
HIGH POINT
SET DEFAULTS

RANGE  AVE  DIAGS ALARM
```

Low and High Points

The Calibrate Oven Thermistor Low Point screen allows the user to view and set the permeation oven thermistor resistance. The low and high point screens function the same way.

In the Main Menu, choose Service > Perm Oven Settings > Factory Cal Oven Therm > **Low Point**.

```
CAL OVEN THERM LOW POINT:
CURRENTLY:      4367 Ohms
SET TO:         04000 Ohms

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS ALARM
```

Set Defaults

The Set Defaults screen allows the user to reset the configuration values to factory defaults.

In the Main Menu, choose Service > Perm Oven Settings > Factory Cal Oven Therm > **Set Defaults**.

```
RESTORE DEFAULT SETTINGS:
FOR PERM OVEN HTR THERM
      ← RESTORE

ARE YOU SURE YOU WANT TO?
PRESS → TO CONFIRM RESTORE

RANGE  AVG  DIAGS ALARM
```

Extended Ranges

The Extended Ranges screen is used to turn the extended ranges feature ON and OFF. The extended ranges is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” described previously in this chapter.

```

EXTENDED RANGES:
CURRENTLY:      OFF
SET TO:         ON

      ← TOGGLE VALUE

RANGE  AVG  DIAGS  ALARM

```

Dilution Ratio

The Dilution Ratio screen allows the user to view and set the dilution ratio. Acceptable values are 1–500: 1. The default is 1:1. When this value is set, the dilution ratio is applied to all concentration measurements. This screen is only accessible if the dilution ratio option is installed.

In the Main Menu, choose Service > **Dilution Ratio**.

```

DILUTION RATIO:
CURRENTLY:      001.0 :1
SET TO:         000.0 :1 ?

      ↔ MOVE CURSOR
      ↑↓ CHANGE VALUE  ← SAVE

```

Display Pixel Test

The Display Pixel Test is used to test the LCD display. The display pixel test screen is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

In the Main Menu, choose Service > **Display Pixel Test**.

```

DISPLAY PIXEL TEST:
DURING TEST PRESS 0 OR ▶
TO EXIT, ← TO TOGGLE

      ← BEGIN TEST
      0 GO BACK TO MENU


RANGE  AVG  DIAGS  ALARM

```

Restore User Defaults


The Restore User Defaults screen is used to reset the user calibration and configuration values to factory defaults. The restore default user is visible only when the instrument is in service mode. For more information on the service mode, see “Service Mode” earlier in the chapter.

In the Main Menu, choose Service > **Restore User Defaults**.



Password The Password menu allows the user to configure password protection. If the instrument is locked, none of the settings may be changed via the front panel user interface. The items visible under the password menu are determined by the instrument's password status.

In the Main Menu, choose **Set Password**.



Set Password The Set Password screen is used to set the password to unlock the front panel. The set password is shown if the instrument is unlocked and the password is set.

In the Main Menu, choose Password > **Password**.



Lock Instrument

The Lock Instrument screen is used to lock the instrument's front panel so users can not change any settings from the front panel. The lock instrument screen is shown if the instrument is unlocked and the password is set.

If the instrument keyboard is locked via the front panel using Password > **Lock Instrument**, the instrument reports being in Remote mode. In this mode, the keypad is locked, data can be viewed but not changed using the front panel interface, and the remote "Set" commands are active.

If the instrument keyboard is unlocked via the front panel using Password > **Unlock Instrument**, the instrument reports being in Local mode, the front panel interface is unlocked, and data can be changed from the front panel.

Refer to the "C-Link Protocol Commands" appendix for detailed information about "mode", "allow mode", and "power up mode" commands.

In the Main Menu, choose Password > **Lock Instrument**.

```

LOCK FRONT PANEL:
PRESSING ENTER WILL
PREVENT USER FROM CHANGING
CONFIG FROM FRONT PANEL
← LOCK AND RETURN TO RUN

RANGE  AVG  DIAGS  ALARM
  
```

Change Password

The Change Password is used to set or change the password used to unlock the instrument's front panel. The change password screen is shown if the instrument is unlocked.

In the Main Menu, choose Password > **Change Password**.

```

ENTER NEW PASSWORD:
          █
ABCDEF GHIJ KLMN  BKSP
OPQRST UVWXYZ    PAGE
012345 6789  . / -  SAVE

RANGE  AVG  DIAGS  ALARM
  
```

Remove Password

The Remove Password screen is used to erase the current password and disable password protection. The remove password screen is shown if the instrument is unlocked and the password set.

In the Main Menu, choose Password > **Remove Password**.



```
REMOVE PASSWORD:
PRESSING ENTER WILL
REMOVE CURRENT PASSWORD
AND DISABLE LOCKING
← REMOVE PASSWORD

RANGE  AVG  DIAGS  ALARM
```

Unlock Instrument

The Unlock Instrument screen is used to enter the password to unlock the front panel. The unlock instrument is shown if the instrument is locked.

In the Main Menu, choose Password > **Unlock Instrument**



```
ENTER THE PASSWORD:
█

ABCDEFGHIJKLMN  BKSP
UPQRSTUVWXYZ   PAGE
0123456789 . / -  SAVE

RANGE  AVG  DIAGS  ALARM
```


Chapter 4

Calibration

The Model 43i requires initial and periodic calibration according to the procedures described in this chapter. A quality control plan that allows the frequency and number of calibration points to be modified depending on calibration and zero/span check data should be implemented. Such a quality control program is essential to ascertain the accuracy and reliability of the air quality data collected. The data compiled for such a program might include items such as dates of calibration, atmospheric conditions, control settings and other pertinent data. For more detailed quality assurance guidelines, see the *Quality Assurance Handbook for Air Pollution Measurement Systems*, published by the U.S. EPA, Research Triangle Park, NC, 27711.

There are a number of conditions which should be met prior to a calibration or a zero/span check. First, the instrument should have at least 30 minutes to warm up and stabilize. Second, the range used during the calibration or zero/span check should be the same as that used during normal monitoring. Third, all operational adjustments to the instrument should be completed prior to calibration. Fourth, all parts of the gas flow system, such as sample lines, and particulate filters, which are used in normal monitoring should also be used during calibration. Finally, it is recommended that the recording devices and outputs used during normal monitoring be calibrated prior to the instrument calibration and that they be used during the calibration or the zero/span check.

Zero Gas Generation

An SO₂-free (< 0.0005 ppm) air supply is required for the proper calibration and checkout of the instrument. There are several methods that are acceptable to generate this zero gas.

Commercial Heatless Air Dryers

Commercial heatless air dryers filled with a mixed bed of activated charcoal and a 13X molecular sieve have been found effective in removing SO₂ from compressed air. The use of this type of zero gas system is recommended when minimum maintenance is of prime importance. This system requires a source of compressed air. Refer to the manufacturer's recommendations for installation of such a system.

Absorbing Column

An absorbing column packed with activated charcoal is acceptable for scrubbing SO₂ from ambient air. Ambient air is forced through a laboratory gas absorption column packed with the charcoal and the SO₂ is removed to acceptable levels (<0.0005 ppm). The charcoal should be changed at a minimum of every six months. It may be necessary to change the charcoal more frequently depending on local conditions.

Calibration Gas Generation

A calibration gas system capable of providing accurate levels of SO₂ calibration gas between zero and 80% of the full-scale range is required. The calibration system must provide a flow rate of at least 0.5 LPM for an instrument with the standard flow (instruments with higher flow rates will require a higher minimum calibration system flow rate). All calibration gas should be derived from local or working standards (such as cylinders of compressed gas or permeation devices) that are certified as traceable to an NIST primary standard.

Cylinder Gas Dilution

A cylinder gas dilution system, shown in **Figure 4–1**, can be constructed. All connections between components in the system should be made with glass, Teflon, or other non-reactive material.

The air flow controller should be capable of maintaining a constant air flow within $\pm 2\%$ of the required flow rate. The SO₂ flow controller should be capable of maintaining constant SO₂ flows within $\pm 2\%$ of the required flow rate. Ensure both flow controllers are properly calibrated. The pressure regulator for the standard SO₂ cylinder must have a non-reactive diaphragm and internal parts and a suitable delivery pressure.




Figure 4–1. Cylinder Gas Dilution System

The exact SO₂ concentration is calculated from:

$$[SO_2]_{OUT} = \frac{[SO_2]_{STD} \times F_{SO_2}}{F_D + F_{SO_2}}$$

Where:

[SO₂]_{OUT} = diluted SO₂ concentration at the output manifold, ppm

[SO₂]_{STD} = concentration of the undiluted SO₂ standard, ppm

F_{SO₂} = flow rate of the SO₂ standard corrected to 25 °C and 760 mm Hg

F_D = flow rate of the dilution air corrected to 25 °C and 760 mm Hg

Commercial Precision Dilution Systems

Commercial precision dilution systems are available which reliably and accurately dilute a high concentration gas mixture to provide a reliable span gas. A high concentration (50 ppm) of SO₂ in air is precisely diluted to the concentration range required.

The Thermo Scientific *Model 146 Multigas Calibration System* is one such system for precision dilution.

Permeation Tube System

Permeation tube systems which precisely maintain a set temperature to within ±0.1 °C and hold a zero air flow rate to within ±0.5% can be used for generation of span gas. The flow rate of the permeation system must be at least 0.5 LPM for proper operation.

A permeation tube system, shown in **Figure 4–2** can be constructed. All connections between components in the system should be made with glass, Teflon, or other non-reactive material.

The air flow controllers should be capable of maintaining a constant air flow within $\pm 2\%$ of the required flow rate. Ensure all devices are properly calibrated and that all flows are corrected to 25 °C and 1 atm.




Figure 4–2. Permeation Tube System

The SO₂ output level is calculated from:

$$[SO_2]_{OUT} = \frac{P \times K}{F_T}$$

Where:

[SO₂]_{OUT} = SO₂ output concentration in ppm

P = permeation rate in µg/min

F_T = total flow rate of gas after mixing chamber (F_P + F_D) in liters/minute

K (SO₂) = 0.382 constant for SO₂ permeant

Commercial Permeation Systems

Commercial permeation systems, such as the Thermo Scientific Model 146 Multigas Calibration System, are available for this requirement. Refer to the instrument instruction manual for more information.

Multi-Point Calibration

Regulations typically require zero/span calibration when the instrument is newly installed, moved, repaired, interrupted for more than a few days, or when span or zero shift by more than 15%.

All gas must be supplied to the instrument at atmospheric pressure. It may be necessary to employ an atmospheric bypass plumbing arrangement to accomplish this. Refer to **Figure 2-4** in the “Installation” chapter for an example of an atmospheric bypass plumbing arrangement.

If a filter is used, all gas must enter the instrument through the filter.

For detailed information about the menu parameters and the icons used in these procedures, see the “Operation” chapter.

Note The calibration and calibration check duration times should be long enough to account for the transition (purge) process when switching from sample to zero and from zero to span. This transition time is the time required to purge the existing air. ▲

Depending on the plumbing configuration and the instrument, data from approximately the first minute of a zero calibration or check should be disregarded because of residual sample air. Also, data from approximately the first minute of a span calibration or check should be disregarded because the span is mixing with the residual zero air. ▲

Use the following procedure to perform a zero/span calibration.

1. If the instrument is equipped with the optional zero/span and sample valves, connect the zero and span gas to the rear panel bulkheads labeled ZERO and SPAN, otherwise connect a source of vented zero air to the SAMPLE bulkhead.




Note Do not use nitrogen for zero air. ▲






is used to activate the zero and span valves. The lower left-hand corner of the Run screen indicates which mode is active: ZERO, SPAN, or SAMPLE.






2. To ensure that the zero air is being measured at atmospheric pressure, check that the zero air flow reported by the analyzer is approximately

0.5 LPM. Actual zero air flow should be 0.8 LPM or more, with the excess flowing out the atmospheric bypass.


- a. From the Run screen, press  to display the Main Menu.
 - b. From the Main Menu, choose Diagnostics > **Flow** to display the Sample Flow screen.
 - c. Make sure that the reported sample flow is less than the actual zero air flow.
3. Monitor the zero air reading and wait for the reading to stabilize.
 4. From the Main Menu, choose **Calibration** to display the Calibration menu.
 5. At the Calibration menu, press  to display the SO₂ Background screen, after 10 minutes of zero air and when the reading is stable, press  to set the SO₂ reading to zero.

The display flashes the message “SAVING”, and the SO₂ reading is added to the background correction. Record the stable zero air reading as Z_{SO₂}.
 6. Press  to return to the Calibration menu.
 7. Connect a source of calibration gas to the SAMPLE bulkhead. The calibration gas concentration should be approximately 80% of the full-scale range.
 8. To ensure that the calibration gas is being measured at atmospheric pressure, check that the sample flow in the analyzer is approximately 0.5 LPM. Actual sample air flow should be 0.8 LPM or more, with the excess flowing out the atmospheric bypass.
 9. Sample the vented calibration gas and wait for the instrument reading to stabilize.
 10. Press  to move the cursor to Cal SO₂ Coefficient, and press  to display the Calibrate SO₂ screen.

The first line of the display shows the current SO₂ reading. The SPAN CONC line of the display is where you enter the calibration gas concentration.

11. To enter the calibration gas concentration, use   to move the cursor left and right. Use   to increment and decrement the digit. Press  to calibrate the instrument to the SO₂ calibration gas.

The display flashes the message “SAVING”, and the corrected SO₂ reading is displayed.

12. Press the  pushbutton to return to the Run screen. If using a chart recorder hooked up to an analog output channel, the SO₂ recorder response will equal:

$$\frac{[\text{SO}_2]_{\text{OUT}}}{\text{URL}} \times 100 = Z_{\text{SO}_2}$$

Where:

URL = upper range limit of the analyzer's operating range

Z_{SO₂} = analyzer response to zero air, % fullscale

Note The minimum and maximum analog output configuration values should be set to the default settings (minimum 0%; maximum 100%). ▲

13. For multi-point calibration, generate five SO₂ concentrations equally spaced between zero and the concentration above. Record instrument reading for each concentration after allowing time for both gas generation system and instrument to stabilize. Plot a graph of instrument readings against the SO₂ concentrations generated. This is the instrument calibration curve. All future measurements should be interpreted using this curve.

Multipoint Calibration in Dual/Auto Range Mode

Regulations typically require multipoint calibration when the instrument is newly installed, moved, repaired, interrupted for more than a few days, or when span or zero shift by more than 15%.

All gas must be supplied to the instrument at atmospheric pressure. It may be necessary to employ an atmospheric bypass plumbing arrangement to accomplish this.

If a filter is used, all gas must enter the instrument through the filter.

For detailed information about the menu parameters and the icons used in these procedures, see the “Operation” chapter.

Calibration


Multipoint Calibration in Dual/Auto Range Mode





Note The calibration and calibration check duration times should be long enough to account for the transition (purge) process when switching from sample to zero and from zero to span. This transition time is the time required to purge the existing air. ▲




Use the following procedure to perform a multipoint calibration in dual/autorange mode.

1. If the instrument is equipped with the optional zero/span and sample valves, connect the zero and span gas to the rear panel bulkheads labeled ZERO and SPAN, otherwise connect a source of vented zero air to the SAMPLE bulkhead.






Note Do not use nitrogen for zero air. ▲

 is used to activate the zero and span valves from the run screen. The lower left-hand corner of the Run screen indicates which mode is active ZERO, SPAN, or SAMPLE.


2. To ensure that the zero air is being measured at atmospheric pressure, check that the zero air flow reported by the analyzer is approximately 0.5 LPM. Actual zero air flow should be 0.8 LPM or more, with the excess leaving out the atmospheric bypass.
 - a. From the Run screen, press  to display the Main Menu.
 - b. From the Main Menu choose, Diagnostics > **Flow** to display the Sample Flow screen.
 - c. Make sure that the reported sample flow is less than the actual zero air flow.
3. Press  to monitor the zero air reading and wait for the reading to stabilize.
4. Press  and choose Calibration > **SO₂ Background** to display the SO₂ Background screen.
5. When the reading stabilizes, press  to set the SO₂ reading to zero. The display flashes the message “SAVING”, and the SO₂ reading is added to the background correction. Record the stable zero air reading as Z_{SO₂}.

6. Press  to return to the Calibration menu.
7. Connect a source of calibration gas to the SAMPLE bulkhead. The calibration gas should be approximately 80% of the high full-scale range.
8. To ensure that the calibration gas is being measured at atmospheric pressure, check that the flow reported by the analyzer is approximately 0.5 LPM. Actual sample flow should be 0.8 LPM or more, with the excess flowing out the atmospheric bypass.
9. Sample the calibration gas and wait for the instrument reading to stabilize.
10. Use  to move the cursor to **Calibrate HI SO₂**, and press  to display the Calibrate HI SO₂ screen.

The first line of the display shows the current SO₂ reading. The second line of the display is where you enter the high calibration gas concentration.

11. To enter the high calibration gas concentration, use   to move the cursor left and right. Use   to increment and decrement the digit. Press  to calibrate the instrument to the high SO₂ calibration gas.

The display flashes the message “SAVING”, and the corrected SO₂ reading is displayed.

12. Press  to return to the Calibration menu. If using a chart recorder, the SO₂ recorder response will equal:



$$\frac{[SO_2]_{OUT}}{URL} \times 100 + Z_{SO_2}$$






Where:


URL = upper range limit of the instrument's operating range

Z_{SO₂} = instrument response to zero air, % full scale

13. Generate five SO₂ concentrations equally spaced between zero and the concentration above.

14. Record instrument reading for each concentration after allowing time for both gas generation system and instrument to stabilize.
15. Plot a graph of instrument readings against the SO₂ concentrations generated for the high range.
16. Connect a source of calibration gas to the SAMPLE bulkhead. The calibration gas should be approximately 80% of the low full-scale range.
17. Use  to move the cursor to Calibrate LO SO₂, and press  to display the Calibrate LO SO₂ screen.

The first line of the display shows the current SO₂ reading. The second line of the display is where you enter the low calibration gas concentration.
18. To enter the low calibration gas concentration, use   to move the cursor left and right. Use   to increment and decrement the digit. Press  to calibrate the instrument to the low SO₂ calibration gas.

The display flashes the message "SAVING", and the corrected SO₂ reading is displayed.
19. Press  to return to the Calibration menu.
20. Generate five SO₂ concentrations equally spaced between zero and the concentration above.
21. Record instrument reading for each concentration after allowing time for both gas generation system and instrument to stabilize.
22. Plot a graph of instrument readings against the SO₂ concentrations generated for the low range.

This is the instrument calibration curve. All future measurements should be interpreted using this curve.

Zero/Span Check

The zero/span check procedure is normally performed any time a quick check of the accuracy of the instrument is required. Normally, zero and span are checked daily. As experience is gained with the instrument, the frequency of these checks can be adjusted accordingly.

The span gas concentration used in the span check should be between 70% and 90% of the full-scale range. The zero and span drift should be measured and recorded prior to making any adjustments.

All gas must be supplied to the instrument at atmospheric pressure. It will be necessary to employ an atmospheric bypass plumbing arrangement to accomplish this.


If a filter is used, all gas must enter the instrument through the filter.




For detailed information about the menu parameters and the icons used in these procedures, see the “Operation” chapter.

Use the following procedure to check the zero/span.

1. If the instrument is equipped with the optional zero/span and sample valves, connect the zero and span gas to the rear panel bulkheads labeled ZERO and SPAN, otherwise connect a source of vented zero air to the SAMPLE bulkhead.


Note Do not use nitrogen for zero air. ▲

 is used to activate the zero and span valves. The lower left-hand corner of the Run screen indicates which mode is active: ZERO, SPAN, or SAMPLE.

2. To ensure that the zero air is being measured at atmospheric pressure check that the flow reported by the analyzer is approximately 0.5 LPM. Actual zero air flow should be 0.8 LPM or more, with the excess flowing out the atmospheric bypass.
 - a. From the Run screen, press  to display the Main Menu.
 - b. From the Main Menu, select Diagnostics >  > **Flow** to display the Sample Flow screen.
 - c. Make sure that the reported sample flow is less than the actual zero air flow.
3. Press  to monitor the zero air reading and wait for the reading to stabilize.
4. Record the measured SO₂ value as the zero drift since the last adjustment. If the zero has changed by more than ± 0.015 ppm, it is recommended that a new calibration be performed.

Calibration

Zero/Span Check

5. Connect a source of vented span gas to the SAMPLE bulkhead. The span gas should be approximately 80% of the full-scale range.
6. To ensure that the span gas is being measured at atmospheric pressure check that the flow is approximately 0.5 LPM or more, with the excess flowing out the atmospheric bypass.
7. Press  to monitor the span gas reading and wait for the reading to stabilize.
8. Record the difference between the measured SO₂ value and the actual SO₂ span concentration used. This is the span drift since the last adjustment. If the calibration has changed by more than $\pm 10\%$, a new calibration should be performed.

Chapter 5

Preventive Maintenance

This chapter describes the periodic maintenance procedures that should be performed on the instrument to ensure proper operation. Since usage and environmental conditions vary greatly, you should inspect the components frequently until an appropriate maintenance schedule is determined.

This chapter includes the following maintenance information and replacement procedures:

- “Safety Precautions” on page 5-1
- “Replacement Parts” on page 5-2
- “Cleaning the Outside Case” on page 5-2
- “Visual Inspection and Cleaning” on page 5-2
- “Cleaning the Mirrors” on page 5-2
- “Fan Filter Inspection and Cleaning on page 5-5
- “Sample Particulate Filter Inspection” on page 5-5
- “Lamp Voltage Check” on page 5-6
- “Leak Test” on page on page 5-6
- “Pump Rebuilding” on page 5-7

Safety Precautions



Read the safety precautions before beginning any procedures in this chapter.

WARNING If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲



Equipment Damage Do not attempt to lift the instrument by the cover or other external fittings. ▲



Equipment Damage Do not use solvents or other cleaning products to clean the outside case. ▲



Equipment Damage DO NOT attempt to clean the mirrors in the optical bench. These mirrors do not come in contact with the sample gas and should not be cleaned. Cleaning the mirrors can damage the mirrors. ▲

Replacement Parts

See the “Servicing” chapter for a list of replacement parts.

Cleaning the Outside Case

Clean the outside case using a damp cloth being careful not to damage the labels on the case.



Equipment Damage Do not use solvents or other cleaning products to clean the outside case. ▲

Visual Inspection and Cleaning

The instrument should be inspected occasionally for obvious visible defects, such as loose connectors, loose fittings, cracked or clogged Teflon lines, and excessive dust or dirt accumulation. Dust and dirt can accumulate in the instrument and can cause overheating or component failure. Dirt on the components prevents efficient heat dissipation and may provide conducting paths for electricity. The best way to clean the inside of the instrument is to first carefully vacuum all accessible areas and then blow away the remaining dust with low pressure compressed air. Use a soft paint brush or cloth to remove stubborn dirt.

Cleaning the Mirrors

The mirrors located in the optical bench do not come in contact with the sample gas and DO NOT need cleaning. Read the Equipment Damage warning that follows.



Equipment Damage DO NOT attempt to clean the mirrors in the optical bench. These mirrors do not come in contact with the sample gas and should not be cleaned. Cleaning the mirrors can damage the mirrors. ▲

Capillary Inspection and Replacement

The capillary normally only requires inspection when instrument performance indicates that there may be a flow problem. A decreased sample flow may be an indication that a capillary is blocked.



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

Use the following procedure to inspect and replace the capillary.

1. Turn the instrument OFF and unplug the power cord.
2. Remove the instrument cover.
3. Locate the capillary holder (**Figure 5–1**) and unscrew the knurled capillary nut.

Note The capillary used with the optional heated kicker is located adjacent to the flow transducer. ▲

4. Remove the glass capillary (1.5-inch long x 0.250-inch OD x 0.013-inch ID) and O-ring (**Figure 5–2**). Refer to “Replacement Parts” in the “Servicing” chapter.
5. Check capillary for particulate deposits. Clean or replace as necessary.
6. Inspect O-ring for cuts or abrasion, and replace as necessary.
7. Replace capillary in the holder, making sure the O-ring is around the capillary before inserting it into the body.
8. Finger-tighten the capillary nut enough to ensure a tight seal.

9. Re-install the cover.

10. Connect the power cord and turn the instrument ON.




Figure 5-1. Inspecting and Replacing the Capillary




Figure 5-2. Capillary Assembly

Fan Filter Inspection and Cleaning

Under normal use, the filter over the instrument fan located on the rear panel of the instrument should be cleaned and reconditioned at six-month intervals. If the instrument is operated in excessively dirty surroundings, this procedure should be instituted on a more frequent schedule. Use the following procedure to inspect and clean the fan filter (**Figure 5-3**).



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn the instrument OFF and unplug the power cord.
2. Remove the fan guard from the fan.
3. Flush the filter with warm water and let dry (a clean, oil-free purge will help the drying process) or blow the filters clean with compressed air.
4. Re-install the filter and fan guard.




Figure 5-3. Inspecting and Cleaning the Fan



Sample Particulate Filter Inspection

If a sample pre-filter is used, it should be inspected regularly for excessive dust and particulates which will restrict flow. Replace the sample filter as necessary.

Lamp Voltage Check

The instrument is equipped with a lamp voltage control circuit, which automatically corrects for degradation of the flash lamp. However, after several years of use, the lamp may have degraded to the point that is being driven with the maximum voltage that the power supply can deliver.









Use the following procedure to check the lamp voltage.

1. Press  to display the Main Menu.
2. From the Main Menu, select Diagnostics > Voltages > **Interface Board** and press  to display the Interface Board Voltages screen
3. Check the flash supply voltage. If this voltage is at 1200 V, it is necessary to either replace the lamp or adjust the lamp voltage control circuit.

For detailed information about this screen, refer to the “Operation” chapter. For more information about replacing the lamp or adjusting the lamp voltage control circuit, see the “Servicing” chapter.

Leak Test

A normal flow rate is approximately 0.5 LPM. If the flow rate is less than 0.35 LPM, use the following procedure to perform a leak test.

1. Block the SAMPLE bulkhead on the rear panel with a leak-tight cap.
2. Wait two minutes.
3. Press  to display the Main Menu.
4. Press  to move the cursor to Diagnostics and press  to display the Diagnostics menu.
5. Press  to move the cursor to Flow and press  to display the Sample Flow screen. The flow reading should indicate zero flow.
6. Press  to display the Diagnostics Menu, then press  to move the cursor to Pressure and press  to display the Pressure screen. The pressure reading should be less than 180 mm Hg. If not, check to see that all fittings are tight and that none of the input lines are cracked or broken. For detailed information about these screens, refer to the “Operation” chapter.

7. If the instrument passes the leak test, but still has low flow, check the capillary for blockage.
8. If the flow drops to zero during the flow check, but the pressure is above 250 mm Hg, the pump may need to be rebuilt.

Pump Rebuilding

Use the following procedure to rebuild the pump (**Figure 5-4**). To replace the pump, see “Pump Replacement” in the “Servicing” chapter.

Equipment Required:

Flatblade screwdriver

Pump rebuild kit (flapper valve and diaphragm)



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Loosen the fittings and remove both lines going to the pump.
3. Remove the four screws from the top plate, remove top plate, flapper valve, and the bottom plate (**Figure 5-4**).
4. Remove the screw securing the diaphragm to piston and remove diaphragm.
5. Assemble the pump by following the previous steps in reverse, make sure the Teflon (white) side of the diaphragm is facing up and that the flapper valves cover the holes of the top and bottom plate.




Figure 5–4. Rebuilding the Pump

6. Check that the flow reads approximately 0.5 LPM when power is turned ON.
7. Perform a leak test as described in this chapter.

Chapter 6

Troubleshooting

This instrument has been designed to achieve a high level of reliability. In the rare event of problems or failure, the troubleshooting guidelines, board-level connection diagrams, connector pin descriptions, and testing procedures presented in this chapter should be helpful in isolating and identifying problems.

For additional fault location information refer to the “Preventive Maintenance” chapter in this manual.

The service mode, described in the “Operation” chapter, includes parameters and functions that are useful when making adjustments or diagnosing problems.

The Technical Support Department at Thermo Fisher Scientific can also be consulted in the event of problems. See “Service Locations” at the end of this chapter for contact information. In any correspondence with the factory, please note both the serial number and program number of the instrument.

This chapter provides the following troubleshooting information:

- Safety Precautions on page 6-1
- Troubleshooting Guides on page 6-1
- Board-Level Connection Diagrams on page 6-10
- Connector Pin Descriptions on page 6-12
- Service Locations on page 6-24

Safety Precautions

Read the safety precautions in the Preface and the “Servicing” chapter before performing any actions listed in this chapter.

Troubleshooting Guides

The troubleshooting guides presented in this chapter are designed to help isolate and identify instrument problems.

Table 6–1. Troubleshooting - Power-Up Failures, **Table 6–2.** Troubleshooting - Calibration Failures, and **Table 6–3.** Troubleshooting - Measurement Failures provide general troubleshooting information and

indicate the checks that you should perform if you experience an instrument problem.

Table 6–4. Troubleshooting - Alarm Messages lists all the alarm messages you may see on the display and provides recommendations about how to resolve the alarm condition.

Table 6–1. Troubleshooting - Power-Up Failures

Malfunction	Possible Cause	Action
Does not start (The backlight on the display does not come on and the pump motor is not running.)	No power or wrong power configuration	Check the line to confirm that power is available and that it matches the voltage and frequency configuration of the instrument.
	Main fuse is blown or missing	Unplug the power cord, open the fuse drawer on the back panel, and check the fuses visually or with a multimeter.
	Bad switch or wiring connection	Unplug the power cord, disconnect the switch and check operation with a multimeter.
Display does not come on. (Pump is running.)	DC power supply failure	Check the green LED on the back edge of the power supply. If the LED is off, the supply has failed.
	DC power distribution failure	Check surface mount LEDs labelled “24V PWR” on the motherboard and the interface board. If lit, power is OK.
	Display failure	If possible, check instrument function through RS-232 or Ethernet. Contact Thermo Fisher Scientific Service Department.
Power comes on and the display functions, but the pump is not running.	AC power is not reaching the pump.	Locate the three-pin connector on the interface board and use a voltmeter to check AC voltage across the two black wires (should read 110 - 120V, even on 220V or 100V instruments).
	Pump is jammed due to a new or stiff diaphragm.	Carefully rotate the pump fan to get past sticking point.
	Pump bearings have failed.	Disconnect AC power and remove the gas lines from the pump head, then try to rotate the pump fan. If it is jammed, or noisy, the motor bearings may have failed.

Table 6–2. Troubleshooting - Calibration Failures

Malfunction	Possible Cause	Action
Cannot zero instrument or there is a high background signal when sampling zero air. (Zero air should produce a reading equivalent to less than 0.015 ppm SO ₂ .)	Zero air system is faulty, needs new SO ₂ scrubbers or requires maintenance.	Test against an ultra-zero cylinder from a reputable scientific gas supplier or check effect of a new chromatography grade activated charcoal scrubber installed at the instrument inlet.
	Zero air flow rate is inadequate.	Check by-pass or atmospheric pressure vent to verify that the zero air system is providing more flow than the instrument is drawing.
	Instrument is not drawing in span gas.	Check sample Flow and Pressure readings on the Diagnostics screen.
		Use an independent flow meter to check flows at the sample inlet and exhaust bulkheads (they should match).
		Perform a leak test, as described in the “Preventive Maintenance” chapter.
		Verify that span gases connected to the calibration system are shut off and leak-tight.
	Span gas containing SO ₂ , NO, or a hydrocarbon is contaminating system.	
	Internal or external lines, filters, and other sample handling equipment are contaminated or dirty.	Replace inlet filter (if installed) and as much of the tubing as possible.
	Hydrocarbon kicker has failed.	Replace the hydrocarbon kicker.
	High scattered light	Go to Instrument Controls, select Flash Lamp and toggle to OFF. If the previously high signal drops to zero or less when the flash lamp is off, the problem may be caused by scattered light from dust in the optical bench. If so, carefully clean the optical bench.
	Input board failure	Disconnect the input board from the interface board by unplugging ribbon cable labelled “INPUT.” The instrument reading should drop to zero or to a negative value.
Instrument appears to zero, but there is weak or	Span cylinder empty	Check the source pressure.

Malfunction	Possible Cause	Action
no response to span gas.	Calibration system failure	Check solenoids or other hardware to be sure that span gas is being delivered.
	Flow rate of the diluted span mix is inadequate.	Check by-pass or atmospheric vent to verify that the zero air system is providing more flow than the instrument draws.
	Instrument is not drawing in span gas.	Check sample Flow and Pressure readings on the Diagnostics screen. Use an independent flow meter to check flows at the sample inlet and exhaust bulkheads (they should match). Perform a leak test, as described in the "Preventive Maintenance" chapter.
	SO ₂ is being absorbed by tubing, filters, or dirt in the calibration system.	Replace any lines made of vinyl or other plastics with fresh Teflon or stainless steel. Replace Teflon filter membranes that look dirty. Remove any filters that are not Teflon membranes.
	Flash lamp has failed.	Listen for the rapid clicking of the flash lamp. Check the flash lamp voltage and intensity.
	PMT or input board has failed.	Check the PMT voltage and run the optical span test. A good optical span test indicates that the PMT is OK and that the problem is more likely the flash lamp.
Zero or Span will not stabilize.	Flow rate of the diluted span mix is inadequate.	Check by-pass or atmospheric pressure vent to verify that the zero air system is providing more flow than the instrument is drawing.
	Instrument is not drawing in span gas.	Check sample Flow and Pressure readings on the Diagnostics screen. Use an independent flow meter to check flows at the sample inlet and exhaust bulkheads (they should match). Perform a leak test, as described in the "Preventive Maintenance" chapter.
	SO ₂ is being absorbed	Replace any lines made of vinyl or

Malfunction	Possible Cause	Action
	and released by dirt in the tubing or filters of the calibration system, or contamination inside the instrument.	other plastics with fresh Teflon or stainless steel. Replace Teflon filter membranes that look dirty. Remove any filters that are not Teflon membranes.
	Averaging time is not set correctly.	Check the Averaging Time in Main Menu. If too high, the unit will be slow to stabilize. If too low, the signal may appear noisy.
	PMT high voltage power supply failure	Check the PMT high voltage power supply voltage. This voltage should be about -600 volts (violet wire is positive).
	Flasher lamp	Replace with known good lamp to see if the lamp is the problem.

Table 6–3. Troubleshooting - Measurement Failures

Malfunction	Possible Cause	Action
Reduced response or no response to sample gas with alarm(s) indicated.	Undefined electronic failure or pump failure	Check alarm screens and the diagnostic voltage screen to localize fault.
		Check the response to known span gas. Run an optical span test.
	Instrument is not drawing in sample as expected.	Check sample Flow and Pressure readings on the Diagnostics screen.
		Use an independent flow meter to check flows at the sample inlet and exhaust bulkheads (they should match). Perform a leak test, as described in the "Preventive Maintenance" chapter.
Reduced response or no response to sample gas with no alarms indicated.	Instrument is not drawing in sample as expected.	Check sample Flow and Pressure readings on the Diagnostics screen.
		Use an independent flow meter to check flows at the sample inlet and exhaust bulkheads (they should match). Perform a leak test, as described in the "Preventive Maintenance" chapter.
		Check the external plumbing for leaks or

Malfunction	Possible Cause	Action
		other problems.
		Check all external plumbing and the source of the sample to verify that the SO ₂ is not being adsorbed by the sampling system. Lines carrying SO ₂ must be made from clean Teflon or stainless steel.
	Detection circuit failure	Go to Diagnostics menu and run the optical span test to verify PMT and associated electronics.
	Instrument is not properly calibrated.	Go to the Calibration Factors menu and verify that the SO ₂ Background and SO ₂ Coefficient are set appropriately.
	Input board malfunction	Go to Service Menu and select Input Board Test to verify A/D signal on each range.
	Signal cable failure	While viewing the Input Board Test screen, set the gain to 100 and then disconnect the signal cable from the input board. The signal should drop from a value above 1000 to near zero.
	PMT failure	Check the PMT voltage (Service menu).
	Flash lamp assembly failure	Check the lamp voltage (Service menu).
Span calibration coefficient outside acceptable limits of 0.5 – 2.0.	Bad span gas	Verify quality of span gas.
	System leak	Perform leak test.
	Insufficient calibrator flow	Verify calibrator is providing a flow of at least 0.8 LPM.
Excessive noise or spikes on analog outputs	Defective or low sensitivity PMT	Check PMT voltage and run an optical span test. Replace PMT with known good unit if possible.
	Defective input board or BNC connection	Identify the defective component and replace.
	Noise pick-up by recorder or data logger	Check analog cable shielding and grounding. Try to localize source of noise by comparing analog signal to data collected through RS-232 or Ethernet.
Poor linearity	Problem with calibrator	Verify accuracy of the multipoint calibration system with an independent flow meter.
	Problem with input board range switching	Go to the Input Board Test screen (Service menu) and step through each range while the instrument samples a known stable

Malfunction	Possible Cause	Action
		source of SO ₂ . Stay on the Input Board Test screen, and while holding instrument on the lowest gain, step the calibrator through all SO ₂ levels. Manually plot signal vs. concentration to verify linearity.
	Leak in sample probe line	Check for variable dilution.
Excessive response time	Averaging time is not set correctly.	Go to Averaging Time (Main Menu) and verify setting.
	Instrument is not drawing in sample at normal flow rate.	Check sample Flow and Pressure readings on the Diagnostics screen. Use an independent flow meter to check flows at the sample inlet and exhaust bulkheads (they should match). Perform a leak test, as described in the "Preventive Maintenance" chapter.
	SO ₂ is being absorbed and/or released by dirt in the tubing or filters of the sampling system, or inside the instrument.	Replace any lines made of vinyl or other plastics with fresh Teflon or stainless steel.
		Replace Teflon filter membranes that look dirty. Remove any filters that are not Teflon membranes.
Analog signal doesn't match expected value.	Software has not been configured.	Verify that the selected analog output has been properly configured to match the data system.
	Analog output goes above full-scale value or below zero	By default, a 5% over and under range on the analog outputs is provided. If this is not desirable due to system restrictions, it may be turned off in the INSTRUMENT CONTROLS > I/O CONFIGURATION > ANALOG OUTPUT CONFIG screens.
	Recorder is drawing down output.	Verify that the recorder or data logger input impedance meets minimum requirements.
Flow meter fluctuations	Dirty pump diaphragm	Clean or replace pump diaphragm.
	Capillary blocked	Clean or replace capillary.
	Clogged Teflon line	Inspect all sample lines.

Table 6–4. Troubleshooting - Alarm Messages

Alarm Message	Possible Cause	Action
Alarm - Internal Temp	Instrument overheating	Replace fan if not operating properly.
		Clean or replace foam filter, refer to the "Preventive Maintenance" chapter in this manual. Check 10K thermistor on measurement interface board, replace if bad.
Alarm - Chamber Temp	Chamber temperature below set point	Check 10K thermistor, replace if bad. Check temperature control board to insure the LEDs are coming on. If not, temperature control board could be defective.
	Heaters have failed	Check connector pins for continuity.
Alarm - Pressure	High pressure indication	Check plumbing for leaks. Check the pump for a tear in the diaphragm, replace with pump repair kit if necessary. Refer to the "Preventive Maintenance" chapter in this manual. Check that capillary is properly installed and O-rings are in good shape. Replace if necessary.
Alarm - Flow	Flow low	Check sample capillary for blockage. Replace as necessary. If using sample particulate filter make sure it is not blocked. Disconnect sample particulate filter from the sample bulkhead, if flow increases, replace the filter. Perform leak test to check for internal leaks.
	Flow high	When delivering zero air or gas to the instrument, use an atmospheric dump.
Alarm - Intensity	Low - lamp is failing	Check that the lamp and trigger pak are securely fastened. Replace lamp.
Alarm - Lamp voltage	Low voltage (<750V) – lamp power supply has failed	Replace the lamp power supply.
	High voltage (>1200V) - flash lamp failed	Replace the flash lamp.
Alarm - SO ₂ Conc.	Concentration has exceeded range limit	Check to insure range corresponds with expected value. If not, select proper range.

Alarm Message	Possible Cause	Action
	Concentration low	Check user-defined low set point, be sure the min trigger is set as desired.
Alarm - Zero Check Alarm - Span Check	Instrument out of calibration	Recalibrate instrument.
Alarm - Zero Autocal Alarm - Span Autocal	Instrument out of calibration	Check gas supply. Perform manual calibration.
Alarm - Motherboard Status Alarm - Interface Status Alarm - I/O Exp Status	Internal cables not connected properly Board is defective	Check that all internal cables are connected properly. Recycle AC power to instrument. If still alarming, change board.

Board-Level Connection Diagrams

Figure 6-1 and **Figure 6-2** are board-level connection diagrams for the common electronics and measurement system. These illustrations can be used along with the connector pin descriptions in **Table 6-5** through **Table 6-12** to troubleshoot board-level faults.




Figure 6-1. Board-Level Connection Diagram - Common Electronics




Figure 6–2. Board-Level Connection Diagram – Measurement System

Connector Pin Descriptions

The connector pin descriptions in **Table 6–5** through **Table 6–12** can be used along with the board-level connection diagrams to troubleshoot board-level faults.

Table 6–5. Motherboard Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
INTF DATA	J1	1	Ground
		2	+RS485 to Interface Board
		3	-RS485 to Interface Board
10-BASE-T	J2	1	Ethernet Output (+)
		2	Ethernet Output (-)
		3	Ethernet Input (+)
		4	NC
		5	NC
		6	Ethernet Input (-)
		7	NC
		8	NC
EXPANSION BD	J3	1	+5V
		2	+24V
		3	+24V
		4	Ground
		5	Ground
		6	Ground
		7	+RS485 to Expansion Board
		8	-RS485 to Expansion Board
SPARE DATA	J4	1	+5V
		2	+24V
		3	+24V
		4	Ground
		5	Ground
		6	Ground
		7	+RS485 to Spare Board
		8	-RS485 to Spare Board
I/O	J5	1	Power Fail Relay N.C. Contact

Connector Label	Reference Designator	Pin	Signal Description
		2	Ground
		3	TTL Input 1
		4	TTL Input 2
		5	Ground
		6	TTL Input 5
		7	TTL Input 7
		8	TTL Input 8
		9	TTL Input 10
		10	Ground
		11	TTL Input 13
		12	TTL Input 15
		13	Ground
		14	Analog Voltage Output 1
		15	Analog Voltage Output 3
		16	Ground
		17	Analog Voltage Output 5
		18	Ground
		19	Ground
		20	Power Fail Relay COM
		21	Power Fail Relay N.O. Contact
		22	Ground
		23	TTL Input 3
		24	TTL Input 4
		25	TTL Input 6
		26	Ground
		27	TTL Input 9
		28	TTL Input 11
		29	TTL Input 12
		30	TTL Input 14
		31	TTL Input 16
		32	Ground
		33	Analog Voltage Output 2
		34	Analog Voltage Output 4
		35	Ground
		36	Analog Voltage Output 6

Troubleshooting

Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
SER EN	J7	37	Ground
		1	Serial Enable Jumper
		2	+3.3V
24V IN	J10	1	+24V
		2	Ground
DIGITAL OUTPUT	J14	1	+5V
		2	+24V
		3	+24V
		4	Ground
		5	Ground
		6	Ground
		7	SPI Reset
		8	SPI Input
		9	SPI Output
		10	SPI Board Select
		11	SPI Clock
EXT. RS485	J15	1	-RS485 to Rear Panel
		2	+RS485 to Rear Panel
		3	+5V
		4	+5V
		5	+5V
		6	Ground
		7	Ground
		8	Ground
		9	NC
		10	NC
		11	+24V
		12	+24V
		13	+24V
		14	+24V
		15	+24V
24V MONITOR	J17	1	24V Power Monitor
		2	Ground
FRONT PANEL BD	J18	1	Ground

Connector Label	Reference Designator	Pin	Signal Description
		2	Ground
		3	LCLK – LCD Signal
		4	Ground
		5	Ground
		6	LLP – LCD Signal
		7	LFLM – LCD Signal
		8	LD4 – LCD Signal
		9	LD0 – LCD Signal
		10	LD5 – LCD Signal
		11	LD1 – LCD Signal
		12	LD6 – LCD Signal
		13	LD2 – LCD Signal
		14	LD7 – LCD Signal
		15	LD3 – LCD Signal
		16	LCD Bias Voltage
		17	+5V
		18	Ground
		19	Ground
		20	LCD_ONOFF – LCD Signal
		21	Keypad Row 2 Input
		22	Keypad Row 1 Input
		23	Keypad Row 4 Input
		24	Keypad Row 3 Input
		25	Keypad Col 2 Select
		26	Keypad Col 1 Select
		27	Keypad Col 4 Select
		28	Keypad Col 3 Select
		29	Ground
		30	Ground
		31	Ground
		32	Ground
		33	+24V
		34	+24V
RS232/RS485:A	P1:A	1	NC

Connector Label	Reference Designator	Pin	Signal Description
		2	Serial Port 1 RX (+RS485 IN)
		3	Serial Port 1 TX (-RS485 OUT)
		4	NC
		5	Ground
		6	NC
		7	Serial Port 1 RTS (+RS485 OUT)
		8	Serial Port 1 CTS (-RS485 IN)
		9	NC
RS232/RS485:B	P1:B	1	NC
		2	Serial Port 2 RX (+RS485 IN)
		3	Serial Port 2 TX (-RS485 OUT)
		4	NC
		5	Ground
		6	NC
		7	Serial Port 2 RTS (+RS485 OUT)
		8	Serial Port 2 CTS (-RS485 IN)
		9	NC
AC IN	PJ1	1	AC-HOT
		2	AC-NEUT
		3	AC-Ground
AC 24VPWR	PJ2	1	AC-HOT
		2	AC-NEUT
		3	AC-Ground
AC INTF BD	PJ3	1	AC-HOT
		2	AC-NEUT
		3	AC-Ground

Table 6–6. Measurement Interface Board Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
DATA	IPJ8	1	Ground
		2	+RS485 from Motherboard
		3	-RS485 from Motherboard
FLASH TRIG	FJ1	1	Flash Voltage
		2	Flash Trigger

Connector Label	Reference Designator	Pin	Signal Description
FLASH INT	FJ2	3	Ground
		1	+15V
		2	-15V
		3	Ground
		4	Lamp Intensity
INPUT BD	MJ8	1	+15V
		2	Ground
		3	-15V
		4	+5V
		5	Ground
		6	Measurement Frequency Output
		7	Sample Hold
		8	NC
		9	GAIN A
		10	GAIN B
HVPS	MJ9	1	HV Power Supply Voltage Adjust
		2	Ground
		3	HV Power Supply On/Off
		4	Ground
		5	HV Power Supply Voltage Monitor
		6	Ground
		7	Ground
PRES	MJ10	1	Pressure Sensor Input
		2	Ground
		3	+15V
		4	-15V
FLOW	MJ11	1	Flow Sensor Input
		2	Ground
		3	+15V
		4	-15V
		5	Ground
LED	MJ14	1	LED Drive
		2	LED Supply
AMB TEMP	MJ15	1	Ambient Temperature Thermistor

Troubleshooting

Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
BENCH HEATER	NTJ1	2	Ground
		1	Bench Temperature Input
		2	Ground
		3	AC-HOT
CONVERTER	MJ17	4	Bench Heater AC
		1	Converter Temperature Input
		2	Ground
		3	Converter Heater On/Off
24V IN	P1	4	Ground
		5	+15V
		6	-15V
		2	Ground
AC PUMP	PJ5	1	AC-HOT
		2	AC-NEUT
		3	AC-Ground
FAN	PJ4	1	+24V
		2	Ground
AC IN	PJ3	1	AC-HOT
		2	AC-NEUT
		3	AC-Ground
AC CONVERTER	PJ12	1	AC-HOT
		2	AC-NEUT
		3	AC-Ground
Z/S SOL.	PJ7	1	+24V
		2	Zero/Span Solenoid Control
SAMPLE SOL.	PJ8	1	+24V
		2	Sample Solenoid Control
CONV SOL.	PJ9	1	+24V
		2	Spare 1 Solenoid Control
SPAN2 SOL.	PJ10	1	+24V
		2	Spare 2 Solenoid Control
PERM OVEN THERM	POJ1	1	Perm Oven Gas Thermistor
		2	Ground

Connector Label	Reference Designator	Pin	Signal Description
PERM OVEN	POJ3	1	Perm Oven Heater On/Off
		2	+15V Power
		3	Perm Oven Heater Thermistor
		4	Ground

Table 6–7. Front Panel Board Connector Pin Diagram

Connector Label	Reference Designator	Pin	Signal Description
MOTHER BOARD	J1	1	Ground
		2	Ground
		3	LCCLK – LCD Signal
		4	Ground
		5	Ground
		6	LLP – LCD Signal
		7	LFLM – LCD Signal
		8	LD4 – LCD Signal
		9	LD0 – LCD Signal
		10	LD5 – LCD Signal
		11	LD1 – LCD Signal
		12	LD6 – LCD Signal
		13	LD2 – LCD Signal
		14	LD7 – LCD Signal
		15	LD3 – LCD Signal
		16	LCD Bias Voltage
		17	+5V
		18	Ground
		19	Ground
		20	LCD_ONOFF – LCD Signal
		21	Keypad Row 2 Input
		22	Keypad Row 1 Input
		23	Keypad Row 4 Input
		24	Keypad Row 3 Input
		25	Keypad Col 2 Select
		26	Keypad Col 1 Select
		27	Keypad Col 4 Select

Troubleshooting

Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
		28	Keypad Col 3 Select
		29	Ground
		30	Ground
		31	Ground
		32	Ground
		33	+24V
		34	+24V
LCD DATA	J2	1	LD0_5V – LCD Signal
		2	LD1_5V – LCD Signal
		3	LD2_5V – LCD Signal
		4	LD3_5V – LCD Signal
		5	LCD_ONOFF_5V – LCD Signal
		6	LFLM_5V – LCD Signal
		7	NC
		8	LLP_5V – LCD Signal
		9	LCLK_5V – LCD Signal
		10	+5V
		11	Ground
		12	-25V
		13	LCD Bias Voltage
		14	Ground
KEYBOARD	J3	1	Keypad Row 1 Input
		2	Keypad Row 2 Input
		3	Keypad Row 3 Input
		4	Keypad Row 4 Input
		5	Keypad Col 1 Select
		6	Keypad Col 2 Select
		7	Keypad Col 3 Select
		8	Keypad Col 4 Select
LCD BACKLIGHT	J4	1	+5V Supply
		2	NC
		3	Ground

Table 6–8. I/O Expansion Board (Optional) Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
EXPANSION I/O	J1	1	Analog Voltage Input 1
		2	Analog Voltage Input 2
		3	Analog Voltage Input 3
		4	Ground
		5	Analog Voltage Input 4
		6	Analog Voltage Input 5
		7	Analog Voltage Input 6
		8	Ground
		9	Analog Voltage Input 7
		10	Analog Voltage Input 8
		11	Ground
		12	NC
		13	Current Output Return
		14	Ground
		15	Current Output 1
		16	Current Output Return
		17	Current Output 2
		18	Current Output Return
		19	Current Output 3
		20	Current Output Return
		21	Current Output 4
		22	Current Output Return
		23	Current Output 5
		24	Current Output Return
		25	Current Output 6
MOTHER BD	J2	1	+5V
		2	+24V
		3	+24V
		4	Ground
		5	Ground
		6	Ground
		7	+RS485 to Motherboard

Connector Label	Reference Designator	Pin	Signal Description
		8	-RS485 to Motherboard

Table 6–9. Digital Output Board Connector Pin Descriptions

Connector Label	Reference Designation	Pin	Signal Description
MOTHER BD	J1	1	+5V
		2	+24V
		3	+24V
		4	Ground
		5	Ground
		6	Ground
		7	SPI Reset
		8	SPI Input
		9	SPI Output
		10	SPI Board Select
		11	SPI Clock
DIGITAL OUTPUTS	J2	1	Relay 1 Contact a
		2	Relay 2 Contact a
		3	Relay 3 Contact a
		4	Relay 4 Contact a
		5	Relay 5 Contact a
		6	Relay 6 Contact a
		7	Relay 7 Contact a
		8	Relay 8 Contact a
		9	Relay 9 Contact a
		10	Relay 10 Contact a
		11	NC
		12	Solenoid Drive Output 1
		13	Solenoid Drive Output 2
		14	Solenoid Drive Output 3
		15	Solenoid Drive Output 4
		16	Solenoid Drive Output 5
		17	Solenoid Drive Output 6
		18	Solenoid Drive Output 7
		19	Solenoid Drive Output 8

Connector Label	Reference Designation	Pin	Signal Description
		20	Relay 1 Contact b
		21	Relay 2 Contact b
		22	Relay 3 Contact b
		23	Relay 4 Contact b
		24	Relay 5 Contact b
		25	Relay 6 Contact b
		26	Relay 7 Contact b
		27	Relay 8 Contact b
		28	Relay 9 Contact b
		29	Relay 10 Contact b
		30	+24V
		31	+24V
		32	+24V
		33	+24V
		34	+24V
		35	+24V
		36	+24V
		37	+24V

Table 6–10. Input Board Connector Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
PMT IN	J1	1	PMT Input
		2	Ground
INTF BD	J2	1	+15V
		2	Ground
		3	-15V
		4	+5V
		5	Ground
		6	Measurement Frequency Output
		7	Sample Hold
		8	NC
		9	Gain A
		10	Gain B

Table 6–11. Flash Trigger Pack Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
FLASH TRIG	TO J01	1	Flash Voltage
		2	Flash Trigger
		3	Ground

Table 6–12. Flash Intensity Assembly Pin Descriptions

Connector Label	Reference Designator	Pin	Signal Description
FLASH INT		1	+15V
		2	-15V
		3	Ground
		4	Lamp Intensity

Service Locations

For additional assistance, service is available from exclusive distributors worldwide. Contact one of the phone numbers below for product support and technical information or visit us on the web at www.thermo.com/aqi.

1-866-282-0430 Toll Free

1-508-520-0430 International

Chapter 7

Servicing

This chapter explains how to replace the Model 43i subassemblies. It assumes that a subassembly has been identified as defective and needs to be replaced.

For fault location information refer to the “Preventive Maintenance” chapter and the “Troubleshooting” chapter in this manual.

The service mode, described in the “Operation” chapter, includes parameters and functions that are useful when making adjustments or diagnosing problems.

For additional service assistance, see “Service Locations” at the end of this chapter.

Safety Precautions

Read the safety precautions before beginning any procedures in this chapter.



WARNING The service procedures in this manual are restricted to qualified representatives. ▲

If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲



CAUTION Carefully observe the instructions in each procedure. ▲



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

DO NOT point the photomultiplier tube at a light source. This can permanently damage the tube. ▲

DO NOT attempt to clean the mirrors in the optical bench. These mirrors do not come in contact with the sample gas and should not be cleaned. Cleaning the mirrors can damage the mirrors. ▲

Handle all printed circuit boards by the edges. ▲

Do not remove the LCD panel or frame from the LCD module. ▲

The polarizing plate is very fragile, handle it carefully. ▲

Do not wipe the polarizing plate with a dry cloth, it may easily scratch the plate. ▲

Do not use alcohol, acetone, MEK or other Ketone based or aromatic solvents to clean the LCD module, use a soft cloth moistened with a naphtha cleaning solvent. ▲

Do not place the LCD module near organic solvents or corrosive gases. ▲

Do not shake or jolt the LCD module. ▲








Figure 7-1. Properly Grounded Antistatic Wrist Strap

Firmware Updates




The firmware can be updated by the user in the field via the serial port or over the Ethernet. This includes both the main processor firmware and the firmware in all low-level processors. Refer to the *iPort* manual for the firmware update procedure.

Accessing the Service Mode

If the Service Menu is not displayed on the Main Menu, use the following procedure to display it.

1. At the Main Menu, press  to scroll to Instrument Controls > press  >  to scroll to **Service Mode** > and press .

The Service Mode screen appears.

2. Press  to toggle the Service Mode to ON.
3. Press  >  to return to the Main Menu.
4. Return to the procedure.

Replacement Parts List

Table 7–1 lists the replacement parts for the Model 43i major subassemblies. Refer to **Figure 7–2** to identify the component location.

Table 7–1. Replacement Parts

Part Number	Description
100480-00	Front Panel Pushbutton Board
101491-07	Processor Board
100533-00	Motherboard Assembly
100539-00	Digital Output Board
100542-00	I/O Expansion Board (Optional)
102340-00	Front Panel Connector Board
102496-00	Front Panel Display
101399-00	Transformer, Step-Down, 220-240V (Optional)
101863-00	Transformer, 100V, Step-up Transformer
100862-00	Measurement Interface Board Assembly
100883-00	Input Board Assembly
8774	Trigger Board Assembly
101023-00	Pressure Transducer Assembly
102055-00	Flow Transducer
8666	Lamp, Flashtube
8884	Flash Intensity (Photocell) Assembly
8746	Kicker Assembly, Standard and Heated (optional)
8868	Photomultiplier Tube (PMT)
101024-00	PMT High Voltage Power Supply
100727-00	PMT Base Socket Assembly
101426-00	Pump 110VAC w/Plate and Fittings
8606	Pump Repair Kit (for 101426-00)
101055-00	AC Receptacle Assembly
4510	Fuse, 250VAC, 3.0 Amp, SlowBlow (for 100VAC and 110VAC models)

Part Number	Description
14007	Fuse, 250VAC, 1.60 Amp, SlowBlow (for 220-240VAC models)
101681-00	Power Supply Assembly, 24VDC, w/Base Plate and Screws
101688-00	Ambient Temperature Thermistor with Connector
100907-00	Fan, 24VDC
8630	Filter Guard Assembly (w/foam)
8919	Capillary, 0.013-inch ID (~0.5 LPM flow rate standard)
4800	Capillary O-ring
4119	Capillary, 0.008-inch ID (Perm Oven Option)

Cable List

Table 7–2 describes the Model 43i cables. See the “Troubleshooting” chapter for associated connection diagrams and board connector pin descriptions.

Table 7–2. Model 43i Cables

Part Number	Description
101036-00	DC Power Supply, 24V Output
101037-00	115VAC Supply to Measurement Interface Board
101048-00	RS-485/Data
101038-00	Power Switch to Motherboard
101364-00	DC Power Supply Status Monitor
101054-00	Motherboard to Front Panel Board
101035-00	DC Power Supply AC Input
101033-00	AC from Receptacle
101377-00	AC to Power Switch
101355-00	Signal Output Ribbon
101695-00	Permeation Oven
101055-00	Main AC Receptacle Assembly
101267-00	Fan Power Cable

External Device Connection Components

Table 7–3 lists the standard and optional cables and components used for connecting external devices such as PCs and data loggers to an *iSeries* instrument.

Table 7–3. External Device Connection Components

Part Number	Description
102562-00	Terminal Block and Cable Kit (DB25) (optional)
102556-00	Terminal Block and Cable Kit (DB37) (optional)
102645-00	Cable, DB37M to Open End, Six Feet (optional)
102646-00	Cable, DB37F to Open End, Six Feet (optional)
102659-00	Cable, DB25M to Open End, Six Feet (optional)
6219	Cable, RS-232 (optional)
102888-00	Terminal Board PCB Assembly, DB37F (standard with all instruments)
102891-00	Terminal Board PCB Assembly, DB37M (standard with all instruments)
103084-00	Terminal Board PCB Assembly, DB25M (included with optional I/O Expansion Board in all instruments)

Servicing

Removing the Measurement Bench and Lowering the Partition Panel




Figure 7-2. Model 43i Component Layout

Removing the Measurement Bench and Lowering the Partition Panel

The measurement bench can be removed and the partition panel can be lowered to improve access to connectors and components. Refer to the following steps when a procedure requires lowering the partition panel (**Figure 7-3**).




Figure 7-3. Removing the Measurement Bench and Lowering the Partition Panel

Equipment Required:

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF and unplug the power cord.

2. If the instrument is mounted in a rack, remove it from the rack.
3. Remove the cover.
4. Disconnect the plumbing connections at the rear of the measurement bench.
5. Disconnect the connectors that pass through the center of the partition panel.
6. Remove two screws from the left side of the case (viewed from front).
7. Remove one screw from the bottom rear of the case.
8. Remove one screw from the top front of the partition panel.
9. While holding the case securely, loosen the captive screw at the rear of the measurement bench, and pull the measurement bench from the rear of the case.
10. Remove the screw at the top rear of the partition panel securing the top of partition panel to the measurement bench, and lower the panel being careful not to put excessive tension on the cables.
11. Replace the measurement bench by following previous steps in reverse.

Fuse Replacement

Use the following procedure to replace the fuse.

Equipment Required:

Replacement fuses (refer to the “Replacement Parts List” in this chapter).

1. Turn instrument OFF and unplug the power cord.
2. Remove fuse drawer, located on the AC power connector.
3. If either fuse is blown, replace both fuses.

4. Insert fuse drawer and reconnect power cord.

Pump Replacement

Use the following procedure to replace the pump (**Figure 7-4**). To rebuild the pump, see “Pump Rebuilding” in the “Preventive Maintenance” chapter.

Equipment Required:

Pump

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the pump power cable from the AC PUMP connector on the measurement interface board.
3. Remove both lines from the pump.
4. Loosen the four captive screws holding the pump bracket to the shock mounts and remove the pump assembly.




Figure 7-4. Replacing the Pump

5. Install the new pump by following the previous steps in reverse.
6. Perform a leak test as described in the “Preventive Maintenance” chapter.

Fan Replacement

Use the following procedure to replace the fan (**Figure 7-5**).

Equipment Required:

Fan

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Remove the fan guard from the fan and remove the filter.
3. Pull the power connector off the fan.

4. Remove the four fan mounting screws and remove the fan.
5. Install a new fan following the previous steps in reverse.




Figure 7–5. Replacing the Fan

Optical Bench Replacement

Use the following procedure to replace the optical bench (**Figure 7–6**).

Equipment Required:

Allen wrench, 5/32-inch

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the electrical cables from the optical bench:
 - a. Flash intensity assembly cable from the FLASH INT connector on the measurement interface board
 - b. Heater cable from AC BENCH connector on the measurement interface board

Servicing

Optical Bench Replacement

- c. PMT BNC cable from the input board connector
 - d. PMT power cable from the HVPS
 - e. LED cable from the LED connector on the measurement interface board
 - f. Flasher assembly from the FLASH TRIG connector on the measurement interface board
 - g. Green ground wire from the floor plate
3. Disconnect the optical bench plumbing.
 4. Using a 5/32-inch Allen wrench, remove the four optical bench retaining screws, and lift the optical bench off the floor plate.
 5. Replace the optical bench by following the previous steps in reverse order.
 6. Calibrate the instrument. Refer to the “Calibration” chapter in this manual.




Figure 7–6. Replacing the Optical Bench

Cleaning the Mirrors

The mirrors located in the optical bench do not come in contact with the sample gas and DO NOT need cleaning. Read the Equipment Damage warning that follows.



Equipment Damage DO NOT attempt to clean the mirrors in the optical bench. These mirrors do not come in contact with the sample gas and should not be cleaned. Cleaning the mirrors can damage the mirrors. ▲

Flash Lamp Replacement

Use the following procedure to replace the flash lamp (**Figure 7-7**).

Equipment Required:

Flash lamp

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the flash trigger cable from the FLASH TRIG connector the measurement interface board.
3. Remove the bench (see “Optical Bench Replacement” in this chapter).
4. Loosen the retaining screw on the top of the lamp housing and pull out the socket assembly and lamp.

Servicing

Flash Lamp Voltage Adjustment




Figure 7-7. Replacing the Flash Lamp and Flash Trigger Assembly

5. Remove the old lamp from the socket assembly by pulling straight out and insert the new lamp.
6. Insert the socket assembly into the lamp housing, tighten the retaining screw, and reconnect the flash trigger cable.
7. Re-install the bench.
8. Adjust the lamp voltage. Refer to the “Flash Lamp Voltage Adjustment” procedure that follows.

Flash Lamp Voltage Adjustment




Use the following procedure to adjust the flash lamp voltage.

Note The service procedures in this manual are restricted to qualified service representatives. ▲

1. From the Main Menu, press  to scroll to **Service** > press  >  to scroll to **Flash Voltage Adjustment** > and press .

The Set Flash Voltage Adjustment - Man screen appears.

Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲

2. At the Set Flash Voltage Adjustment - Main screen, use   until the SUPPLY voltage is 1000V.
3. Press  to store the value.
4. Perform a PMT Voltage Adjustment, and recalibrate the instrument. Refer to “PMT Voltage Adjustment” in this chapter and the calibration procedures in the “Calibration” chapter.

Flash Trigger Assembly Replacement

Use the following procedure to replace the flash trigger assembly (**Figure 7-7**).

Equipment Required:

Flash trigger assembly

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the flash trigger cable from the FLASH TRIG connector on the measurement interface board.
3. Remove the bench (see “Optical Bench Replacement” in this chapter).
4. Loosen the retaining screw on the top of the lamp housing and pull out the trigger assembly and lamp.

5. Remove the lamp from the trigger assembly by pulling straight out and insert the lamp into the new trigger assembly.
6. Insert the new flash trigger assembly into the lamp housing, tighten the retaining screw, and reconnect the flash trigger cable.
7. Re-install the bench.

Flash Intensity Assembly Replacement

Use the following procedure to replace the flash intensity assembly.

Equipment Required:

Flash intensity assembly

Phillips screwdriver, small



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the flash intensity cable from the FLASH INT connector on the measurement interface board.
3. Remove the three screws securing the flash intensity assembly to the reaction chamber (**Figure 7-8**).
4. Install the new flash intensity assembly by following this procedure in reverse.




Figure 7–8. Replacing the Flash Intensity Assembly

Photomultiplier Tube Replacement

Use the following procedure to replace the photomultiplier tube.

Equipment Required:

Photomultiplier tube

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn analyzer OFF, unplug the power cord, and remove the cover.
2. Disconnect the high voltage cable from the PMT power supply cable connector and unplug the BNC cable from the input board connector.
3. Remove the three retaining screws holding the PMT cover to the PMT housing, and pull back the cover to access the two PMT base retaining screws.
4. Pull PMT and PMT base from the PMT housing by twisting it slightly back and forth.
5. To install a new PMT, follow previous steps in reverse.

6. Perform a photomultiplier tube calibration. See “PMT Voltage Adjustment” in this chapter.




Figure 7–9. Replacing the PMT

PMT High Voltage Power Supply Replacement

Use the following procedure to replace the PMT high voltage power supply (**Figure 7–10**).

Equipment Required:

PMT high voltage power supply

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the two PMT high voltage supply cables.
3. Loosen the two retaining screws securing the power supply bracket to the floor plate and slide the power supply towards the rear slightly and lift it off the base screws.




Figure 7–10. Replacing the PMT High Voltage Power Supply (HVPS)





4. Loosen two screws on the input box assembly and lift the input box assembly off the bracket.
5. Remove the four screws securing the power supply to the bracket and remove the power supply.
6. To install the power supply, follow the previous steps in reverse.
7. Recalibrate the instrument. Refer to the calibration procedures in the “Calibration” chapter.

PMT Voltage Adjustment

Use the following procedure to adjust the PMT voltage after replacing the PMT, High Voltage Power Supply, or switching from standard to extended ranges or vice versa.


Note: The service procedures in this manual are restricted to qualified service representatives. ▲

1. Select the SO₂ range. Refer to “Range Menu” in the “Operation” chapter.



2. Reset the SO₂ BKG calibration factors to 0.0. Refer to “Calibration Factors Menu” in the “Operation” chapter.
3. Reset the SO₂ COEF to 1.000.
4. Set the Averaging Time to 10 seconds. Refer to “Averaging Time” in the “Operation” chapter.
5. Connect the calibration gas and allow the instrument to sample calibration gas until the reading stabilizes.
6. From the Main Menu, press  to scroll to **Service** > press  >  to scroll to **PMT Supply Settings** > and press .

The PMT Supply Settings screen appears.

Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲

7. At the PMT Supply Settings screen, press  to select **Manual PMT Adjustment**.

The Set PMT Voltage - Manual screen appears.

8. At the Set PMT Voltage - Manual screen, use   to increment/decrement the counts until the instrument displays the calibration gas concentration value.

DC Power Supply Replacement

Use the following procedure to replace the DC power supply (**Figure 7–11**).

Equipment Required:

DC power supply
Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect all the power supply electrical connections. Note connector locations to facilitate re-connection.
3. Loosen the captive screw securing the power supply to the chassis plate and lift out the power supply.
4. To install the DC power supply, follow the previous steps in reverse.




Figure 7–11. Replacing the DC Power Supply





Analog Output Testing

The analog outputs should be tested if the concentration value on the front panel display disagrees with the analog outputs. To check the analog outputs, you connect a meter to an analog output channel (voltage or current) and compare the meter reading with the output value displayed on the Test Analog Outputs screen.



Equipment Required:

Multimeter


Use the following procedure to test the analog outputs.

1. Connect a meter to the channel to be tested. **Figure 7–12** shows the analog output pins and **Table 7–4** identifies the associated channels.
2. From the Main Menu, press  to scroll to Diagnostics, press  >  to scroll to Test Analog Outputs, and press .

The Test Analog Outputs screen displays.


3. Press  to scroll to the desired channel corresponding to the rear panel terminal pins where the meter is connected, and press .

The Set Analog Outputs screen displays.

4. Press  to set the output to zero.


The Output Set To line displays Zero.

5. Check that the meter is displaying a zero value. If the meter reading differs by more than one percent, the analog outputs should be adjusted. Refer to the “Analog Output Calibration” procedure that follows.

6. Press  to set the output to full scale.

The Output Set To line displays Full Scale.

7. Check that the meter is displaying the full scale value. If the meter reading differs by more than one percent, the analog outputs should be adjusted. Refer to the “Analog Output Calibration” procedure that follows.

8. Press  to reset the analog outputs to normal.




Figure 7–12. Rear Panel Analog Input and Output Pins

Table 7–4. Analog Output Channels and Rear Panel Pin Connections

Voltage Channel	Pin	Current Channel	Pin
1	14	1	15
2	33	2	17
3	15	3	19
4	34	4	21
5	17	5	23
6	36	6	25
Ground	16, 18, 19, 35, 37	Current Output Return	16, 18, 20, 22, 24

Table 7–5. Analog Input Channels and Rear Panel Pin Connections





Input Channel	Pin
1	1
2	2
3	3
4	5
5	6
6	7
7	9
8	10
Ground	4, 8, 11

Analog Output Calibration

Use the following procedure to calibrate the analog outputs if a meter reading in the “Analog Output Testing” procedure differed by more than one percent or after replacing the motherboard or optional I/O expansion board.




Equipment Required:

Multimeter

1. Connect a meter to the channel to be adjusted and set to voltage or current as appropriate. **Figure 7–12** shows the analog output pins and **Table 7–4** identifies the associated channels.
2. From the Main Menu, press  to scroll to Service, press  >  to scroll to Analog Out Calibration, and press .










The Analog Output Cal screen displays.

Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲

3. At the Analog Output Cal screen, press  to scroll to the voltage channel or current channel corresponding to the rear panel terminal pins where the meter is connected, then press .
4. With the cursor at Calibrate Zero, press .

The Analog Output Cal line displays Zero.

Note When calibrating the analog output, always calibrate zero first and then calibrate full scale. ▲

5. Use   until the meter reads the value shown in the Set Output To line, then press  to save the value.
6. Press  to return to the previous screen.
7. Press   to select Calibrate Full Scale.
8. Use   until the meter reads the value shown in the Set Output To line, then press  to save the value.

Analog Input Calibration

Use the following procedures to calibrate the analog inputs after replacing the optional I/O expansion board. These procedures include selecting analog input channels, calibrating them to zero volts, and then calibrating them to full scale using a known voltage source.




Use the following procedure to calibrate the input channels to zero volts.

Calibrating the Input Channels to Zero Volts


1. From the Main Menu, press  to scroll to Service, press  >  to scroll to Analog Input Calibration, and press .

The Analog Input Cal screen displays.



Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲

2. At the Analog Input Cal screen, press  to scroll to a channel, and press .
3. With the cursor at Calibrate Zero, press .

The screen displays the input voltage for the selected channel.

4. Make sure that nothing is connected to the channel input pins and press  to calibrate the input voltage on the selected channel to zero volts.

The screen displays 0.00 V as the voltage setting.





5. Press  >  to return to the Analog Input Cal screen and repeat Steps 2 through 4 to calibrate other input channels to zero as necessary.
6. Continue with the “Calibrating the Input Channels to Full Scale” procedure that follows.

Calibrating the Input Channels to Full Scale





Use the following procedure to calibrate the input channels to full scale by applying a known voltage to the channels.

Equipment Required:






DC voltage source (greater than 0 volts and less than 10 volts)



1. Connect the known DC voltage source to the input channel (1-8) to be calibrated. **Figure 7–12** shows the analog output pins and **Table 7–4** identifies the associated channels.
2. From the Main Menu, press  to scroll to Service, press  >  to scroll to Analog Input Calibration, and press .

The Analog Input Cal screen displays input channels 1-8.

3. At the Analog Input Cal screen, press  to scroll to the channel selected in Step 1, and press .
4. Press  to scroll to Calibrate Full Scale, and press .

The screen displays the current input voltage for the selected channel.

5. Use   and   to enter the source voltage, and press  to calibrate the input voltage for the selected channel to the source voltage.

6. Press  >  to return to the input channels display and repeat Steps 3-5 to calibrate other input channels to the source voltage as necessary.

Pressure Transducer Assembly Replacement

Use the following procedure to replace the pressure transducer assembly (**Figure 7-13**).

Equipment Required:

Pressure transducer assembly

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect plumbing from the pressure transducer assembly. Note the plumbing connections to facilitate reconnection.
3. Disconnect the pressure transducer cable from the measurement interface board.
4. Loosen the two pressure transducer assembly retaining screws and remove the pressure transducer assembly by sliding it down then taking it out.
5. To install the pressure transducer assembly, follow the previous steps in reverse.
6. Calibrate the pressure transducer. Refer to the “Pressure Transducer Calibration” procedure that follows.




Figure 7-13. Replacing the Pressure Transducer Assembly

Pressure Transducer Calibration

Use the following procedure to calibrate the pressure transducer.

Notes An error in the zero setting of the pressure transducer does not introduce a measurable error in the output concentration reading. Therefore, if only a barometer is available and not a vacuum pump, adjust only the span setting. ▲

A rough check of the pressure accuracy can be made by obtaining the current barometric pressure from the local weather station or airport and comparing it to the pressure reading. However, since these pressures are usually corrected to sea level, it may be necessary to correct the reading to local pressure by subtracting 0.027 mm Hg per foot of altitude. ▲





Do not try to calibrate the pressure transducer unless the pressure is known accurately. ▲

Equipment Required:

Vacuum pump













Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Remove the cover.
2. Disconnect the tubing from the pressure transducer and connect a vacuum pump known to produce a vacuum less than 1 mm Hg.
3. From the Main Menu, press  to scroll to **Service** > press  >  to scroll to **Pressure Calibration** > and press .

The Pressure Sensor Cal menu appears.

Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲

4. At the Pressure Sensor Cal screen, press  to select **Zero**.
The Calibrate Pressure Zero screen appears.
5. Wait at least 10 seconds for the zero reading to stabilize, then press  to save the zero pressure value.
6. Disconnect the pump from the pressure transducer.
7. Press  to return to the Pressure Sensor Cal screen.
8. At the Pressure Sensor Cal screen, press   to select **Span**.
The Calibrate Pressure Span screen appears.
9. Wait at least 10 seconds for the ambient reading to stabilize, use   and   to enter the known barometric pressure, and press  to save the pressure value.
10. Reconnect the instrument tubing to the pressure transducer.
11. Install the cover.

Flow Transducer Replacement

Use the following procedure to replace the flow transducer (**Figure 7–14**).

Equipment Required:

Flow transducer

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the plumbing connections from the flow transducer. Note the plumbing connections to facilitate reconnection.
3. Disconnect the flow transducer cable from the FLOW connector on the measurement interface board.
4. Remove the two screws securing the flow transducer to the kicker bracket and remove the flow transducer.
5. Install the new flow transducer following the previous steps in reverse.
6. Calibrate the flow transducer. Refer to the “Flow Transducer Calibration” procedure that follows.




Figure 7–14. Replacing the Flow Transducer

Flow Transducer Calibration

Use the following procedure to calibrate the flow transducer.

Equipment Required:

Calibrated flow sensor







WARNING The service procedures in this manual are restricted to qualified representatives. ▲

If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Remove the cover.


2. Disconnect the pump cable from AC PUMP connector on the measurement interface board.
3. From the Main Menu, press  to scroll to Service > press  >  to scroll to **Flow Calibration** > and press .

The Flow Sensor Cal screen appears.

Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲


4. At the Flow Sensor Cal screen, press  to select **Zero**.



The Calibrate Flow Zero screen appears.

5. Wait at least 10 seconds for the zero reading to stabilize, then press  to save the zero flow value.






6. Reconnect the pump cable to the AC PUMP connector on the measurement interface board.

7. Connect a calibrated flow sensor at the SAMPLE bulkhead on the rear panel.

8. Press  to return to the Flow Sensor Cal screen.

9. At the Flow Sensor Cal screen, press   to select **Span**.

The Calibrate Flow Span screen appears.

10. Wait at least 10 seconds for the reading to stabilize, use   and   to enter the flow sensor reading, and press  to save the value.

11. Install the cover.

Heater Assembly Replacement

Use the following procedure to replace the heater assembly (**Figure 7–15**).

Equipment Required:

- Heater assembly
- Heat sink grease
- Philips screwdriver
- Allen wrench, 5-32-inch



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect heaters from the AC BENCH cable.
3. Using the 5-32-inch wrench, remove the four screws securing the optical bench to the floor plate (**Figure 7–6**).
4. Lift the optical bench from the floor plate to gain access to the heater assembly.
5. Remove two retaining screws and washers from each heater and remove the heaters (**Figure 7–15**).
6. Apply heat sink grease to the new heaters as appropriate.
7. Fasten each heater with the two retaining screws and washers.
8. Secure the optical bench to the floor plate with the four screws.
9. Connect the heaters to the AC BENCH cable.

10. Replace the cover and plug in the power cord.




Figure 7–15. Replacing the Heater Assembly

Kicker Replacement

Use the following procedure to replace the kicker assembly (**Figure 7–16**).

Equipment Required:

Kicker assembly

Cable ties



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the plumbing connections from the flow transducer, the optical bench, and the rear bulkhead. Note the plumbing connections to facilitate reconnection.
3. Cut the ties securing the kicker assembly to the kicker bracket and remove the kicker.

4. Install the new kicker, following the previous steps in reverse.




Figure 7–16. Replacing the Kicker Assembly (Standard Kicker)

Heated Kicker Replacement

Use the following procedure to replace the heated kicker assembly (**Figure 7–17**).

Equipment Required:

- Heated kicker assembly (optional)
- Allen wrench, 5/32-inch



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Using a 5/32-inch Allen wrench, remove the four optical bench retaining screws (**Figure 7–17**).

3. Disconnect the plumbing connections as appropriate to gain enough clearance to lift the optical bench off the heated kicker. Carefully note the plumbing connections to facilitate reconnection.
4. Lift the heated kicker off the rubber mounts.
5. Install the new heated kicker assembly.
6. Reposition the optical bench on top of the heated kicker, insert and tighten the four optical bench retaining screws, and reconnect any plumbing connections by following the previous steps in reverse order.
7. Calibrate the instrument. Refer to the “Calibration” chapter in this manual.




Figure 7–17. Replacing the Kicker Assembly (Optional Heated Kicker)

Thermistor Replacement

Use the following procedure to replace the ambient temperature thermistor (**Figure 7–18**).

Equipment Required:

Thermistor



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Squeeze the thermistor latch and pull the thermistor from the AMB TEMP connector on the measurement interface board.
3. Snap the new thermistor into the AMB TEMP connector.




Figure 7-18. Replacing the Thermistor

Ambient Temperature Calibration

Use the following procedure to calibrate the ambient internal temperature for the instrument.

Equipment Required:

Calibrated thermometer or 10K \pm 1% resistor



WARNING The service procedures in this manual are restricted to qualified representatives. ▲

If the equipment is operated in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired. ▲



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Remove the instrument cover.
2. Tape the thermistor (plugged into the measurement interface board) to a calibrated thermometer






Note Since the thermistors are interchangeable to an accuracy of ± 0.2 °C, and have a value of 10K ohms at 25 °C, an alternate procedure is to connect an accurately known 10K resistor to the thermistor input (AMB TEMP) on the measurement interface board, and enter the temperature reading. ▲

A 1 °C change corresponds to a $\pm 5\%$ change in resistance, thus this alternative procedure can be quite accurate as a check; however, it clearly is not NIST traceable. ▲

3. From the Main Menu, press  to scroll to Service > press  >  to scroll to **Temperature Calibration** > and press .

The Calibrate Ambient Temperature screen appears.

Note If Service Mode is not displayed, refer to “Accessing the Service Mode” in this chapter, then return to the beginning of this step. ▲

4. Wait at least 10 seconds for the ambient reading to stabilize, use   and   to enter the known temperature, and press  to save the temperature value.
5. Install the cover.

Input Board Replacement

Use the following procedure to replace the input board (**Figure 7–19**).

Equipment Required:

Input board
Philips screwdriver

1. Disconnect the BNC signal cable and the ribbon cable.
2. Loosen the two screws securing the bracket holding the input board to the floor plate, slide the bracket towards the optical bench slightly, and lift it off the base screws.




Figure 7–19. Replacing the Input Board

3. Loosen the two screws securing the input board assembly to the bracket, slide the assembly up, and remove from bracket.
4. Install the input board assembly by following the previous steps in reverse.

I/O Expansion Board (Optional) Replacement

Use the following procedure to replace the optional I/O expansion board (**Figure 7–20**).

Note After replacing the optional I/O expansion board, calibrate the current outputs and the analog voltage inputs. See the “Analog Output Calibration” procedure and the “Analog Input Calibration” procedure in this chapter. ▲

Equipment Required:

I/O expansion board

Nut driver, 3/16-inch



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Unplug the I/O expansion board cable from the EXPANSION BD connector on the motherboard.
3. Remove the two standoffs holding the I/O expansion board connector to the rear panel (**Figure 7–21**).
4. Pop off the board from the mounting studs and remove the board.
5. To install the I/O expansion board, follow previous steps in reverse.
6. Calibrate the analog current outputs and analog voltage inputs per the procedure earlier in this chapter.




Figure 7–20. Replacing the I/O Expansion Board (Optional)




Figure 7–21. Rear Panel Board Connectors

Digital Output Board Replacement

Use the following procedure to replace the digital output board (**Figure 7–18** and **Figure 7–19**).

Equipment Required:

Digital output board

Nut driver, 3/16-inch



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis

before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Remove the I/O expansion board (optional), if used. See the “I/O Expansion Board Replacement” procedure in this chapter.
3. Disconnect the digital output board ribbon cable from the motherboard.
4. Using the nut driver, remove the two standoffs securing the board to the rear panel (**Figure 7-19**).
5. Pop off the digital output board from the mounting studs and remove the board.
6. To install the digital output board, follow previous steps in reverse.

Motherboard Replacement

Use the following procedure to replace the motherboard (**Figure 7-18**).

Equipment Required:

Motherboard

Philips screwdriver

Nut driver, 3/16-inch



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7-1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Remove the I/O expansion board (optional), if used. See the “I/O Expansion Board Replacement” procedure in this chapter.

3. Remove the digital output board. See the “Digital Output Board Replacement” procedure in this chapter.
4. Unplug all connectors from the motherboard. Note connector locations to facilitate reconnection.
5. Using the nut driver, remove the standoffs securing the board to the rear panel (**Figure 7–19**).
6. Pop off the motherboard from motherboard support bracket, and remove the motherboard.
7. To install the motherboard, follow previous steps in reverse.
8. Calibrate the analog voltage outputs. Refer to “Analog Output Calibration” in this chapter.

Measurement Interface Board Replacement

Use the following procedure to replace the measurement interface board (**Figure 7–22**).

Equipment Required:

Measurement interface board

Philips screwdriver



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Refer to “Removing the Measurement Bench and Lowering the Partition Panel” in this chapter to lower the partition panel, then proceed to the next step below.
2. Unplug all connectors. Note the locations of the connectors to facilitate reconnection.

3. Unscrew the two screws at the top of the measurement interface board. Pop off the measurement interface board from the two bottom mounting studs and remove the board.
4. To install the measurement interface board, follow previous steps in reverse.
5. Re-install the measurement bench. Refer to “Removing the Measurement Bench and Lowering the Partition Panel” in this chapter.




Figure 7–22. Replacing the Measurement Interface Board

Front Panel Board Replacement

Use the following procedure to replace the front panel board (**Figure 7–23**).

Equipment Required:

Front panel board



Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Remove the three ribbon cables and the two-wire connector from the front panel board.
3. Pop off the board from the two top mounting studs and remove the board by lifting it up and off the slotted bottom support.
4. Replace the front panel board by following previous steps in reverse.




Figure 7–23. Replacing the Front Panel Board and the LCD Module

LCD Module Replacement

Use the following procedure to replace the LCD module (**Figure 7–23**).

Equipment Required:

LCD module

Philips screwdriver



CAUTION If the LCD panel breaks, do not let the liquid crystal contact your skin or clothes. If the liquid crystal contacts your skin or clothes, wash it off immediately using soap and water. ▲

Equipment Damage Some internal components can be damaged by small amounts of static electricity. A properly ground antistatic wrist strap must

be worn while handling any internal component (**Figure 7–1**). If an antistatic wrist strap is not available, be sure to touch the instrument chassis before touching any internal components. When the instrument is unplugged, the chassis is not at earth ground. ▲

Do not remove the panel or frame from the module. ▲

The polarizing plate is very fragile, handle it carefully. ▲

Do not wipe the polarizing plate with a dry cloth, it may easily scratch the plate. ▲

Do not use alcohol, acetone, MEK or other Ketone based or aromatic solvents to clean the module, use a soft cloth moistened with a naphtha cleaning solvent. ▲

Do not place the module near organic solvents or corrosive gases. ▲

Do not shake or jolt the module. ▲

1. Turn instrument OFF, unplug the power cord, and remove the cover.
2. Disconnect the ribbon cable and the two-wire connector from the front panel board.
3. Remove the four screws at the corners of the LCD module.
4. Slide the LCD module out towards the top of the instrument.
5. Replace the LCD module by following previous steps in reverse.

Service Locations

For additional assistance, service is available from exclusive distributors worldwide. Contact one of the phone numbers below for product support and technical information or visit us on the web at www.thermo.com/aqi.

1-866-282-0430 Toll Free

1-508-520-0430 International

Chapter 8

System Description

This chapter describes the function and location of the system components, provides an overview of the software structure, and includes a description of the system electronics and input/output connections and functions as follows.

Hardware

Model 43i hardware components (**Figure 8–1**) include:

- Hydrocarbon kicker
- Heated hydrocarbon kicker (optional)
- Optics
 - Flash lamp
 - Condensing lens
 - Mirror assembly
 - Light baffle
- Trigger pack
- Reaction chamber
 - Bandpass filter
- Photomultiplier tube
- Photodetector
- Flow sensor
- Pressure transducer
- Capillary
- Vacuum Pump




Figure 8–1. Hardware Components

Hydrocarbon Kicker

The hydrocarbon kicker removes hydrocarbons from the gas stream while leaving the SO₂ concentration unaffected. It operates on a selective permeation principle using differential pressure to force hydrocarbon molecules to pass through the tube wall. The differential pressure is created across the tube wall as sample gas passes through a capillary tube which reduces its pressure. The sample gas is then fed to the shell side of the hydrocarbon kicker.

Heated Hydrocarbon Kicker (Optional)

The optional heated hydrocarbon kicker is used in applications requiring more efficiency than the standard kicker. The heated kicker operates at the same temperature as the optical bench and requires no additional power.

Optics The optics section provides the light source for the fluorescence reaction and optimizes the reaction with a system of lenses and mirrors. It includes a flash lamp, condensing lens, mirror assembly and light baffle.

Flash Lamp The flash lamp provides the ultraviolet light source that causes the fluorescence reaction in the SO₂ molecules.

Condensing Lens The condensing lens focuses light from the flash lamp into the mirror assembly.

Mirror Assembly A set of eight mirrors selectively reflects only those wavelengths used in exciting SO₂ molecules. This reflective filtering causes the radiation reaching the detection chamber to be more intense and more stable throughout the lifetime of the instrument.

Light Baffle The circular baffle helps keep stray light from entering the detection volume.

Flash Lamp Trigger Assembly The flash lamp trigger assembly pulses the UV flash lamp at a rate of 10 times per second for improved signal-to-noise ratio and long term stability.

The lamp is operated in the pulsed mode for six major reasons:

- Long life
- High optical intensity – improved signal to noise ratio
- Small size
- Low power requirements – less than 1 watt
- Long-term stability
- Chopped signal processing – no dark current drift

Reaction Chamber In the reaction chamber pulsating light from the flash lamp excites the SO₂ molecules. A condenser lens collects and focuses light from fluorescing SO₂ molecules onto the mirror assembly.

Bandpass Filter	The bandpass filter restricts the light reaching the photomultiplier tube to the SO ₂ fluorescence wavelengths.
Photomultiplier Tube	The PMT converts optical energy from the reaction to an electrical signal. This signal is sent to the input board which transmits it to the processor.
Photodetector	The photodetector is located in the fluorescence chamber and continuously monitors the pulsating UV flash lamp. This photodetector is connected to a circuit that automatically compensates for fluctuations in flash lamp output.
Flow Sensor	The flow sensor is used for measuring the flow of sample gas in the measurement system.
Pressure Transducer	The pressure transducer or pressure sensor measures the reaction chamber pressure.
Capillary	The capillary along with the pump is used to control flow in the sample line.
Vacuum Pump	The vacuum pump draws the reacted gases out of the reaction chamber.
Software	<p>The processor software tasks are organized into four areas:</p> <ul style="list-style-type: none">● Instrument Control● Monitoring Signals● Measurement Calculations● Output Communication
Instrument Control	Low-level embedded processors are used to control the various functions on the boards, such as analog and digital I/O, and heater control. These processors are controlled over a serial interface with a single high-level processor that also controls the front-panel user interface. The low-level

processors all run common firmware that is bundled with the high-level firmware and loaded on power-up if a different version is detected.

Each board has a specific address that is used to identify to the firmware what functions are supported on that board. This address is also used for the communications between the low-level processors and the high-level processor.

Every tenth of a second the frequency counters, analog I/O, and digital I/O are read and written to by the low-level processor. The counters are accumulated over the past second and the analog inputs are averaged over that second. The high-level processor polls the low-level processors once per second to exchange the measurement and control data.

Monitoring Signals

Signals are gathered from the low-level processors once per second, and then processed by the high-level processor to produce the final measurement values. The one-second accumulated counts are accumulated and reported for the user-specified averaging time. If this averaging time is greater than ten seconds, the measurement is reported every 10 seconds. The one-second average of the other analog inputs are reported directly (no additional signal conditioning is performed by the high-level processor).

Measurement Calculations

The calculation begins by flashing the lamp 10 times per second. After the lamp flash, a sample and hold circuit on the input board is used to sample the PMT output. The raw accumulated counts are scaled according to the gain setting of the input board.

Next, the uncorrected values are determined according to a unique averaging algorithm which minimizes errors resulting from rapidly changing gas concentrations. This algorithm results in values which are stored in RAM in a circular buffer that holds all the ten second data from the previous five minutes. This data is averaged over the selected time interval, which can be any multiple of ten between 1 and 300 seconds.

The background values, which are corrected for temperature, are subtracted from their respective averages. The reading is corrected by the stored span factor and by the temperature factor.

Output Communication

The front panel display, serial and Ethernet data ports, and analog outputs are the means of communicating the results of the above calculations. The front panel display presents the SO₂ concentrations. The display is updated every 1-10 seconds, depending on the averaging time.

The analog output ranges are user selectable via software. The analog outputs are defaulted based on the measurement range. The defaults are

calculated by dividing the data values by the full-scale range for each of the three parameters and then multiplying each result by the user-selected output range. Negative concentrations can be represented as long as they are within -5% of full-scale. The zero and span values may be set by the user to any desired value.

Electronics

All electronics operate from a universal switching supply, which is capable of auto-sensing the input voltage and working over the entire operating range.

The internal pump and heaters all operate on 110VAC. An optional transformer is required if operating on the 210-250VAC or 90-110VAC ranges.

An on/off switch controls all power to the instrument, and is accessible on the front panel.

Motherboard

The motherboard contains the main processor, power supplies, a sub-processor and serves as the communication hub for the instrument.

The motherboard receives operator inputs from the front panel mounted function key panel and/or over I/O connections on the rear panel and sends commands to the other boards to control the functions of the instrument and to collect measurement and diagnostic information.

The motherboard outputs instrument status and measurement data to the front-panel mounted graphics display and to the rear-panel I/O.

The motherboard also contains I/O circuitry and the associated connector to monitor external digital status lines and to output analog voltages that represent the measurement data.

Connectors located on the motherboard include:

External Connectors

External connectors include:

- External Accessory
- RS-232/485 Communications (two connectors)
- Ethernet Communications
- I/O connector with Power Fail Relay, 16 Digital Inputs, and 6 Analog Voltage Outputs.

Internal Connectors

Internal connectors include:

- Function key panel and Display

- Measurement Interface Board Data
- I/O Expansion Board Data
- Digital Output Board
- AC distribution

Measurement Interface Board

The measurement interface board serves as a central connection area for all measurement electronics in the instrument. It contains power supplies and interface circuitry for sensors and control devices in the measurement system. It sends status data to the motherboard and receives control signals from the motherboard.

Measurement Interface Board Connectors

Connectors located on the measurement interface board include:

- Data communication with the motherboard
- 24V and 120VAC power supply inputs
- Fan and solenoid outputs
- 120VAC outputs for the pump and temperature control
- Flow and pressure sensors
- Ambient temperature sensor
- Bench heater
- PMT high voltage supply
- Input board
- Flash trigger
- Flash intensity
- Diagnostic LED

Flow Sensor Assembly

The flow sensor assembly consists of a board containing an instrumentation amplifier and a flow transducer with input and output gas fittings. The flow transducer output is produced by measuring the pressure difference across a precision orifice. This unit is used for measuring the flow of sample gas in the measurement system.

Pressure Sensor Assembly

The pressure sensor assembly consists of a board containing an instrumentation amplifier and a pressure transducer with a gas input fitting. The pressure transducer output is produced by measuring the

pressure difference between the sample gas pressure and ambient air pressure.

Bench Heater

The fluorescence chamber temperature is measured with a thermistor. The voltage across the thermistor is fed to the main processor for use in calculating and displaying the reaction chamber temperature. The voltage across the thermistor is also compared to a set-point voltage and used to control that the reaction chamber heaters to maintain a constant temperature.

PMT Power Supply Assembly

The PMT power supply produces high voltage to operate the photomultiplier tube used in the measurement system. The output voltage is adjustable from approximately 600 to 1200 volts under software control.

Diagnostic LED

The diagnostic LED is used to provide an alternate light source to the PMT to determine if the PMT is operating when the operating condition of the flash lamp is unknown.

Input Board

The input board accepts the current signal from the PMT and converts it to a voltage, which is scaled by a factor of approximately 1, 10, or 100 depending on the full-scale range of the SO₂ channel. The scaled voltage signal is converted to a frequency and sent to the microprocessor.

Digital Output Board

The digital output board connects to the motherboard and provides solenoid driver outputs and relay contact outputs to a connector located on the rear panel of the instrument. Ten relay contacts normally open (with power off) are provided which are electrically isolated from each other. Eight solenoid driver outputs (open collector) are provided along with a corresponding +24VDC supply pin on the connector.

Front Panel Connector Board

The front panel connector board interfaces between the motherboard and the front panel mounted function key panel and Graphics display. It serves as central location to tie the three connectors required for the function key panel, the graphics display control lines, and the graphics display backlight to a single ribbon cable extending back to the motherboard. This board also includes signal buffers for the graphics display control signals and a high voltage power supply for the graphics display backlight.

Flash Trigger Board

The flash trigger board is located in the base of the flash lamp assembly. It receives high voltage and the trigger signal from the measurement interface board and uses a small transformer to produce a short, high-voltage pulse to fire the flash lamp.

Flash Intensity Board

The flash intensity board amplifies the lamp intensity signal detected by the photodetector which is used to control the lamp voltage.

I/O Expansion Board (Optional)

The I/O expansion board connects to the motherboard and adds the capability to input external analog voltage inputs and to output analog currents via a connector located on the rear panel of the instrument. It contains local power supplies, a DC/DC isolator supply, a sub-processor and analog circuits. Eight analog voltage inputs are provided with an input voltage range of 0V to 10VDC. Six current outputs are provided with a normal operating range of 0 to 20 mA.

I/O Components

External I/O is driven from a generic bus that is capable of controlling the following devices:

- Analog output (voltage and current)
- Analog input (voltage)
- Digital output (TTL levels)
- Digital input (TTL levels)

Note The instrument has spare solenoid valve drivers and I/O support for future expansion. ▲

Analog Voltage Outputs

The instrument provides six analog voltage outputs. Each may be software configured for any one of the following ranges, while maintaining a minimum resolution of 12 bits:

- 0-100mV
- 0-1V
- 0-5V
- 0-10V

The user can calibrate each analog output zero and span point through firmware. At least 5% of full-scale over and under range are also supported.

The analog outputs may be assigned to any measurement or diagnostic channel with a user-defined range in the units of the selected parameter. The voltage outputs are independent of the current outputs.

Analog Current Outputs (Optional)

The optional I/O Expansion board includes six isolated current outputs. These are software configured for any one of the following ranges, while maintaining a minimum resolution of 11 bits:

- 0-20 mA
- 4-20 mA

The user can calibrate each analog output zero and span point through firmware. At least 5% of full-scale over and under range are also supported.

The analog outputs may be assigned to any measurement or diagnostic channel with a user-defined range in the units of the selected parameter. The current outputs are independent of the voltage outputs. The current outputs are isolated from the instrument power and ground, but they share a common return line (Isolated GND).

Analog Voltage Inputs (Optional)

The optional I/O expansion board includes eight analog voltage inputs. These inputs are used to gather measurement data from third-party devices such as meteorological equipment. The user may assign a label, unit, and a voltage to user-defined unit conversion table (up to 16 points). All voltage inputs have a resolution of 12 bits over the range of 0 to 10 volts.

Digital Relay Outputs

The instrument includes one power fail relay on motherboard and ten digital output relays on the digital output board. These are reed relays rated for at least 500 mA @ 200VDC.

The power fail relay is Form C (both normally opened and normally closed contacts). All other relays are Form A (normally opened contacts) and are used to provide alarm status and mode information from the analyzer, as well as remote control to other devices, such as for controlling valves during calibration. The user may select what information is sent out each relay and whether the active state is opened or closed.

Digital Inputs

Sixteen digital inputs are available which may be programmed to signal instrument modes and special conditions including:

- Zero Gas Mode
- Span Gas Mode

- Set Background
- Cal to low span
- Cal to high span
- Analog outputs to zero
- Analog outputs to full scale

The actual use of these inputs will vary based on analyzer configuration.

The digital inputs are TTL level compatible and are pulled up within the analyzer. The active state can be user defined in firmware.

Serial Ports

Two serial ports allow daisy chaining so that multiple analyzers may be linked using one PC serial port.

The standard bi-directional serial interface can be configured for either RS-232 or RS-485. The serial baud rate is user selectable in firmware for standard speeds from 1200 to 19,200 baud. The user can also set the data bits, parity, and stop bits. The following protocols are supported:

- C-Link
- Streaming Data
- Modbus Slave
- Geysitech (Bayern-Hessen)

The Streaming Data protocol transmits user-selected measurement data via the serial port in real-time for capture by a serial printer, data logger, or PC.

RS-232 Connection

A null modem (crossed) cable is required when connecting the analyzer to an IBM Compatible PC. However, a straight cable (one to one) may be required when connecting the analyzer to other remote devices. As a general rule, when the connector of the host remote device is female, a straight cable is required and when the connector is male, a null modem cable is required.

Data Format:

1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200 BAUD

8 data bits

1 stop bit

no parity

All responses are terminated with a carriage return (hex 0D)

Refer to **Table 8–1** for the DB9 connector pin configuration.

Table 8–1. RS-232 DB Connector Pin Configurations

DB9 Pin	Function
2	RX
3	TX
7	RTS
8	CTS
5	Ground

RS-485 Connection

The instrument uses a four wire RS-485 configuration with automatic flow control (SD). Refer to **Table 8–2** for the DB9 connector pin configuration.

Table 8–2. RS-485 DB Connector Pin Configuration

DB9 Pin	Function
2	+ receive
8	- receive
7	+ transmit
3	- transmit
5	ground

Ethernet Connection

An RJ45 connector is used for the 10Mbps Ethernet connection supporting TCP/IP communications via standard IPV4 addressing. The IP address may be configured for static addressing or dynamic addressing (set using a DHCP server).

Any serial port protocols may be accessed over Ethernet in addition to the serial port.

External Accessory Connector

The external accessory connector is not used in the Model 43*i* analyzer.

This port is used in other models to communicate with smart external devices that may be mounted hundreds of feet from the analyzer using an RS-485 electrical interface.

Chapter 9

Optional Equipment

Internal Zero/Span and Sample Valves

With the zero/span assembly option, a source of span gas is connected to the SPAN port and a source of zero air is connected to the ZERO port. Zero and span gas should be supplied at atmospheric pressure. It may be necessary to use an atmospheric dump bypass plumbing arrangement to accomplish this.

See the “Installation” and “Operation” chapters for more information.

Internal Permeation Span Source

The Internal Permeation Span Source option is designed to provide a simple span check. This option is intended as a quick, convenient check to be used between zero and span calibrations for determining instrument malfunction or drift. Because this option does not precisely control dilution gas flow, it should not be used as a basis for instrument zero and span adjustments, calibration updates or adjustment of ambient data.

Whenever there is an indication of possible instrument drift or malfunction, a full zero and multipoint calibration (Level 1) should be performed prior to corrective action. For further information on zero, span and calibration of air pollution monitors, refer to Section 2.0.9 of the US EPA's *Quality Assurance Handbook for Air Pollution Measurement Systems (Volume II)*.

Figure 9–1 shows how this option is integrated with the Model 43i components. Energizing the sample valve V1 shuts off the sample flow and permits the flow of zero air for analysis. When valves V1 and V2 are energized, the flow of zero air mixes with air containing SO₂ from the permeation oven. This mode of operation provides a single point span check.




Figure 9-1. Internal Permeation Span Source Flow Diagram

Permeation Tube Installation

Use the following procedure to install the permeation tube.

1. Remove the oven cover.
 2. Remove the glass chamber assembly by loosening the white plastic retaining collar, loosening (not removing) the knurled screw, and gently pulling the assembly upward. Completely remove the oven.
 3. Separate the glass chamber from the top assembly by twisting and gently pulling the glass away from the top.
- Note** Keep the glass clean when handling it. ▲
4. Place the permeation tube(s) in the glass chamber.
 5. Attach the glass chamber to the top assembly by gently pushing the two together with a slight twisting motion.
 6. Replace the glass chamber assembly into the oven until the top of the assembly is flush or slightly below the top of the oven.



Equipment Damage Do not use tools to tighten the knurled screw in the following step. ▲

7. Tighten the knurled screw finger tight. Do not use tools to tighten.
8. Tighten the white plastic retaining collar.
9. Replace the oven cover being careful to place the tubing and wiring into the cover slot.

Computation of Concentrations

The computation of SO₂ output level is shown in the following information. Note that is assumed that all devices are properly calibrated and that all flows are corrected to 25 °C and 1 atm.

Permeation Tube:

$$Output (ppm) = \frac{(R)(K)}{Q_o}$$

Where:

R = permeation rate in ng/min

Q₀ = flow rate of gas (scc/min) into the charcoal scrubber during span mode

K = constant for the specific permeant = 24.45 / MW

MW = molecular weight

K(SO₂) = 0.382









Oven Installation and Configuration

Use the following procedure to install and configure the permeation oven.

1. Physically install the permeation oven and valves into the instrument and connect the cables and plumbing.
2. From the Perm Oven Settings menu in the Service menu, select **Perm Oven Selection**, then select **45 °C**.
3. Remove the thermistor from POJ1 on the measurement interface board.
4. Connect a resistance of approximately 3.8 KΩ across pins 1 and 2 of POJ1.

Optional Equipment

Internal Permeation Span Source

5. Go to the Factory Cal Gas Therm menu from the Perm Oven Settings menu in the Service menu. Select **Low Point**, enter the exact value of the resistor and press  to calibrate the low resistance point.
6. Press  to return to the Factory Cal Gas Therm menu.
7. Connect a resistance of approximately 5 K Ω across pins 1 and 2 of POJ1.
8. Go to the High Point screen, enter the exact value of the resistor and press  to calibrate the high resistance point.
9. Press  to return to the Factory Cal Gas Therm menu.
10. Remove resistor from POJ1 and re-attach the gas thermistor.
11. Connect a resistance of approximately 3.8 K Ω across pins 3 and 4 of POJ3.
12. Go to the Factory Cal Oven Therm menu from the Perm Oven Settings menu in the Service menu. Select **Low Point**, enter the exact value of the resistor and press  to calibrate the low resistance point.
13. Press  to return to the Factory Cal Oven Therm menu.
14. Connect a resistance of approximately 5 K Ω across pins 3 and 4 of POJ3.
15. Go to the High Point screen, enter the exact value of the resistor and press  to calibrate the high resistance point.
16. Press  to return to the Factory Cal Oven Therm menu.
17. Remove resistor from POJ3 and re-attach the permeation oven.
18. Perform a thermistor calibration using the “Permeation Tube Oven Calibration” procedure that follows.

Permeation Tube Oven Calibration

There are two general approaches that can be used to calibrate the permeation tube oven. The first is to calibrate the temperature indicator very accurately (to better than 0.02 °C) and to use a permeation tube whose weight loss has been previously determined at that temperature.

Note An error of approximately 0.1 °C corresponds to an error of 1% in release rate. ▲

The second approach is to note that the thermistors used to measure temperature are interchangeable to better than ± 0.2 °C. Thus a 1% resistor of the proper value (4.369 K Ω for 45 °C) can be used to set the span on the measurement interface board. The release rate for the permeation tube is then determined by weight loss in the actual oven being used.

Setting Perm Oven Temperature

You can use either of the two calibration methods presented here. One method involves performing the “Setting Perm Oven Temperature” procedure and then continuing with the “Setting Temperature with Water Bath” procedure.

Alternatively, you can perform the “Setting Perm Oven Temperature” procedure and then continue with the “Setting Temperature with Known Resistance” procedure.

In either case, use the following procedure for setting the perm oven temperature.

1. Unplug POJ3 from the measurement interface board. Place a 4.369 K Ω resistor across pins 3 and 4 on the board.
2. From the Permeation Oven menu in the Service menu, select **Cal Oven Thermistor (Figure 9–2)**.

```



CAL OVEN THERM (RESISTOR):
CURRENTLY:      4369 Ohms
SET TO:         04369 Ohms

      ↔ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM


```


Figure 9–2. Cal Oven Therm Resistor Screen

3. Enter the exact value of the attached resistor and press  to save the offset.
4. Press  to return to the Permeation Oven menu.
5. Remove the resistor and re-attach the permeation oven to POJ3.

Setting Temperature with Water Bath

Use the following procedure for setting the measure temperature with water bath.

1. Remove the thermistor from the permeation tube oven, but leave the thermistor connected to the measurement interface board. Insert the thermistor into the water bath next to an NIST traceable thermometer (if necessary, use an extension cable to reach).
2. Turn on the power to the water bath. Using an NIST traceable thermometer with a resolution of ± 0.01 °C, adjust the water bath to 45 °C.
3. From the Permeation Oven menu, in the Service menu, select Cal Gas Thermistor > **Water Bath**. Enter the thermistor temperature from the thermometer and press  (**Figure 9-3**).



```
CAL GAS THERM (BATH):  
CURRENTLY: 45.80 °C  
SET TO: 45.00 °C  
  
↔ MOVE CURSOR  
↑↓ CHANGE VALUE ← SAVE  
  
RANGE AVG DIAGS ALARM
```

Figure 9-3. Cal Gas Therm Bath Screen

4. Remove the thermistor from the water bath, dry, and replace the permeation tube oven.
5. Make sure the charcoal scrubber is connected to the ZERO bulkhead on the rear panel.

- Wait for the permeation gas temperature reading to stabilize.

Setting Temperature with Known Resistance

Use the following procedure to set the gas temperature with an accurate known resistance.

- Remove the thermistor from POJ1 on the measurement interface board.
- Connect a 4.369 K Ω resistor across pins 1 and 2 of POJ1 (use a resistance substitution box and an accurate meter, if necessary).
- From the Permeation Oven menu, select **Cal Gas Thermistor**, then select known resistor (**Figure 9-4**).

```


CAL GAS THERM (RESISTOR):
CURRENTLY:    4369 Ohms
SET TO:       04369 Ohms

      ←→ MOVE CURSOR
↑↓ CHANGE VALUE  ← SAVE

RANGE  AVG  DIAGS  ALARM

```

Figure 9-4. Cal Gas Therm Resistor Screen

- Enter the exact value of the attached resistor and press  to save the offset.
- Remove the resistor and reconnect the gas thermistor.
- Make sure the charcoal scrubber is connected to the ZERO bulkhead on the rear panel.
- Wait for the permeation gas temperature reading to stabilize.

Determining Permeation Rate by Weight Loss

Use the following procedure to determine the permeation rate by weight loss.

- Make sure the oven has been calibrated as described in the “Permeation Tube Oven Calibration” procedure described previously.

Optional Equipment

Internal Permeation Span Source

2. Insert the permeation tube carefully. Do not touch with fingers.
3. Turn on the instrument.
4. Wait 48-72 hours for the permeation tube to stabilize.
5. Carefully remove the permeation tube from the oven and weigh to an accuracy of 0.1mg. Perform this measurement as quickly as possible.
6. Replace the permeation tube into the oven of the instrument.
7. Repeat Steps 5 and 6 after two weeks.
8. Compute the weight loss of the permeation tube from the values determined in Steps 5 through 7.
9. Repeat Steps 5 through 8 until the weight loss has been determined to a precision of 1-2%.
10. For the most accurate work, use the permeation tube in the same oven that was used to determine the weight loss of permeation tube.

Determining Release Rate by Transfer Standard

Use the following procedure to determine the release rate by transfer standard.

1. Make sure the oven has been calibrated as described in the "Permeation Tube Oven Calibration" procedure described previously. Also make sure that the Transfer Standard has been properly calibrated.
2. Determine the permeation rate for the permeation tube in the Transfer Standard, or install a certified permeation tube.
3. Allow the permeation tubes in both the 43*i* and the Transfer Standard to stabilize for at least 48 hours.
4. Carefully calibrate the 43*i* using the Transfer Standard. The output of the Transfer Standard should be connected to the SAMPLE bulkhead on the rear panel of the 43*i*.

5. Switch the calibrated 43i into the span mode.
6. Measure the flow rate into the ZERO bulkhead on the rear panel of the 43i. Be sure that the charcoal scrubber is connected. Note the flow and measured SO₂ concentration.
7. From the flow and measured concentration, compute the permeation tube release rate.

Heated Hydrocarbon Kicker

The optional heated hydrocarbon kicker is used in applications requiring more efficiency than the standard kicker. The heated kicker operates at the same temperature as the optical bench and requires no additional power.

Teflon Particulate Filter

A 5-10 micron pore size, two-inch diameter Teflon element is available for the Model 43i. This filter should be installed just prior to the **SAMPLE** bulkhead. When using a filter, all calibrations and span checks must be performed through the filter.

I/O Expansion Board Assembly

The I/O expansion board provides six analog current output channels (0-20 mA or 4-20 mA) and eight analog voltage inputs (0-10V). The DB25 connector on the rear panel provides the interface for these inputs and outputs.

25-Pin Terminal Board Assembly

The 25-pin terminal board assembly is included with the optional I/O expansion board. Refer to “Terminal Board PCB Assemblies” in the Installation” chapter for information on attaching the cable to the connector board. For associated part numbers, refer to the “Servicing” chapter.

Terminal Block and Cable Kits

The optional terminal block and cable kits provide a convenient way to connect devices to the instrument. These kits break out the signals on the rear panel connector to individual numbered terminals.

Two types of terminal block and cable kits are available. One kit is for the DB37 connectors and can be used for either the analog output connector or the relay output connector. The other kit is for the DB25 connector and can be used for the optional I/O expansion board. For associated part numbers, refer to the “Servicing” chapter.

Each kit consists of:

- one six-foot cable
- one terminal block

- one snap track

Note Supporting all of the connections on units with the optional I/O expansion board requires:

- two DB37 kits
- one DB25 kit

Cables

Table 9–1 identifies the optional individual cables that are available for the instrument and **Table 9–2** provides the cable color codes. For associated part numbers, refer to the Servicing chapter.

Note **Table 9–2** provides the color coding for both 25-pin cables and 37-pin cables. Color codes for pins 1-25 are for 25-pin cables; color codes for pins 1-37 are for 37-pin cables. ▲

Table 9–1. Cable Options

Description	Cable Length
DB37M to open end	Six feet
DB37F to open end	Six feet
DB25M to open end	Six feet
RS-232	

Table 9–2. Color Codes for 25-Pin and 37-Pin Cables

Pin	Color	Pin	Color
1	BLACK	20	RED/BLACK
2	BROWN	21	ORANGE/BLACK
3	RED	22	YELLOW/BLACK
4	ORANGE	23	GREEN/BLACK
5	YELLOW	24	GRAY/BLACK
6	GREEN	25	PINK/BLACK
7	BLUE	End color codes for 25-pin cables continue for 37-pin cables.	
8	VIOLET	26	PINK/GREEN
9	GRAY	27	PINK/RED
19	WHITE	28	PINK/VIOLET
11	PINK	29	LIGHT BLUE

Pin	Color	Pin	Color
12	LIGHT GREEN	30	LIGHT BLUE/BROWN
13	BLACK/WHITE	31	LIGHT BLUE/RED
14	BROWN/WHITE	32	LIGHT BLUE/VIOLET
15	RED/WHITE	33	LIGHT BLUE/BLACK
16	ORANGE/WHITE	34	GRAY/GREEN
17	GREEN/WHITE	35	GRAY/RED
18	BLUE/WHITE	36	GRAY/VIOLET
19	VIOLET/WHITE	37	LIGHT GREEN/BLACK

The analyzer can be installed in the configuration described in **Table 9–3** and shown in

Mounting Options

Figure 9–5 through **Figure 9–8**.

Table 9–3. Mounting Options

Mounting Type	Description
Bench	Positioned on bench, includes mounting feet, and front panel side-trim handles.
EIA rack	Mounted in an EIA-style rack, includes mounting slides, and front panel EIA-rack mounting handles.
Retrofit rack	Mounted in a Thermo non-EIA rack, includes mounting slides, and retrofit front panel rack-mounting handles.




Figure 9–5. Rack Mount Option Assembly




Figure 9-6. Bench Mounting




Figure 9-7. EIA Rack Mounting




Figure 9–8. Retrofit Rack Mounting

Optional Equipment

Mounting Options

Appendix A

Warranty

Seller warrants that the Products will operate or perform substantially in conformance with Seller's published specifications and be free from defects in material and workmanship, when subjected to normal, proper and intended usage by properly trained personnel, for the period of time set forth in the product documentation, published specifications or package inserts. If a period of time is not specified in Seller's product documentation, published specifications or package inserts, the warranty period shall be one (1) year from the date of shipment to Buyer for equipment and ninety (90) days for all other products (the "Warranty Period"). Seller agrees during the Warranty Period, to repair or replace, at Seller's option, defective Products so as to cause the same to operate in substantial conformance with said published specifications; provided that (a) Buyer shall promptly notify Seller in writing upon the discovery of any defect, which notice shall include the product model and serial number (if applicable) and details of the warranty claim; (b) after Seller's review, Seller will provide Buyer with service data and/or a Return Material Authorization ("RMA"), which may include biohazard decontamination procedures and other product-specific handling instructions; and (c) then, if applicable, Buyer may return the defective Products to Seller with all costs prepaid by Buyer. Replacement parts may be new or refurbished, at the election of Seller. All replaced parts shall become the property of Seller. Shipment to Buyer of repaired or replacement Products shall be made in accordance with the Delivery provisions of the Seller's Terms and Conditions of Sale. Consumables, including but not limited to lamps, fuses, batteries, bulbs and other such expendable items, are expressly excluded from the warranty under this warranty.

Notwithstanding the foregoing, Products supplied by Seller that are obtained by Seller from an original manufacturer or third party supplier are not warranted by Seller, but Seller agrees to assign to Buyer any warranty rights in such Product that Seller may have from the original manufacturer or third party supplier, to the extent such assignment is allowed by such original manufacturer or third party supplier.

In no event shall Seller have any obligation to make repairs, replacements or corrections required, in whole or in part, as the result of (i) normal wear and tear, (ii) accident, disaster or event of force majeure, (iii) misuse, fault or negligence of or by Buyer, (iv) use of the Products in a manner for which

they were not designed, (v) causes external to the Products such as, but not limited to, power failure or electrical power surges, (vi) improper storage and handling of the Products or (vii) use of the Products in combination with equipment or software not supplied by Seller. If Seller determines that Products for which Buyer has requested warranty services are not covered by the warranty hereunder, Buyer shall pay or reimburse Seller for all costs of investigating and responding to such request at Seller's then prevailing time and materials rates. If Seller provides repair services or replacement parts that are not covered by the warranty provided in this warranty, Buyer shall pay Seller therefor at Seller's then prevailing time and materials rates. ANY INSTALLATION, MAINTENANCE, REPAIR, SERVICE, RELOCATION OR ALTERATION TO OR OF, OR OTHER TAMPERING WITH, THE PRODUCTS PERFORMED BY ANY PERSON OR ENTITY OTHER THAN SELLER WITHOUT SELLER'S PRIOR WRITTEN APPROVAL, OR ANY USE OF REPLACEMENT PARTS NOT SUPPLIED BY SELLER, SHALL IMMEDIATELY VOID AND CANCEL ALL WARRANTIES WITH RESPECT TO THE AFFECTED PRODUCTS.

THE OBLIGATIONS CREATED BY THIS WARRANTY STATEMENT TO REPAIR OR REPLACE A DEFECTIVE PRODUCT SHALL BE THE SOLE REMEDY OF BUYER IN THE EVENT OF A DEFECTIVE PRODUCT. EXCEPT AS EXPRESSLY PROVIDED IN THIS WARRANTY STATEMENT, SELLER DISCLAIMS ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, WITH RESPECT TO THE PRODUCTS, INCLUDING WITHOUT LIMITATION ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. SELLER DOES NOT WARRANT THAT THE PRODUCTS ARE ERROR-FREE OR WILL ACCOMPLISH ANY PARTICULAR RESULT.

Appendix B

C-Link Protocol Commands

This appendix provides a description of the C-Link protocol commands that can be used to remotely control a Model 43*i* analyzer using a host device such as a PC or a datalogger. C-Link protocol may be used over RS-232, RS-485, or Ethernet. C-Link functions can be accessed over Ethernet using TCP/IP port 9880. Streaming data may be accessed over Ethernet using TCP/IP port 9881.

- “Instrument Identification Number” on page B-1.
- “Commands” on page B-2.
- “Measurements” on page B-8
- “Alarms” on page B-11.
- “Diagnostics” on page B-15.
- “Datalogging” on page B-16.
- “Calibration” on on page B-24.
- “Keys/Display” on page B-26.
- “Measurement Configuration” on page B-28.
- “Hardware Configuration” on page B-32.
- “Communications Configuration” on page B-35.
- “I/O Configuration” on page B-39.
- “I/O Configuration” on page B-39.

Instrument Identification Number

Each command sent to the analyzer must begin with the American Standard Code for Information Interchange (ASCII) symbol or byte value equivalent of the instrument's identification number plus 128. For example, if the instrument ID is set to 25, then each command must begin with the ASCII character code 153 decimal. The analyzer ignores any command that does not begin with its instrument identification number. If the instrument ID is set to 0, then this byte is not required. For more information on changing Instrument ID, see Chapter 3, “Operation”.

Commands

The analyzer must be in the remote mode in order to change instrument parameters via remote. However, the command "set mode remote" can be sent to the analyzer to put it in the remote mode. Report commands (commands that don't begin with "set") can be issued either in the remote or local mode. For information on changing modes, see Chapter 3, "Operation."

The commands can be sent in either uppercase or lowercase characters. Each command must begin with the proper instrument identification number (ASCII) character. The command in the example that follows begins with the ASCII character code 171 decimal, which directs the command to the Model 43*i*, and is terminated by a carriage return "CR" (ASCII character code 13 decimal).

<ASCII 171>	T	I	M	E	<CR>
-------------	---	---	---	---	------

If an incorrect command is sent, a "bad command" message will be received. The example that follows sends the incorrect command "set unit ppm" instead of the correct command "set gas unit ppm."

Send: set unit ppm
Receive: set unit ppm bad cmd

The "save" and "set save params" commands stores parameters in FLASH. It is important that each time instrument parameters are changed, that this command be sent. If changes are not saved, they will be lost in the event of a power failure.

Accessing Streaming Data

Streaming data is sent out the serial port or the Ethernet port on a user-defined periodic basis. Streaming data over Ethernet is only generated when a connection is made on TCP port 9881.

Entering Units in PPB

When interfacing to an instrument via C-link commands, always enter the concentration values in ppb or $\mu\text{g}/\text{m}^3$ units. For example, to set a background value to 20 ppm, enter 20000 (ppb) as the value for the set background command.

Commands List

Table B–1 lists the 43*i* C-Link protocol commands. The interface will respond to the associated command strings.

Table B–1. C-Link Protocol Commands

Command	Description	Page
addr dns	Reports/sets dns address	B-35
addr gw	Reports/sets default gateway address	B-35
addr ip	Reports/sets IP address	B-35
addr nm	Reports/sets netmask address	B-35
agc int	Reports current AGC intensity	B-15
alarm chamber temp max	Reports/sets chamber temperature alarm maximum value	B-11
alarm chamber temp min	Reports/sets chamber temperature alarm minimum value	B-11
alarm conc so2 max	Reports/sets current SO ₂ concentration alarm maximum value	B-12
alarm conc so2 min	Reports/sets current SO ₂ concentration alarm minimum value	B-12
alarm converter temp max	Reports/sets SO ₂ converter temperature alarm maximum value (Model 450 <i>i</i> only)	B-12
alarm converter temp min	Reports/sets SO ₂ converter temperature alarm minimum value (Model 450 <i>i</i> only)	B-12
alarm internal temp max	Reports/sets internal temperature alarm maximum value	B-13
alarm internal temp min	Reports/sets internal temperature alarm minimum value	B-13
alarm pressure max	Reports/sets pressure alarm maximum value	B-13
alarm pressure min	Reports/sets pressure alarm minimum value	B-13
alarm sample flow max	Reports/sets sample flow alarm maximum value	B-14
alarm sample flow min	Reports/sets sample flow alarm minimum value	B-14
alarm trig conc so2	Reports/sets current SO ₂ concentration alarm warning value	B-14
analog iout range	Reports analog current output range per channel	B-39
analog vin	Retrieves analog voltage input data per channel	B-39
analog vout range	Reports analog voltage output range per channel	B-39
avg time	Reports/sets averaging time	B-8
baud	Reports/sets current baud rate	B-36

Command	Description	Page
cal high so2 coef	Sets/auto-calibrates high range SO ₂ coefficient	B-24
cal low so2 coef	Sets/auto-calibrates low range SO ₂ coefficient	B-24
cal pres	Sets current measured pressure as pressure during calibration (for pressure compensation)	B-26
cal so2 bkg	Sets/auto-calibrates SO ₂ background	B-24
cal so2 coef	Sets/auto-calibrates SO ₂ coefficient	B-24
clr lrecs	Clears away only long records that have been saved	B-16
clr records	Clears away all logging records that have been saved	B-16
clr srecs	Clears away only short records that have been saved	B-16
contrast	Reports/sets current screen contrast	B-32
conv set temp	Reports/sets temperature setpoint for SO ₂ converter (Model 450i only)	B-32
conv temp	Reports current SO ₂ converter temperature (Model 450i only)	B-9
copy lrec to sp	Sets/copies current lrec selection into the scratch pad	B-22
copy sp to lrec	Sets/copies current selections in scratch pad into lrec list	B-22
copy sp to srec	Sets/copies current selections in scratch pad into srec list	B-22
copy sp to stream	Sets/copies current selections in scratch pad into stream list	B-22
copy srec to sp	Sets/copies current srec selection into the scratch pad	B-22
copy stream to sp	Sets/copies current streaming data selection into the scratch pad	B-22
custom	Reports/sets defined custom range concentration	B-29
data treatment lrec/srec	Reports/sets the current selection of data treatment for concentrations in the lrecs or srecs	B-22
date	Reports/sets current date	B-33
default params	Sets parameters to default values	B-33
dhcp	Reports/sets state of use of DHCP	B-36
diag volt iob	Reports diagnostic voltage level for I/O expansion board	B-15
diag volt mb	Reports diagnostic voltage level for motherboard	B-15
diag volt mib	Reports diagnostic voltage level for measurement interface board	B-15
dig in	Reports status of the digital inputs	B-40
din	Reports/sets digital input channel and active state	B-40
do (down)	Simulates pressing down pushbutton	B-26
dout	Reports/sets digital output channel and active state	B-41
dtoa	Reports outputs of the digital to analog converters per channel	B-41

Command	Description	Page
en (enter)	Simulates pressing enter pushbutton	B-26
er	Returns a brief description of the main operating conditions in the format specified in the commands	B-17
erec	Returns a brief description of the main operating conditions in the format specified in the command	B-18
erec format	Reports/sets erec format (ASCII or binary)	B-19
erec layout	Reports current layout of erec data	B-20
flags	Reports 8 hexadecimal digits (or flags) that represent the status of the ozonator, PMT, gas mode, and alarms	B-11
flow	Reports current measured sample flow in LPM	B-9
format	Reports/sets current reply termination format	B-37
gas mode	Reports current mode of sample, zero, or span	B-30
gas unit	Reports/sets current gas units	B-31
he (help)	Simulates pressing help pushbutton	B-26
high avg time	Reports/sets high range averaging time	B-8
high range	Reports/selects current SO ₂ high range	B-28
high so2	Reports SO ₂ concentration calculated with high range coefficients	B-8
high so2 coef	Reports/sets high range SO ₂ coefficients	B-25
high sp conc	Reports/sets high span concentration	B-25
host name	Reports/sets host name string	B-37
instr name	Reports instrument name	B-37
instrument id	Reports/sets instrument id	B-38
internal temp	Reports current internal instrument temperature	B-9
isc (iscreen)	Retrieves framebuffer data used for the display	B-26
lamp, set	Sets the flash lamp ON or OFF	B-33
lamp setpoint	Reports/sets flash lamp setpoint	B-15
lamp status	Reports/sets flash lamp status on or off	B-33
lamp int	Reports the current lamp intensity	B-16
lamp voltage	Reports flash lamp voltage	B-16
layout ack	Disables stale layout/layout changed indicator ("**")	B-38
le (left)	Simulates pressing left pushbutton	B-26
led status (led)	Reports/sets optical test LED status on or off	B-16
list din	Lists current selection for digital input	B-17
list dout	Lists current selection for digital output	B-17

Command	Description	Page
list lrec	Lists current selection lrec logging data	B-17
list sp	Lists current selection in the scratchpad list	B-17
list srec	Lists current selection srec logging data	B-17
list stream	Lists current selection streaming data output	B-17
list var aout	Reports list of analog output, index numbers, and variables	B-42
list var din	Reports list of digital input, index numbers, and variables	B-42
list var dout	Reports list of digital output, index numbers, and variables	B-42
low avg time	Reports/sets low averaging time	B-8
low range	Reports/sets current SO ₂ low range	B-28
low so2	Reports SO ₂ concentration calculated with low range coefficients	B-9
low so2 coef	Reports/sets low range SO ₂ coefficient	B-25
low sp conc	Reports/sets low span concentration	B-25
lr	Outputs long records in the format specified in the command	B-17
lrec	Outputs long records	B-18
lrec format	Reports/sets output format for long records (ASCII or binary)	B-19
lrec layout	Reports current layout of lrec data	B-20
lrec mem size	Reports maximum number of long records that can be stored	B-20
lrec per	Reports/sets long record logging period	B-20
malloc lrec	Reports/sets memory allocation for long records	B-21
malloc srec	Reports/sets memory allocation for short records	B-21
me (menu)	Simulates pressing menu pushbutton	B-26
mode	Reports operating mode in local, service, or remote	B-38
no of lrec	Reports/sets number of long records stored in memory	B-21
no of srec	Reports/sets number of short records stored in memory	B-21
perm gas temp	Reports current perm gas temperature	B-9
pmt status	Reports/sets PMT on or off	B-33
pmt voltage	Reports current PMT voltage	B-10
pres	Reports current reaction chamber pressure	B-10
pres cal	Reports/sets pressure used for calibration	B-26
pres comp	Reports/sets pressure compensation on or off	B-31
program no	Reports analyzer program number	B-38
push	Simulates pressing a key on the front panel	B-26
range	Reports/sets current SO ₂ range	B-28

Command	Description	Page
range mode	Reports/sets current range mode	B-29
react temp	Reports current reaction chamber temperature	B-10
relay status	Reports/sets relay logic status to for the designated relay(s)	B-42
ri (right)	Simulates pressing right pushbutton	B-26
ru (run)	Simulates pressing run pushbutton	B-26
sample sample gas	Sets zero/span valves to sample mode	B-30
save	Stores parameters in FLASH	B-33
save params	Stores parameters in FLASH	B-33
sc (screen)	C-series legacy command that reports a generic response (Use iscreen instead)	B-27
so2	Reports current SO ₂ concentration	B-9
so2 bkg	Reports/sets current SO ₂ background	B-25
so2 coef	Reports/sets current SO ₂ coefficient	B-25
sp conc	Reports/sets span concentration	B-25
sp field	Reports/sets item number and name in scratch pad list	B-22
span span gas	Sets zero/span valves to span mode	B-30
sr	Reports last short record stored	B-17
srec	Reports maximum number of short records	B-18
srec format	Reports/sets output format for short records (ASCII or binary)	B-19
srec layout	Reports current layout of short record data	B-20
srec mem size	Reports maximum number of short records	B-20
srec per	Reports/sets short record logging period	B-20
stream per	Reports/sets current set time interval for streaming data	B-23
stream time	Reports/sets a time stamp to streaming data or not	B-23
temp comp	Reports/sets temperature compensation on or off	B-31
time	Reports/sets current time (24-hour time)	B-34
up	Simulates pressing up pushbutton	B-26
zero zero gas	Sets zero/span valves to zero mode	B-30

Measurements

avg time

high avg time

low avg time

These commands report the averaging time in seconds when operating in single range, or averaging time used with the high and low ranges when operating in dual or auto range mode. The example that follows shows that the averaging time is 300 seconds, according to **Table B–2**.

Send: avg time
Receive: avg time 11:300 sec

set avg time *selection*

set high avg time *selection*

set low avg time *selection*

These commands set the averaging time, high and low averaging times, according to **Table B–2**. The example that follows sets the low range averaging time to 120 seconds.

Send: set low avg time 8
Receive: set low avg time 8 ok

Table B–2. Averaging Times

<i>Selection</i>	<i>Averaging Time (seconds)</i>
0	1 seconds
1	2
2	5
3	10
4	20
5	30
6	60
7	90
8	120
9	180
10	240
11	300

so2**high so2****low so2**

These commands report the measured SO₂ concentration when operating in single range, or high and low SO₂ when operating in dual or auto range mode. The example that follows shows that the SO₂ concentration is 40 ppm.

Send: so2
Receive: so2 0040E+0 ppm

conv temp

This command reports the current SO₂ converter temperature. The example that follows reports that the current converter temperature is 45 °C.

Send: conv temp
Receive: conv temp 45.0 deg C

flow

This command reports the current sample flow. The example that follows reports that the current sample flow is 0.503 liters/minute.

Send: flow
Receive: flow 0.503 1/m

internal temp

This command reports the current internal instrument temperature. The first reading is the temperature being used in instrument calculations. The second temperature is the actual temperature being measured. If temperature compensation is on, then both temperature readings are the same. If temperature compensation is off, a temperature of 30 °C is used as the default temperature even though the actual internal temperature is 27.2 °C. The example that follows shows that temperature compensation is on and that the internal temperature is 27.2 °C.

Send: internal temp
Receive: internal temp 27.2 deg C

perm gas temp

This command reports the current permeation gas temperature. The example that follows reports that the permeation gas temperature is 45 °C.

Send: perm gas temp
Receive: perm gas temp 45 deg C

pmt voltage

This command reports the current PMT voltage. The example that follows reports that the current PMT voltage is -510 volts.

Send: pmt voltage
Receive: pmt voltage -510 volts

pres

This command reports the current reaction chamber pressure. The first pressure reading is the pressure reading being used in instrument calculations. The second pressure is the actual pressure reading being measured. If pressure compensation is on, then both pressure readings are the same. If pressure compensation is off, a pressure of 760 mmHg is used as default pressure even though the actual pressure is 753.4 mmHg. The example that follows shows that the actual reaction chamber pressure is 753.4 mmHg.

Send: pres
Receive: pres 753.4 mmHg

react temp

This command reports the current reaction chamber temperature. The example that follows reports that the current reaction chamber temperature is 45.2 °C.

Send: react temp
Receive: react temp 45.2 deg C

flags

This reports 8 hexadecimal digits (or flags) that represent the status of the flash lamp, LED, pressure and temperature compensation status, gas units, gas mode, and alarms. To decode the flags, each hexadecimal digit is converted to binary as shown in the **Table B-1**. It is the binary digits that define the status of each parameter. In the example that follows, the instrument is reporting that the flash lamp is on, and the SO₂ high concentration alarm is activated.

Send: flags
Receive: flags 40028000




Figure B-1. Flags

Alarms

alarm chamber temp min

alarm chamber temp max

These commands report the chamber temperature alarm minimum and maximum value current settings. The example that follows reports that the chamber temperature alarm minimum value is 35.0 °C.

Send: alarm chamber temp min
Receive: alarm chamber temp min 35.0 deg C

set alarm chamber temp min *value*

set alarm chamber temp max *value*

These commands set the chamber temperature alarm minimum and maximum values to *value*, where *value* is a floating-point number representing chamber temperature alarm limits in degrees C. The example that follows sets the chamber temperature alarm maximum value to 55.0 °C.

Send: set alarm chamber temp max 55.0
Receive: set alarm chamber temp max 55.0 ok

alarm conc so2 min**alarm conc so2 max**

These commands report the SO₂ concentration alarm minimum and maximum values current setting. The example that follows reports that the SO₂ concentration minimum is 5.2 ppb.

Send: alarm conc so2 min
Receive: alarm conc so2 min 5.2 ppb

set alarm conc so2 min *value***set alarm conc so2 max *value***

These commands set the SO₂ concentration alarm minimum and maximum values to *value*, where *value* is a floating-point representation of the concentration alarm limits. Values must be in the ppb or µg/m³. Refer to “Entering Units in PPB” in this chapter. The example that follows sets the SO₂ concentration alarm maximum value to 80 ppm.

Send: set alarm conc so2 max 80000
Receive: set alarm conc so2 max 80000 ok

alarm converter temp min**alarm converter temp max**

These commands report the converter temperature alarm minimum and maximum value current settings. The example that follows reports that the converter temperature alarm minimum value is 205.0 °C.

Send: alarm converter temp min
Receive: alarm converter temp min 205.0 deg C

set alarm converter temp min *value***set alarm converter temp max *value***

These commands set the converter temperature alarm minimum and maximum values to *value*, where *value* is a floating-point number representing converter temperature alarm limits in degrees C. The example that follows sets the converter temperature alarm maximum value to 215.0 °C.

Send: set alarm converter temp max 215
Receive: set alarm converter temp max 215 ok

alarm internal temp min**alarm internal temp max**

These commands report the internal temperature alarm minimum and maximum value current settings. The example that follows reports that the internal temperature alarm minimum value is 15.0 °C.

Send: internal temp alarm min
Receive: internal temp alarm min 15.0 deg C

set internal temp alarm min *value***set internal temp alarm max *value***

These commands set the internal temperature alarm minimum and maximum values to *value*, where *value* is a floating-point number representing internal temperature alarm limits in degrees C. The example that follows sets the internal temperature alarm maximum value to 45.0 °C.

Send: set internal temp alarm max 45
Receive: set internal temp alarm max 45 ok

alarm pressure min**alarm pressure max**

These commands report the pressure alarm minimum and maximum value current settings. The example that follows reports that the pressure alarm minimum value is 205 mmHg.

Send: pressure alarm min
Receive: pressure alarm min 205 mmHg

set alarm pressure min *value***set alarm pressure max *value***

These commands set the pressure alarm minimum and maximum values to *value*, where *value* is a floating-point number representing pressure alarm limits in millimeters of mercury. The example that follows sets the pressure alarm maximum value to 215 mmHg.

Send: set alarm pressure max 215
Receive: set alarm pressure max 215 ok

alarm sample flow min**alarm sample flow max**

These commands report the sample flow alarm minimum and maximum value current settings. The example that follows reports that the sample flow alarm minimum value is 2 LPM.

Send: alarm sample flow min
Receive: alarm sample flow min 2 l/min

set alarm sample flow min *value***set alarm sample flow max *value***

These commands set the sample flow alarm minimum and maximum values to *value*, where *value* is a floating-point number representing sample flow alarm limits in liters per minute. The example that follows sets the sample flow alarm maximum value to 1 LPM.

Send: set alarm sample flow max 1
Receive: set alarm sample flow max 1 ok

alarm trig conc so2

This command reports the SO₂ concentration alarm trigger action for minimum alarm, current setting, to either floor or ceiling. The example that follows shows the SO₂ concentration minimum alarm trigger set to ceiling, according to **Table B-3**.

Send: alarm trig conc so2
Receive: alarm trig conc so2 1

These commands set the SO₂ concentration alarm minimum *value*, where *value* is set to either floor or ceiling, according to **Table B-3**. The example that follows sets the SO₂ concentration minimum alarm trigger to ceiling.

Send: set alarm trig conc so2 1
Receive: set alarm trig conc so2 1 ok

Table B-3. Alarm Trigger Values

<i>Value</i>	Alarm Trigger
00	Floor
01	Ceiling

Diagnostics

agc int

This command reports the current of the reference channel AGC circuit. The example that follows reports that the current AGC intensity is 90 percent.

Send: agc int
Receive: agc int 90 %

diag volt mb

This command reports the diagnostic voltage measurements on the motherboard. The sequence of voltages is: Positive 24, positive 15, positive 5, positive 3.3, and negative 3.3. Each voltage value is separated by a space.

Send: diag volt mb
Receive: diag volt mb 24.1 14.9 4.9 3.2 -3.2

diag volt mib

This command reports the diagnostic voltage measurements on the measurement interface board. The sequence of voltages is: Positive 24, positive 15, negative 15, positive 5, and positive 3.3. Each voltage value is separated by a space.

Send: diag volt mib
Receive: diag volt mib 24.1 14.9 -14.9 4.9 3.2

diag volt iob

This command reports the diagnostic voltage measurements on the I/O expansion board. The sequence of voltages is: Positive 24, positive 5, positive 3.3, and negative 3.3. Each voltage value is separated by a space.

Send: diag volt iob
Receive: diag volt iob 24.1 4.9 3.2 -3.2

lamp setpoint

This command reports the set lamp setpoint. The example that follows reports the lamp setpoint is 1000 counts.

Send: lamp setpoint
Receive: lamp setpoint 1000 counts

set lamp setpoint *value*
value = 0 < *value* < 4095

These commands set the lamp setpoint in counts. The example that follows sets the lamp setpoint to 100 counts.

Send: set lamp setpoint 100
Receive: set lamp setpoint 100 ok

lamp int

This command reports the current flash lamp intensity. The example that follows reports that the current flash lamp intensity is 3867 Hz.

Send: lamp int
Receive: lamp int 3867 Hz

lamp voltage

This command reports the current flash lamp voltage. The example that follows reports that the current flash lamp voltage is -810 volts.

Send: lamp voltage
Receive: lamp voltage -810 V

led status

led

These commands report the status of the optical test LED on or off. The example that follows reports that the optical test LED is on.

Send: lamp status
Receive: lamp status on

set led onoff

These commands set the optical test LED *on* or *off*. The example that follows turns the optical test LED off.

Send: set lamp off
Receive: set lamp off ok

Datalogging

clr records

This command will clear all long and short records that have been saved.

Send: clear records
Receive: clear records ok

set clr lrecs

set clr srecs

These commands will clear only the long records or only the short records that have been saved. The example that follows clears short records.

Send: set clr srecs
Receive: set clr srecs ok

list din

list dout

These commands report the current selection for the digital outputs in the format. Output no Index number variable name active state. The active state for digital outputs is open or closed. The active state for digital inputs is high or low.

```
Send:      list dout
Receive:    list dout
            output index variable state
            1 28 CONC ALARM closed
            2 2  LOCAL/REMOTE open
            3 4  UNITS  closed
            4 11 HI  SO2 CONC open
            7 7  SAMPLE MODE open
            8 8  SO2  MODE open
```

list lrec

list srec

list stream

list sp

These commands report the list of current selections for long record logging data, short record logging data, streaming data output, or the scratch pad (sp) list. The example that follows shows the list for streaming data output.

```
Send:      list stream
Receive:    list stream
            field index variable
            x x time
            1 1 so2
            2 18 pmtv
```

er xy

lr xy

sr xy

$x = | 0 | 1 |$: Reply termination format (see “set format *format*” command)

$y = | 0 | 1 | 2 |$: Output format (see “set errec/lrec/srec format *format*” command)

These commands report the last long or short records stored and dynamic data. In the example that follows, the command requests a long record with no checksum, in ASCII format with text. For details on how to decode the flag fields within these records, see the “flags” command.

```
Send:      lr01
Receive:    lr01
           18:09 05-12-03 flags 5c000044 S02 9658E-5 low S02 8920E-5
           Intt 28.6 Rctt 25.6 Pgast 0.00 Pres 720.3 Smpfl 0.489 PMt V
           -808 LmpV 449 Lmpi 4740E+1
```

erec

This command returns a brief description of the main operating conditions at the time the command is issued (i.e. dynamic data). The example that follows shows a typical response.

The format is defined by the current settings of “format” and “erec format” commands. For details on how to decode the flag fields within these records, see the “flags” command.

```
Send:      erec
Receive:    erec
           09:45 04-07-05 flags 5C040000 so2 0.001 4 loso2 0.001 4
           pmtv 595.331 FlshV 797.227 Intt 29.263 Rctt 44.938 PGast
           0.000 Smpfl 0.440 Pres 715.478 avgt 10 lo avgt 10 S02bkg
           6.795 S02 coef 1.000 lo S02 coef 1.000 S02range 10000.000 lo
           S02range 10000.000 Lmpi 92.000
```

lrec

srec

lrec *xxxx yy*

srec *xxxx yy*

lrec *aa:bb oo-pp-qq yy*

srec *aa:bb oo-pp-qq yy*

xxxx = the number of past records

yy = the number of records to return (1 to 10)

aa = hours (01 to 24)

bb = minutes (01 to 59)

oo = month (01 to 12)

pp = day (01 to 31)

qq = year

These commands output long or short records. The output format is determined by the “set lrec format” and “set srec format” commands. The logging time is determined by the “set lrec per” and “set srec per” commands.

In the following example, there are 740 long records currently stored in memory. When the command **lrec 100 5** is sent, the instrument counts back 100 records from the last record collected (record 740), and then

returns 5 records: 640, 641, 642, 643, and 644. For details on how to decode the flag fields within these records, see the “flags” command.

```
Send:          lrec 5
Receive:       lrec 100 5
              18:09 05-12-03 flags 5c000044 S02 9658E-5 low S02 8920E-5
              Intt 28.6 Rctt 25.6 Pgast 0.00 Pres 720.3 Smpfl 0.489 PMt V
              -808 LmpV 449 Lmpi 4740E+1
              18:10 05-12-03 flags 5c000044 S02 6923E-5 low S02 6429E-5
              Intt 28.6 Rctt 25.6 Pgast 0.00 Pres 720.3 Smpfl 0.489 PMt V
              -808 LmpV 449 Lmpi 4740E+1
              18:11 05-12-03 flags 5c000044 S02 8814E-5 low S02 9488E-5
              Intt 28.6 Rctt 25.6 Pgast 0.00 Pres 720.3 Smpfl 0.489 PMt V
              -808 LmpV 449 Lmpi 4740E+1
              18:12 05-12-03 flags 5c000044 S02 7313E-5 low S02 6997E-5
              Intt 28.6 Rctt 25.6 Pgast 0.00 Pres 720.3 Smpfl 0.489 PMt V
              -808 LmpV 449 Lmpi 4740E+1
              18:13 05-12-03 flags 5c000044 S02 8168E-5 low S02 8237E-5
              Intt 28.6 Rctt 25.6 Pgast 0.00 Pres 720.3 Smpfl 0.489 PMt V
              -808 LmpV 449 Lmpi 4740E+1
```

erec format

lrec format

srec format

These commands report the output format for long and short records, and dynamic data in various formats such as ASCII without text, ASCII with text, or binary. The example that follows shows the output format for long records is ASCII with text, according to **Table B-4**.

```
Send:          lrec format
Receive:       lrec format 01
```

set erec format *format*

set lrec format *format*

set srec format *format*

These commands set the output format for long and short records, and dynamic data, according to **Table B-4**. The example that follows sets the long record output format to ASCII with text.

```
Send:          set lrec format 1
Receive:       set lrec format 1 ok
```

Table B–4. Record Output Formats

<i>Format</i>	Output Format
0	ASCII no text
1	ASCII with text
2	binary data

erec layout

lrec layout

srec layout

These commands reports the layout (string indicating the data formats) for data that is sent out in response to the erec, lrec, srec, and related commands The example that follows shows a typical response. For details on how to interpret the strings, see “Record Layout Definition” later in this appendix.

```
Send:          lrec layout
Receive:       lrec layout %s %s %lx %f %f %f %f %f %f
               t D L fffffff
               so2 pmtv lmpv ain4 ain5 lmpi
```

lrec mem size

srec mem size

These commands report the long and short records that can be stored with the current settings and the number of blocks reserved for long and short records. To calculate the number of short records per block, add 2 to the number of records, and then divide by the number of blocks. The example that follows shows that 7 blocks were reserved for long records, and the maximum number of long records that can be stored in memory is 1426.

```
Send:          lrec mem size
Receive:       lrec mem size 1426 recs, 7 blocks
```

lrec per

srec per

These commands report the long and short records logging period. The example that follows shows that the short record logging period is 5 minutes.

```
Send:          srec per
Receive:       srec per 5 min
```

set srec per *value*

set srec per *value*

value = | 1 | 5 | 15 | 30 | 60 |

These commands set the long and short records logging period to *value* in minutes. The example that follows sets the long record logging period to 15 minutes.

Send: set lrec per 15
Receive: set lrec per 15 ok

no of lrec

no of srec

These commands report the number of long and short records stored in the long and short records memory. The example that follows shows that 50 long records have been stored in the memory.

Send: no of lrec
Receive: no of lrec 50 recs

malloc lrec

malloc srec

These commands report the currently set memory allocation for long and short records in percent of total memory.

Send: malloc lrec
Receive: malloc lrec 10%

set malloc lrec *value*

set malloc srec *value*

value = 0 to 100

These commands set the percent of memory space allocated for long and short records to *value*, where *value* is a floating-point number representing percent. The example that follows sets the memory allocation for long records to 10.

Note Issuing these commands will clear all the logging data memory. All the existing records should be retrieved using appropriate commands, if required. ▲

Send: set malloc lrec 10
Receive: set malloc lrec 10 ok

data treatment lrec**data treatment srec**

These commands report the current selection of data treatment for concentrations in the long records (lrecs) or short records (srecs). The example that follows reports the data treatment for concentrations in lrec is minimum.

Send: data treatment lrec
Receive: data treatment lrec min

set data treatment lrec *string***set data treatment srec *string***

string = | cur | avg | min | max |

These commands set the data treatment to *string*, where *string* is current, average, minimum, or maximum for the concentration values recorded in the long records (lrecs) or short records (srecs). The example that follows sets the data treatment for concentrations in lrec to minimum.

Send: set data treatment lrec min
Receive: set data treatment lrec min ok

set copy sp to lrec**set copy sp to srec****set copy sp to stream**

These commands copy the current selections in scratch pad (sp) into the long record, short record, or streaming data list. The example that follows copies the current list in scratch pad into the long records list.

Send: set copy sp to lrec
Receive: set copy sp to lrec ok

set copy lrec to sp**set copy srec to sp****set copy stream to sp**

These commands copy the current contents of the long record, short record, or streaming data list into the scratch pad (sp). These commands are useful in easy modification of current long record, short record, or streaming data lists. The example that follows copies the current list of long records into the scratch pad.

Send: set copy lrec to sp
Receive: set copy lrec to sp ok

sp field *number*

This command reports the variable *number* and name stored at index in the scratch pad list. The example that follows shows that the field 1 in the

scratch pad is set to index number 3, which is for the variable SO₂ concentration.

Send: sp field 1
Receive: sp field 1 1 so2

set sp field *number value*

number = 1-32 is the maximum number of fields in long and short record lists.

number = 1-18 is for streaming data lists.

This command sets the scratch pad field *number* (item number in scratch pad list) to *value*, where *value* is the index number of a variable in the analog out variable list. Available variables and their corresponding index numbers may be obtained using the command “list var aout”. The “set sp field” command is used to create a list of variables which can then be transferred into the long record, short record, or streaming data lists, using the “set copy sp to lrec”, “set copy sp to srec”, or “set copy sp to stream” commands.

Send: set sp field 1 34
Receive: set sp field 1 34 ok

stream per

This command reports the currently set time interval in seconds for streaming data.

Send: stream per
Receive: stream per 10

set stream per *number value*

number value = | 1 | 2 | 5 | 10 | 20 | 30 | 60 | 90 | 120 | 180 | 240 | 300 |

This command sets the time interval between two consecutive streaming data strings to *number value* in seconds. The example that follows sets the number value to 10 seconds.

Send: set stream per 10
Receive: set stream per 10 ok

stream time

This command reports if the streaming data string will have a time stamp attached to it or not, according to **Table B-5**.

Send: stream time
Receive: stream time 0

set stream time *value*

This command enables *value*, where *value* is to attach or disable time stamp to streaming data string, according to **Table B–5**. The example that follows attaches a time stamp to streaming data.

Send: set stream time 0
Receive: set stream time 0 ok

Table B–5. Stream Time Values

<i>Value</i>	Stream Time
00	Attaches time stamp to streaming data string
01	Disables time stamp to streaming data string

Calibration

set cal so2 coef

set cal high so2 coef

set cal low so2 coef

These commands will auto-calibrate SO₂ coefficients based on SO₂ span gas concentrations. The high and low commands are only available in dual and auto range mode. If the mode is incorrect, the instrument responds with “can’t, wrong settings”. The example that follows shows a successful auto-calibration of the low SO₂ coefficient.

Send: set cal low so2 coef
Receive: set cal low so2 coef ok

set cal so2 bkg

This command will auto-calibrate the SO₂ background. The example that follows shows a successful auto-calibration of the SO₂ background.

Send: set cal so2 bkg
Receive: set cal so2 bkg ok

so2 coef

coef so2

high so2 coef

low so2 coef

These commands report SO₂ coefficients in single range mode, or the high and low range coefficients in dual or auto range mode. If the mode is incorrect, the instrument responds with “can’t, wrong settings”. The example that follows reports that the SO₂ coefficient is 1.200.

Send: so2 coef
Receive: so2 coef 1.200

set so2 coef *value*

set coef so2 *value*

set high so2 coef *value*

set low so2 coef *value*

These commands set the SO₂ coefficients to user-defined values to *value*, where *value* is a floating-point representation of the coefficient. The example that follows sets the SO₂ coefficient to 1.200.

Send: set so2 coef 1.200
Receive: set so2 coef 1.200 ok

so2 bkg

This command reports the current SO₂ backgrounds. The example that follows reports that the SO₂ background is 21.4 ppb.

Send: so2 bkg
Receive: so2 bkg 21.4 ppb

set so2 bkg *value*

This command is used to set SO₂ backgrounds to user-defined values to *value*, where *value* is a floating-point representation of the background in current selected units. The example that follows sets the SO₂ background to 21.4 ppb.

Send: set so2 bkg 21.4
Receive: set so2 bkg 21.4 ok

sp conc

high sp conc

low sp conc

These commands report span concentration in single range mode, or the high and low span concentrations in dual or auto range mode. If the mode is incorrect, the instrument responds with “can’t, wrong settings”. The example that follows reports the span gas concentration in single range mode.

Send: sp conc
Receive: sp conc 1000

set sp conc *value*

set high sp conc *value*

set low sp conc *value*

These commands set the span concentrations to user-defined values to *value*, where *value* is a floating-point representation of the span concentration in current selected units. The example that follows sets the span concentration to 80 ppm in the single range mode.

```
Send:      set sp conc 80000
Receive:    set sp conc 80000 ok
```

pres cal

This command reports the pressure recorded at the time of calibration. The example that follows shows that the pressure at calibration is 85.5 mmHg.

```
Send:      pres cal
Receive:    pres cal 85.5 mmHg
```

set pres cal

This command automatically sets the current pressure as the calibration pressure. The example that follows successfully sets the calibration pressure to 120.5 mmHg.

```
Send:      set pres cal 120.5
Receive:    set pres cal 120.5 ok
```

set cal pres

This command automatically sets the current pressure as the calibration pressure. The example that follows successfully sets the calibration pressure.

```
Send:      set cal pres
Receive:    set cal pres ok
```

Keys/Display

push *button*

button = | do | down | en | enter | he | help | le | left | me | menu | ri | right |
ru | run | up | 1 | 2 | 3 | 4 |

These commands simulate pressing the front panel pushbuttons. The numbers represent the front-panel soft keys, from left to right.

```
Send:      push enter
Receive:    push enter ok
```

isc**iscreen**

This command retrieves the framebuffer data used for the display on the iSeries instrument. It is 19200 bytes in size, 2-bits per pixel, 4 pixels per byte arranged as 320 by 240 characters. The data is sent in RLE encoded form to save time in transmission. It is sent as a type '5' binary c_link response with no checksum.

The RLE encoding consists of a 0 followed by an 8-bit count of consecutive 0xFF bytes. The following 'c' code will expand the incoming data.

```
Void  unpackDisplay ( void far* tdib, unsigned char far* rlescreen )
{
    int i,j,k;
    unsigned char far *sc4bpp, *sc2bpp, *screen, *ptr;

    ptr = screen = (unsigned char far *)malloc(19200);
    //RLE decode the screen
    for (i=0; i<19200 && (ptr - screen) < 19200; i++)
    {
        *(ptr++) = *(rlescreen + i);
        if (*(rlescreen + i) == 0)
        {
            unsigned char rlecount = *(unsigned char *)(rlescreen + ++i);
            while (rlecount)
            {
                *(ptr++) = 0;
                rlecount--;
            }
        }
        else if (*(rlescreen + i) == 0xff)
        {
            unsigned char rlecount = *(unsigned char *)(rlescreen + ++i);
            while (rlecount)
            {
                *(ptr++) = 0xff;
                rlecount--;
            }
        }
    }
}
```

To convert this data into a BMP for use with windows, it needs to be turned into a 4BPP as that is the smallest windows can display. Also note that BMP files are upside down relative to this data, i.e. the top display line is the last line in the BMP.

sc**screen**

This command is meant for backward compatibility on the C series. Screen information is reported using the “iScreen” command above.

```
Send:      screen
Receive:   screen
           This is an I series
           Instrument. Screen
           Information not
           Available
```

Measurement Configuration

range
range so2
high range
low range

These commands report SO₂ range in single range mode, or the high and low ranges in dual or auto range mode. If the mode is incorrect, the instrument responds with “can’t, wrong settings”. The example that follows reports that the SO₂ full-scale range is 50 ppm, according to **Table B–6** and **Table B–7**.

```
Send:      range
Receive:   range 6: 5000E-2 ppm
```

set range *Selection*
set high range *Selection*
set low range *Selection*

These commands select the SO₂ full-scale ranges, according to **Table B–6** and **Table B–7**. The example that follows sets the SO₂ full-scale range to 100 ppm.

```
Send:      set range 3
Receive:   set range 3 ok
```

Table B–6. Standard Ranges

<i>Selection</i>	ppm	mg/m ³
0	0.05	0.2
1	0.1	0.5
2	0.2	1
3	0.5	2
4	1	5
5	2	10
6	5	20
7	10	25
8	C1	C1
9	C2	C2

<i>Selection</i>	<i>ppm</i>	<i>mg/m³</i>
10	C3	C3

Table B–7. Extended Ranges

<i>Selection</i>	<i>ppm</i>	<i>mg/m³</i>
0	0.5	2
1	1	5
2	2	10
3	5	20
4	10	50
5	20	100
6	50	200
7	100	250
8	C1	C1
9	C2	C2
10	C3	C3

custom *range*

range = | 1 | 2 | 3 |

This command reports the user-defined value of custom *range* 1, 2, or 3. The example that follows reports that custom range 1 is defined to 5.50 ppm.

Send: custom 1
Receive: custom 1 550E-2 ppm

set custom *range range value*

set custom 1 range *value*

set custom 2 range *value*

set custom 3 range *value*

These commands are used to set the maximum concentration for any of the three custom *ranges* 1, 2, or 3 to *range value*, where *value* is a floating-point number representing concentration in ppm or mg/m³. The example that follows sets the custom 1 range to 55.5 ppm.

Send: set custom 1 range 55500
Receive: set custom 1 range 55500 ok

range mode

This command reports the current range mode.

Send: range mode
Receive: range mode single

set range mode *mode*

This command sets the current range mode to single, dual, or auto. The example that follows sets the range mode to single.

Send: set range mode single
Receive: set range mode single ok

gas mode

This command reports the current mode of sample, zero, or span. The example that follows reports that the gas mode is sample.

Send: gas mode
Receive: gas mode sample

set sample**set sample gas**

This command sets the zero/span valves to the sample mode. The example that follows sets the instrument to sample mode, that is, the instrument is reading the sample gas.

Send: set sample
Receive: set sample ok

set zero**set zero gas**

This command sets the zero/span valves to the zero mode. The example that follows sets the instrument to zero mode that is, the instrument is reading the sample gas.

Send: set zero
Receive: set zero ok

set span**set span gas**

This command sets the zero/span valves to the span mode. The example that follows sets the instrument to span mode that is, the instrument is sampling span gas.

Send: set span
Receive: set span ok

gas unit

This command reports the current gas units (ppb or $\mu\text{g}/\text{m}^3$). The example reports that the gas unit is set to ppm.

Send: gas unit
Receive: gas unit ppm

set gas unit

unit = | ppm | mg/m^3 |

This command sets the gas units to ppm or mg/m^3 . The example that follows sets the gas units to mg/m^3 .

Send: set gas unit mg/m^3
Receive: set gas unit mg/m^3 ok

pres comp

This command reports whether pressure compensation is on or off. The example that follows shows that pressure compensation is on.

Send: pres comp
Receive: pres comp on

set pres comp onoff

These commands turn the pressure compensation *on* or *off*. The example that follows turns pressure compensation off.

Send: set pres comp off
Receive: set pres comp off ok

temp comp

This command reports whether temperature compensation is on or off. The example that follows shows the temperature compensation is off.

Send: temp comp
Receive: temp comp off

set temp comp onoff

These commands turn the temperature compensation *on* or *off*. The example that follows turns temperature compensation off.

Send: set temp comp off
Receive: set temp comp off ok

Hardware Configuration

contrast

This command reports the screen's level of contrast. The example that follows shows the screen contrast is 50%, according to **Table B–8**.

Send: contrast
Receive: contrast 5:50%

set contrast *level*

This command sets the screen's *level* of contrast, according to **Table B–8**. The example that follows sets the contrast level to 50%.

Send: set contrast 5
Receive: set contrast 5 ok

Table B–8. Contrast Level

<i>Level</i>	Contrast Level
0	0%
1	10%
2	20%
3	30%
4	40%
5	50%
6	60%
7	70%
8	80%
9	90%
10	100%

conv set temp

This command reports the temperature that the SO₂ converter is set to. The example that follows reports that the converter temperature is set to 50.1 °C.

Send: conv set temp
Receive: conv set temp 50.1 deg C

set conv set temp *value*

This command sets the temperature that the SO₂ converter is set to *value*, where *value* is an integer representing degrees C. The example that follows sets the converter temperature to 50.1 °C.

Send: set conv set temp 50.1
Receive: set conv set temp 50.1 ok

date

This command reports the current date. The example that follows reports the date as December 1, 2004.

Send: date
Receive: date 12-01-04

set date *mm-dd-yy*

mm = month

dd = day

yy = year

This command sets the date of the analyzer's internal clock. The example that follows sets the date to December 1, 2004.

Send: set date 12-01-04
Receive: set date 12-01-04 ok

set default params

This command sets all the parameters to their default values. This does not affect the factory-calibrated parameters.

Send: set default params
Receive: set default params ok

lamp status

This command reports the status of the flash lamp on or off. The example that follows reports the flash lamp is on.

Send: lamp status
Receive: lamp status on

set lamp *onoff*

These commands set the flash lamp *on* or *off*. The example that follows turns the flash lamp off.

Send: set lamp off
Receive: set lamp off ok

pmt status

This command reports the status of the PMT on or off. The example that follows reports that the PMT is on.

Send: pmt status
Receive: pmt status on

set pmt *onoff*

These commands set the PMT *on* or *off*. The example that follows turns the PMT off.

Send: set pmt off
Receive: set pmt off ok

save

set save params

This command stores all current parameters in FLASH memory. It is important that each time instrument parameters are changed, that this command be sent. If changes are not saved, they will be lost in the event of a power failure. The example that follows saves the parameters to FLASH memory.

Send: set save params
Receive: set save params ok

time

This command reports the current time (24-hour time). The example that follows reports that the internal time is 2:15:30 pm.

Send: time
Receive: time 14:15:30

set time *hh:mm:ss*

hh = hours

mm = minutes

ss = seconds

This command sets the internal clock (24-hour time). The example that follows sets the internal time to 2:15 pm.

Note If seconds are omitted, the seconds default to 00. ▲

Send: set time 14:15
Receive: set time 14:15 ok

Communications Configuration

addr dns

This command reports the TCP/IP address for the domain name server.

Send: addr dns
Receive: addr dns 192.168.1.1

set addr dns *address*

This command sets the dns *address*, where *address* consists of four numbers ranging from 0-255 inclusive, separated by “.”.

Send: set addr dns 192.168.1.1
Receive: set addr dns 192.168.1.1 ok

addr gw

This command reports the default TCP/IP gateway address.

Send: addr gw
Receive: addr gw 192.168.1.1

set addr gw *address*

This command sets the default gateway *address*, where *address* consists of four numbers ranging from 0-255 inclusive, separated by “.”.

Send: set addr gw 192.168.1.1
Receive: set addr gw 192.168.1.1 ok

addr ip

This command reports the IP address of the analyzer.

Send: addr ip
Receive: addr ip 192.168.1.200

set addr ip *address*

This command sets the analyzer's IP *address*, where *address* consists of four numbers ranging from 0-255 inclusive, separated by “.”.

Send: set addr ip 192.168.1.200
Receive: set addr ip 192.168.1.200 ok

addr nm

This command reports the IP netmask.

Send: addr nm
Receive: addr nm 255.255.255.0

set addr nm *address*

This command sets the nm *address*, where *address* consists of four numbers ranging from 0-255 inclusive, separated by “.”.

Send: set addr nm 255.255.255.0
Receive: set addr nm 255.255.255.0 ok

baud

This command reports the current baud rate for the serial port (RS232/RS485). The example that follows reports that the current baud rate is 9600 baud.

Send: baud
Receive: baud 9600

set baud *rate*

rate = | 1200 | 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200 |

This command sets the instrument baud *rate*. The example that follows sets the instrument’s baud rate to 9600.

Note After the command is sent, the baud rate of the sending device must be changed to agree with the instrument. ▲

Send: set baud 9600
Receive: set baud 9600 ok

dhcp

This command reports the current state of use of DHCP on or off. DHCP is used to assign an IP address to the analyzer automatically. The example that follows shows that DHCP is on.

Send: dhcp
Receive: dhcp on

set dhcp *onoff*

These commands enables and disables the DHCP service by either *on* or *off*. Changes to this parameter will only take effect when the analyzer is powered up. The example that follows sets the DHCP service on.

Note When DHCP is set to on, the user-supplied addr gw, addr dns, addr ip, and addr nm parameters are not used. ▲

Send: set dhcp on
Receive: set dhcp on ok

format

This command reports the current reply termination format. The example that follows shows that the reply format is 00, which means reply with no checksum, according to **Table B-9**.

```
Send:          format
Receive:       format 00
```

set format *format*

This command sets the reply termination *format*, where *format* is set according to **Table B-9**. The example that follows sets the reply termination format to checksum.

```
Send:          set format 01
Receive:       set format 01 ok
```

Table B-9. Reply Termination Formats

<i>Format</i>	Reply Termination
00	<CR>
01	<NL> sum xxxx <CR>

where xxxx = 4 hexadecimal digits that represent the sum of all the characters (bytes) in the message

host name

This command reports the host name string.

```
Send:          host name
Receive:       host name analyzer01
```

set host name *string*

This command sets the host name *string*, where *string* is 1-13 alphanumeric characters.

```
Send:          set host name analyzer01
Receive:       set host name analyzer01 ok
```

instr name

This command reports the instrument name.

```
Send:          instr name
Receive:       instr name
               S02 Analyzer
               S02 Analyzer
```

instrument id

This command reports the instrument id.

Send: instrument id
Receive: instrument id 12

set instrument id *value*

This command sets the instrument id to *value*, where *value* is a decimal number between 0 and 127 inclusive.

Note Sending this command via RS-232 or RS-485 will require the host to use the new id for subsequent commands. ▲

Send: set instrument id 12
Receive: set instrument id 12 ok

mode

This command reports what operating mode the instrument is in: local, service, or remote. The example that follows shows that the instrument is in the remote mode.

Send: mode
Receive: mode remote

set mode local**set mode remote**

These commands set the instrument to local or remote mode. The example that follows sets the instrument to the local mode.

Send: set mode local
Receive: set mode local ok

program no

This command reports the analyzer's model information and program version number, which will be dependant on the current version.

Send: program no
Receive: program no iSeries 43i 01.01.10.003

set layout ack

This command disables the stale layout/layout change indicator ('*') that is attached to each response if the layout has changed.

Send: set layout ack
Receive: set layout ack ok

I/O Configuration

analog iout range *channel*

This command reports the analog current output range setting for *channels*, where *channel* must be between 1 and 6, inclusive. The example that follows reports current output channel 4 to the 4-20 mA range, according to **Table B-10**. This command responds with “feature not enabled” if the I/O expansion board is not detected.

```
Send:      analog iout range 4
Receive:   analog iout range 4 2
```

set analog iout range *channel range*

This command sets analog current output *channel* to the *channel range* where *channel* is between 1 and 6 inclusive, and *range* is set according to **Table B-10**. The example that follows sets current output channel 4 to the 0-20 mA range. This command responds with “feature not enabled” if the I/O expansion board is not detected.

```
Send:      set analog iout range 4 1
Receive:   set analog iout range 4 1 ok
```

Table B-10. Analog Current Output Range Values

<i>Range</i>	Output Range
1	0-20 mA
2	4-20 mA
0 [cannot be set to this, but may report]	Undefined

analog vin *channel*

This command retrieves the analog voltage input *channel* data, both the calculated value and the actual voltage. In the example that follows, the “calculated” value of channel 1 is 75.325 degrees F, volts are 2.796. This command responds with “feature not enabled” if the I/O expansion board is not detected.

```
Send:      analog vin 1
Receive:   analog vin 1 75.325 2.796
```

analog vout range *channel*

This command reports the analog voltage output *channel* range, where *channel* is between 1 and 6 inclusive, according to Table B-11.

```
Send:      analog vout range 2
Receive:   analog vout range 2 3
```

set analog vout range *channel range*

This command sets analog voltage output *channel* to the range, where *channel* is between 1 and 6 inclusive, and *range* is set according to **Table B–11**. The example that follows sets channel 2 to the 0-10 V range.

Send: set analog vout range 2 3
Receive: set analog vout range 2 3 ok

Table B–11. Analog Voltage Output Range Values

<i>Range</i>	Output Range
1	0-1 V
2	0-100 mV
3	0-10 V
4	0-5 V
0 [cannot be set to this, but may report]	Undefined

dig in

This command reports the status of the digital inputs as a 4-digit hexadecimal string with the most significant bit (MSB) being input 16.

Send: dig in
Receive: dig in 0xff7f

din *channel*

This command reports the action assigned to input *channel* and the corresponding active state. The example that follows reports the input 1 to be assigned an index number 3 corresponding to action of SO₂ mode with the active state being high.

Send: din 1
Receive: din 1 3 SO2 MODE high

set din *channel index state*

This command assigns digital input *channel* (1-16) to activate the action indicated by *index* (1-35), when the input transitions to the designated *state* (high or low). Use “list din var” command to obtain the list of supported *index* values and corresponding actions.

Send: set din 5 9 high
Receive: set din 1 9 high ok

dout *channel*

This command reports the index number and output variable and the active state assigned to output *channel*. The example that follows reports the input 4 to be assigned an index number 11 corresponding to general alarm with the active state being open.

```
Send:      dout 4
Receive:   dout 4 11 GEN ALARM open
```

set dout *channel index state*

This command assigns digital output *channel* to be assigned to the action associated with *index*, and assigns it an active state of *state* (open or closed).

```
Send:      set dout 4 11 open
Receive:   set dout 4 11 open ok
```

dtoa *channel*

This reports the outputs of the 6 or 12 Digital to Analog converters, according to **Table B–12**. The example that follows shows that the D/A #1 is 97.7% full-scale.

```
Send:      dtoa 1
Receive:   dtoa 1 97.7%
```

Note All channel ranges are user definable. If any customization has been made to the analog output configuration, the default selections may not apply. ▲

Table B–12. Default Output Assignment

D to A	Function	Single Range	Dual Range	Autorange
1	Voltage Output	Low SO ₂	Low SO ₂	High/Low SO ₂
2	Voltage Output	Low SO ₂	High SO ₂	Range Status
3	Voltage Output	Not Assigned	Not Assigned	Not Assigned
4	Voltage Output	Not Assigned	Not Assigned	Not Assigned
5	Voltage Output	Not Assigned	Not Assigned	Not Assigned
6	Voltage Output	Not Assigned	Not Assigned	Not Assigned
7	Current Output	Low SO ₂	Low SO ₂	High/Low SO ₂
8	Current Output	Low SO ₂	High SO ₂	Range Status
9	Current Output	Not Assigned	Not Assigned	Not Assigned
10	Current Output	Not Assigned	Not Assigned	Not Assigned
11	Current Output	Not Assigned	Not Assigned	Not Assigned

D to A	Function	Single Range	Dual Range	Autorange
12	Current Output	Not Assigned	Not Assigned	Not Assigned

list var aout

list var dout

list var din

These commands report the list of index numbers, and the variables (associated with that index number) available for selection in the current mode (determined by single/dual/auto, gas mode) for analog output, digital output and digital inputs. The index number is used to insert the variable in a field location in a list using “set sp *field index*”. The example that follows reports the list of analog output, index numbers, and variables.

```
Send:      list var aout
Receive:   list var aout
           index variable
           0 none
           1 so2
           11 intt
           12 rctt
           16 pres
           17 smp1fl
           18 pmtv
           19 lmpv
           20 lmpi
           21 ain1
           22 ain2
           23 ain3
           24 ain4
           25 ain5
           26 ain6
           27 ain7
           28 ain8
```

relay stat

This command reports the current relay logic normally “open” or normally “closed,” if all the relays are set to same state, that is all open or all closed. The example that follows shows that the status when all the relays logic is set to normally “open”.

```
Send:      relay stat
Receive:   relay stat open
```

Note If individual relays have been assigned different logic then the response would be a 4-digit hexadecimal string with the least significant byte (LSB) being relay no 1. ▲

For example:

Receive: relay stat 0x0001 (indicates relay no 1 is set to normally open logic, all others are normally closed)
Receive: relay stat 0x0005 (indicates relay no 1 and 3 are set to be normally open logic, all others are normally closed)

set relay open

set relay open *value*

set relay closed

set relay closed *value*

These commands set the relay logic to normally open or closed for relay number *value*, where *value* is the relay between 1 and 16. The example that follows sets the relay no 1 logic to normally open.

Note If the command is sent without an appended relay number then all the relays are assigned the set logic of normally open/closed. ▲

Send: set relay open 1
Receive: set relay open 1 ok

Record Layout Definition

The Erec, Lrec Srec layouts contain the following:

- A format specifier for parsing ASCII responses
- A format specifier for parsing binary responses,

In addition to these the Erec Layout contains

- A format specifier for producing the front-panel displays.

In operation, values are read in using either the ASCII or binary format specifiers and converted to uniform internal representations (32-bit floats or 32-bit integers). These values are converted into text for display on the screen using the format specifier for the front-panel display. Normally, the specifier used to parse a particular datum from the input stream will be strongly related to the specifier used to display it (e.g., all of the floating point inputs will be displayed with an 'f' output specifier, and all of the integer inputs will be displayed with a 'd' specifier).

Format Specifier for ASCII Responses

The first line of the Layout response is the scanf-like parameter list for parsing the fields from an ASCII ERec response. Parameters are separated by spaces and the line is terminated by a \n (the normal line separator character). Valid fields are:

%s - parse a string
%d - parse a decimal number

%ld - parse a long (32-bit) decimal number
%f - parse a floating point number
%x - parse a hexadecimal number
%lx - parse a long (32-bit) hex number
%* - ignore the field

Note Signed versus unsigned for the integer values does not matter; it is handled automatically. ▲

Format Specifier for Binary Responses

The second line of the Layout response is the binary parameter list for parsing the fields from a binary response. Parameters **MUST** be separated by spaces, and the line is terminated by a '\n'. Valid fields are:

t - parse a time specifier (2 bytes)
D - parse a date specifier (3 bytes)
i - ignore one 8-bit character (1 byte)
e - parse a 24-bit floating point number (3 bytes: n/x)
E - parse a 24-bit floating point number (3 bytes: N/x)
f - parse a 32-bit floating point number (4 bytes)
c - parse an 8-bit signed number (1 byte)
C - parse an 8-bit unsigned number (1 byte)
n - parse a 16-bit signed number (2 bytes)
N - parse a 16-bit unsigned number (2 bytes)
m - parse a 24-bit signed number (3 bytes)
M - parse a 24-bit unsigned number (3 bytes)
l - parse a 32-bit signed number (4 bytes)
L - parse a 32-bit unsigned number (4 bytes)

There is an optional single digit *d* which may follow any of the numeric fields which indicates that after the field has been parsed out, the resulting value is to be divided by 10^d . Thus the 16-bit field 0xFFC6 would be interpreted with the format specifier 'n3' as the number -0.058.

Format Specifier for Front-Panel Layout

The subsequent lines in the ERec Layout response describe the appearance of the full panel. The full instrument panel as it appears on the screen has two columns of lines. Each line is composed of three major components: (1) a text field, (2) a value field, and (3) a button. None of these three components is required. The text field contains statically displayed text.

The value field displays values which are parsed out of the response to a DATA/ERec command. It also displays, though background changes, alarm status. The button, when pressed, triggers input from either a dialog box or a selection list. There are five kinds of buttons, B, I, L, T, and N.

Each line in the layout string corresponds to one line on the display. The layout string describes each of the three major fields as well as translation mechanisms and corresponding commands.

Text	The first field in the layout string is the text. It is delimited by a ':'. The string up to the first ':' will be read and inserted in the text field of the line.
Value String	This is followed by a possible string, enclosed in quotes. This is used to place a string into the value field.
Value Source	<p>The value source, which is the item (or word) number in the DATA/ERec response, appears next. This is followed by an optional bitfield designator. The datum identified by the value source can be printed as a string 's', hexadecimal 'x', decimal 'd', or floating point 'f', or binary 'b' number. Typically, bitfield extractions are only done for decimal or hexadecimal numbers.</p> <p>Floating-point numbers can be followed with an optional precision specifier which will be used as an argument to printf's %f format (e.g., a field of '4' would be translated into the printf command of '%.3f'). Alternately, the special character '*' can precede the precision specifier; this causes an indirection on the precision specifier (which now becomes a field number).</p> <p>This is useful when formatting, for example, numbers which have varying precision depending on the mode of the instrument.</p> <p>Binary numbers can also have an optional precision specifier which is used to determine how many bits to print. For example, the specifier 'b4' will print the lowest four bits of the parsed number.</p> <p>There are serious restrictions on where an 's' field may appear: currently sources 1 and 2 must be 's', and no others may be 's'.</p>
Alarm Information	The value source is followed by optional alarm information, indicated by a commercial at sign '@' with a source indicator and a starting bit indicator. All alarm information is presumed to be two bits long (low and high). The bitfield extraction is performed on the integer part of the source. Typical alarm information would appear as '@6.4'.
Translation Table	Then, there appears an optional translation table within braces '{}'. This is a string of words separated by spaces. An example translation table would be '{Code_0 Code_1 Code_2 Code_3}'. The value, once extracted is used as a zero-based index into the translation table to determine the string to display.

Selection Table Then there appears an optional selection table within parentheses '(...)'. This is a string of numbers separated by spaces '(0 1)'. The selection table lists the translation table entries which the user may select from when setting the parameter. This is not necessarily the same as the entries which may be displayed.

Button Designator Then there appears an optional button designator. This will be one of 'B', 'I', 'L', 'T', or 'N'.

B- Indicates a button which pops up an input dialog prompting the user for a new value using the designated input format. The input format is specified from the 'B' through the subsequent semicolon.

I—Indicates a button which pops up a selection list with input translation. That is, the values read are translated before they are compared to the selection list options.

L—Indicates a button which pops up a selection list without any translation. The output value is number of the selected option.

T—Indicates a button which pops up a selection list with output translation. The number of the option selected is used as an index into the translation table to generate an output string.

N—Indicates a button which only sends the subsequent command to the instrument. No user-prompting happens.

Examples Some examples ('\n' is the C syntax for an end-of-line character):

'Concentrations\n'

This is a single text-only line.

'\n'

This is a single blank line.

' NO:3s\n'

This is a line which appears slightly indented. The text field is 'NO', the value is taken from the third element of the data response, and interpreted as a string.

```
' NO:18sBd.ddd;set no coef %s\n'
```

This is a line which also appears slightly indented. The next field is also 'NO', but the value is taken from the eighteenth element of the data response, again interpreted as a string. A button appears on this line which, when pressed, pops up an input dialog which will state "Please enter a new value for NO using a d.ddd format." The string entered by the user is used to construct the output command. If the user enters, for example, '1.234', the constructed command will be 'set no coef 1.234'.

```
' NO:21f{Code_0 Code_1 Code_2 Code_3 Code_4 Code_5 Code_6 Code_7  
Code_8 Code_9 Code_10 Code_11}Lset range no %d\n'
```

This is a line which appears slightly indented, the title is again 'NO', and the value the twenty-first element of the data response, interpreted as a floating-point number. There is a no-translation button which creates a selection list of twelve "Code nn" options. The number of the user selection is used to create the output command.

```
'Mode:6.12-13x{local remote service service}(0 1)Tset mode %s\n'
```

This is a line which has a title of 'Mode', and value taken from the sixth field of the data response. There is a bitfield extraction of bits 12 through 13 from the source (the value type is not important here because the value is being translated to an output string). Once the bits have been extracted, they are shifted down to the bit-zero position. Thus, the possible values of this example will be 0 through 3. The translation list shows the words which correspond to each input value, the zeroth value appearing first (0 -> local, 1 -> remote, etc.). The selection list shows that only the first two values, in this case, are to be shown to the user when the button is pressed. The 'T' button indicates full translation, input code to string, and user selection number to output string.

```
'\xC'
```

This is a line that starts a new column (the \xC or ^L),

```
' Comp:6.11x{off on}Tset temp comp %s\n'
```

This shows that the bitfield end (the second part of a bitfield specification) is optional. The bitfield will be one bit long, starting in this case at the eleventh bit.

```
'Background:7f*8Bd.ddd;set o3 bkg %s\n'
```

This shows the use of indirect precision specifiers for floating point displays. The background value is taken from the 7th element, and the precision specifier is taken from the 8th. If the asterisk were not present, it would indicate instead that 8 digits after the decimal point should be displayed.

Appendix C

MODBUS Protocol

This appendix provides a description of the MODBUS Protocol Interface and is supported both over RS-232/485 (RTU protocol) as well as TCP/IP over Ethernet.

The MODBUS Commands that are implemented are explained in detail in this document. The MODBUS protocol support for the iSeries enables the user to perform the functions of reading the various concentrations and other analog values or variables, read the status of the digital outputs of the analyzer, and to trigger or simulate the activation of a digital input to the instrument. This is achieved by using the supported MODBUS commands listed below.

For details of the Model 43*i* MODBUS Protocol specification, see the following topics:

- “Serial Communication Parameters” on page C-2.
- “TCP Communication Parameters” on page C-2.
- “Application Data Unit Definition” on page C-2.
- “Function Codes” on page C-3.
- “MODBUS Commands Supported” on page C-8.

Additional information on the MODBUS protocol can be obtained at <http://www.modbus.org>. References are from MODBUS Application Protocol Specification V1.1a MODBUS-IDA June 4, 2004.

Serial Communication Parameters

The following are the communication parameters that are used to configure the serial port of the *i*Series to support MODBUS RTU protocol.

Number of Data bits : 8

Number of Stop bits : 1

Parity : None

Data rate : from 1200-115200 Baud (9600 is default)

TCP Communication Parameters

iSeries Instruments support the MODBUS/TCP protocol. The register definition is the same as for the serial interface.

TCP connection port for MODBUS: 502

Application Data Unit Definition

Here are the MODBUS ADU (Application Data Unit) formats over serial and TCP/IP:

Serial:	Slave Address	Function Code	Data	Error Check
TCP/IP:	MBAP Header	Function Code	Data	

Slave Address

The MODBUS slave address is a single byte in length. This is the same as the instrument ID used for C-Link commands and can be between 1 and 127 decimal (i.e. 0x01 hex to 0x7F hex). This address is only used for MODBUS RTU over serial connections.

Note Device ID ‘0’ used for broadcast MODBUS commands, is not supported. Device IDs 128 through 247 (i.e. 0x80 hex to 0xF7 hex) are not supported because of limitations imposed by C-Link. ▲

MBAP Header

In MODBUS over TCP/IP, a MODBUS Application Protocol Header (MBAP) is used to identify the message. This header consists of the following components:

Transaction Identifier	2 Bytes	0x0000 to 0xFFFF (Passed back in response)
Protocol Identifier	2 Bytes	0x00 (MODBUS protocol)
Length	2 Bytes	0x0000 to 0xFFFF (Number of following bytes)
Unit Identifier	1 Byte	0x00 to 0xFF (Passed back in response)

A Slave address is not required in MODBUS over TCP/IP because the higher-level protocols include device addressing. The unit identifier is not used by the instrument.

Function Code The function code is a single byte in length. The following function codes are supported by the instrument:

Read Coils	:	0x01
Read Inputs	:	0x02
Read Holding Registers	:	0x03
Read Input Registers	:	0x04
Force (Write) Single Coil	:	0x05
Read Exception Status	:	0x07

If a function code is received that is not in this list, and invalid function exception is returned.

Data The data field varies depending on the function. For more description of these data fields, see “Function Codes” below.

Error Check In MODBUS over Serial an error check is included in the message. This is not necessary in MODBUS over TCP/IP because the higher-level protocols ensure error-free transmission. The error check is a two-byte (16-bit) CRC value.

Function Codes This section describes the various function codes that are supported by the Model 43i.

**(0x01/0x02) Read Coils /
Read Inputs**

Read Coils/Inputs reads the status of the digital outputs (relays) in the instrument. Issuing either of these function codes will generate the same response.

These requests specify the starting address, i.e. the address of the first output specified, and the number of outputs. The outputs are addressed starting at zero. Therefore, outputs numbered 1–16 are addressed as 0–15.

The outputs in the response message are packed as one per bit of the data field. Status is indicated as 1 = Active (on) and 0 = Inactive (off). The LSB of the first data byte contains the output addressed in the query. The other outputs follow toward the high order end of this byte, and from low order to high order in subsequent bytes. If the returned output quantity is not a multiple of eight, the remaining bits in the final data byte will be padded with zeros (toward the high order end of the byte). The Byte Count field specifies the quantity of complete bytes of data.

Note The values reported may not reflect the state of the actual relays in the instrument, as the user may program these outputs for either active closed or open. ▲

Request

Function code	1 Byte	0x01 or 0x02
Starting Address	2 Bytes	0x0000 to maximum allowed by instrument
Quantity of outputs	2 Bytes	1 to maximum allowed by instrument
Unit Identifier	1 Byte	0x00 to 0xFF (Passed back in response)

Response

Function code	1 Byte	0x01 or 0x02
Byte count	1 Byte	N*
Output Status	n Byte	N = N or N+1

*N = Quantity of Outputs / 8, if the remainder not equal to zero, then N=N+1

Error Response

Function code	1 Byte	0x01 or 0x02
Exception code	1 Byte	01=Illegal Function, 02=Illegal Address, 03=Illegal Data, 04=Slave Device Failure

Here is an example of a request and response to read outputs 2–15:

Request

<i>Field Name</i>	<i>(Hex)</i>
Function	0x01
Starting Address Hi	0x00
Starting Address Lo	0x02
Quantity of Outputs Hi	0x00
Quantity of Outputs Lo	0x0D

Response

<i>Field Name</i>	<i>(Hex)</i>
Function	0x01

Byte Count	0x03
Output Status 2–10	0xCD
Output Status 11–15	0x0A

The status of outputs 2–10 is shown as the byte value 0xCD, or binary 1100 1101. Output 10 is the MSB of this byte, and output 2 is the LSB. By convention, bits within a byte are shown with the MSB to the left, and the LSB to the right. Thus the outputs in the first byte are ‘10 through 2’, from left to right. In the last data byte, the status of outputs 15–11 is shown as the byte value 0x0A, or binary 0000 1010. Output 15 is in the fifth bit position from the left, and output 11 is the LSB of this byte. The four remaining high order bits are zero filled.

(0x03/0x04) Read Holding Registers / Read Input Registers

Read holding/input registers reads the measurement data from the instrument. Issuing either of these function codes will generate the same response. These functions read the contents of one or more contiguous registers.

These registers are 16 bits each and are organized as shown below. All of the values are reported as 32-bit IEEE standard 754 floating point format. This uses 2 sequential registers, least significant 16 bits first.

The request specifies the starting register address and the number of registers. Registers are addressed starting at zero. Therefore registers numbered 1–16 are addressed as 0–15. The register data in the response message are packed as two bytes per register, with the binary contents right justified within each byte. For each register, the first byte contains the high order bits and the second contains the low order bits.

The status of outputs 2–10 is shown as the byte value 0xCD, or binary 1100 1101. Output 10 is the MSB of this byte, and output 2 is the LSB. By convention, bits within a byte are shown with the MSB to the left, and the LSB to the right. Thus, the outputs in the first byte are ‘10 through 2’, from left to right. In the last data byte, the status of outputs 15–11 is shown as the byte value 0x0A, or binary 0000 1010. Output 15 is in the fifth bit position from the left, and output 11 is the LSB of this byte. The four remaining high order bits are zero filled.

(0x03/0x04) Read Holding Registers / Read Input Registers

Read holding / input registers reads the measurement data from the instrument. Issuing either of these function codes will generate the same response. These functions read the contents of one or more contiguous registers.

These registers are 16 bits each and are organized as shown below. All of the values are reported as 32-bit IEEE standard 754 floating point format. This uses 2 sequential registers, least significant 16 bits first.

The request specifies the starting register address and the number of registers. Registers are addressed starting at zero. Therefore, registers numbered 1–16 are addressed as 0–15. The register data in the response message are packed as two bytes per register, with the binary contents right justified within each byte. For each register, the first byte contains the high order bits and the second contains the low order bits.

Request

Function code	1 Byte	0x03 or 0x04
Starting Address	2 Bytes	0x0000 to maximum allowed by instrument
Quantity of Registers	2 Bytes	1 to maximum allowed by instrument

Response

Function code	1 Byte	0x03 or 0x04
Byte count	1 Byte	2 x N*
Register value	N* x 2 Bytes	N = N or N+1

*N = Quantity of Registers

Error Response

Function code	1 Byte	Function code + 0x80
Exception code	1 Byte	01=Illegal Function, 02=Illegal Address, 03=Illegal Data, 04=Slave Device Failure

Here is an example of a request and response to read registers 10–13:

Request

<i>Field Name</i>	<i>(Hex)</i>
Function	0x03
Starting Address Hi	0x00
Starting Address Lo	0x09
No. of Registers Hi	0x00
No. of Registers Lo	0x04

Response

<i>Field Name</i>	<i>(Hex)</i>
-------------------	--------------

Function	0x03
Byte Count	0x06
Register value Hi (10)	0x02
Register value Lo (10)	0x2B
Register value Hi (11)	0x00
Register value Lo (11)	0x00
Register value Hi (12)	0x00
Register value Lo (12)	0x64
Register value Hi (13)	0x00
Register value Lo (13)	0x64

The contents of register 10 are shown as the two byte values of 0x02 0x2B. Then contents of registers 11–13 are 0x00 0x00, 0x00 0x64 and 0x00 0x64 respectively.

(0x05) Force (Write) Single Coil

The force (write) single coil function simulates the activation of the digital inputs in the instrument, which triggers the respective action.

This function code is used to set a single action to either ON or OFF. The request specifies the address of the action to be forced. Actions are addressed starting at zero. Therefore, action number 1 is addressed as 0. The requested ON/OFF state is specified by a constant in the request data field. A value of 0xFF00 requests the action to be ON. A value of 0x0000 requests it to be OFF. All other values are illegal and will not affect the output. The normal response is an echo of the request, returned after the state has been written.

Request

Function code	1 Byte	0x05
Starting Address	2 Bytes	0x0000 to maximum allowed by instrument
Output Value	2 Bytes	0x0000 or 0xFF00

Response

Function code	1 Byte	0x05
Starting Address	2 Bytes	0x0000 to maximum allowed by instrument
Output Value	2 Bytes	0x0000 or 0xFF00

Error Response

Function code	1 Byte	Function code + 0x80
Exception code	1 Byte	01=Illegal Function, 02=Illegal Address, 03=Illegal Data, 04=Slave Device Failure

Here is an example of a request to write Coil 5 ON:

Request

<i>Field Name</i>	<i>(Hex)</i>
Function	05
Output Address Hi	00
Output Address Lo	05
Output Value Hi	FF
Output Value Lo	00

Response

<i>Field Name</i>	<i>(Hex)</i>
Function	05
Output Address Hi	00
Output Address Lo	05
Output Value Hi	FF
Output Value Lo	00

MODBUS Commands
Supported

Tables C1 through C3 list the MODBUS commands supported for the Model 43i.

Table C–1. Read Registers for 43i

Register Number	Variable
40001&40002	SO2 CONC
40003&40004	NOT USED
40005&40006	NOT USED
40007&40008	LO SO2 CONC (Dual/Auto Range mode)
40009&40010	NOT USED
40011&40012	NOT USED
40013&40014	HI SO2 CONC (Dual/Auto Range mode)

Register Number	Variable
40015&40016	NOT USED
40017&40018	NOT USED
40019&40020	RANGE (SO ₂) (Dual/Auto Range mode)
40021&40022	INTERNAL TEMP
40023&40024	CHAMBER TEMP
40025&40026	NOT USED
40027&40028	PERM OVEN GAS TEMPERATURE
40029&40030	PERM OVEN HEATER TEMPERATURE
40031&40032	CHAMBER PRESSURE
40033&40034	SAMPLE FLOW
40035&40036	PMT VOLTS
40037&40038	FLASH VOLTS
40039&40040	FLASH REF
40041&40042	ANALOG IN 1 (I/O Expansion Board installed)
40043&40044	ANALOG IN 2 (I/O Expansion Board installed)
40045&40046	ANALOG IN 3 (I/O Expansion Board installed)
40047&40048	ANALOG IN 4 (I/O Expansion Board installed)
40049&40050	ANALOG IN 5 (I/O Expansion Board installed)
40051&40052	ANALOG IN 6 (I/O Expansion Board installed)
40053&40054	ANALOG IN 7 (I/O Expansion Board installed)
40055&40056	ANALOG IN 8 (I/O Expansion Board installed)

Table C–2. Write Coils for 43*i*

Coil Number	Action Triggered
101	ZERO MODE
102	SPAN MODE
103	SO ₂ MODE
104	CS MODE
105	SET BACKGROUND
106	CAL TO LOW SPAN
107	AOUTS TO ZERO
108	AOUTS TO FS
109	CAL TO HIGH SPAN

Table C–3. Read Coils for 43*i*

Coil Number	Status
1	AUTORANGE
2	LOCAL/REMOTE
3	SERVICE
4	UNITS (0 = ppm or ppb; 1 = mg/m ³ or µg/m ³)
5	ZERO MODE
6	SPAN MODE
7	SAMPLE MODE
8	NOT USED
9	NOT USED
10	GEN ALARM
11	SO ₂ CONC MAX ALARM
12	SO ₂ CONC MIN ALARM
13	NOT USED
14	NOT USED
15	NOT USED
16	NOT USED
17	INTERNAL TEMP ALARM
18	CHAMB TEMP ALARM
19	CONVERTER TEMP
20	PERM GAS TEMP
21	PRESSURE ALARM
22	SAMPLE FLOW ALARM
23	FLASH REF ALARM
24	FLASH VOLTAGE ALARM
25	MOTHERBOARD STATUS ALARM
26	MEASUREMENT INTERFACE BOARD STATUS ALARM
27	I/O EXP BD STATUS ALARM
28	CONC ALARM
29	PURGE MODE
30	ZERO CHK/CAL ALARM (Zero/Span Option)
31	SPAN CHK/CAL ALARM (Zero/Span Option)

Appendix D

Geysitech (Bayern-Hessen) Protocol

This appendix provides a description of the Geysitech (Bayern-Hessen or BH) Protocol Interface and is supported both over RS-232/485 as well as TCP/IP over Ethernet.

The Geysitech Commands that are implemented are explained in detail in this document. The Geysitech protocol support for the *i*Series enables the user to perform the functions of reading the various concentrations and to trigger the instrument to be in sample/zero/span mode if valid for that instrument. This is achieved by using the supported Geysitech commands listed below.

For details of the Model 43*i* Geysitech Protocol specification, see the following topics:

[“Serial Communication Parameters”](#) on page D-1

[“TCP Communication Parameters”](#) on page D-2

[“Instrument Address”](#) on page D-2

[“Abbreviations Used”](#) on page D-2

[“Basic Command Structure”](#) on page D-2

[“Block Checksum”](#) on page D-3

[“Geysitech Commands”](#) on page D-3

Serial Communication Parameters

The following are the communication parameters that are used to configure the serial port of the *i*Series to support Geysitech protocol.

Number of Data bits	: 8
Number of Stop bits	: 1
Parity	: None
Data rate	: from 1200-115200 Baud (9600 is default)

TCP Communication Parameters

iSeries Instruments support the Geysitech/TCP protocol over TCP/IP. The register definition is the same as for the serial interface.

TCP connection port for Geysitech: 9882

Instrument Address

The Geysitech instrument address has a value between 0 and 127 and is represented by 3 digit ASCII number with leading zeros or leading spaces if required (e.g. Instrument address of 1 is represented as 001 or <SP><SP>1)

The instrument Address is the same as the Instrument ID used for C-Link and MODBUS commands. This can be set via the front panel.

The Instrument Address is represented by <address> in the examples throughout this document.

Note Device IDs 128 through 247 are not supported because of limitations imposed by the C-Link protocol. ▲

Abbreviations Used

The following is a list of abbreviations used in this document:

<CR> is abbreviation for Carriage Return (ASCII code 0x0D)

<STX> is abbreviation for Start of Text (ASCII code 0x02)

<ETX> is abbreviation for End of Text (ASCII code 0x03)

<SP> is abbreviation for space (ASCII code 0x20)

Basic Command Structure

The following is the basic structure of a Geysitech command:

<STX>Command text<ETX><BCC>

OR

<STX>Command text<CR>

Each Command is framed by control characters, <STX> at the start and terminated with either <ETX> or <CR>.

If a command is terminated with <ETX> then additional two characters <BCC> is attached after <ETX>, this is the block checksum.

Block Checksum <BCC>

The block checksum is calculated beginning with a seed value of 00000000, binary (0x00), and bitwise exclusive ORing with each of the characters of the command string (or response) including the framing characters <STX> and <ETX>. The checksum works as an error check. The command terminator determines the presence or absence of <BCC>.

If a command is terminated by <ETX> then the next two characters are the checksum, if the command is terminated with <CR> no checksum is attached

The block checksum is represented by two characters, which represent a 2 digit hex number (1byte). (e.g. 1 byte 0xAB hex checksum will be represented by the two characters 'A' & 'B')

The checksum is referred to as <BCC> throughout this document.

Geysitech Commands

The following commands are supported by the Geysitech protocol:

- Instrument Control Command (ST)
- Data Sampling/Data Query Command (DA)

Instrument Control Command (ST)

There are three control commands supported by the Geysitech protocol.

This <control command> is a single letter, which triggers an action in the instrument. These commands are active only when service mode is inactive and the zero/span option is present.

Command 'N' switches the instrument gas mode to Zero mode.

Command 'K' switches the instrument gas mode to Span mode.

Command 'M' switches the instrument gas mode to Sample mode.

The following are the different acceptable formats of the ST command:

<STX>ST<address><control command><ETX><BCC>

OR

<STX>ST<address><control command><CR>

OR

<STX>ST<address><SP><control command><CR>

OR

<STX>ST<address><SP><control command><ETX><BCC>

The <address> is optional, which means it can be left out completely. The <address> if present must match the Instrument Address. Additional space can be present after the <address>.

If the received command does not satisfy the above formats or if the <address> does not match the Instrument Address the command is ignored.

This is a sample command to switch the instrument to zero mode, instrument id 5:

<STX>ST005<SP>N<CR>

Data Sampling/Data Query Command (DA)

This command DA initiates a data transfer from the instrument. The instrument responds with measurement data, which depends on the range mode and is listed in “Measurements reported in response to DA command” below.

The command structure for a data query command is as follows:

<STX>DA<address><ETX><BCC>

The <address> is optional, which means it can be left out completely. The <address> if present must match the Instrument Address. Additional space can be present after the <address>.

If the <address> is left out then no space is allowed in the query string.

A command with no address is also a valid command.

The following are the different acceptable formats of the DA command with Instrument Address 5:

<STX>DA<CR>

<STX>DA005<CR>

<STX>DA<SP><SP>5<ETX><BCC>

<STX>DA<ETX><BCC>

The data query string is valid and will be answered with data transmission only if the command starts with <STX> which is followed by the characters DA, and the <address> (if present) matches the Instrument Address, and the command is terminated with either <CR> with no checksum or <ETX> followed by the correct checksum <BCC>.

Sample Data Reply String in response to Data Query Command (DA):

In response to a valid data query command (DA) the instrument responds in the following format:

```
<STX>MD02<SP><address><SP><measured
value1><SP><status><SP><SFKT><SP><address+1><SP><measured
value2><SP><status><SP><SFKT><ETX><BCC>
```

The response uses the same command terminators as used by the received command i.e. if the received command was terminated with a <CR> the response is terminated with <CR> and if the command was terminated with a <ETX><BCC> the response is terminated with <ETX> and the computed checksum <BCC>.

The 02 after the MD indicates, that two measurements are present in the reply string, (a 03 for three measurements and so on, this will also determine the length of the reply string).

<address> is the Instrument Address. Each subsequent measurement attached to the response will have the <address + X> where X keeps incrementing by 1 for each measurement included.

<measured value> is the concentration value in currently selected gas units represented as exponential representation with 4 characters mantissa and 2 characters exponent, each with sign.

Mantissa: sign and 4 digits. The decimal point is assumed to be after the first digit and is not transmitted.

Exponent: sign and 2 digits.

Example:

-5384000.0 is represented as -5384+06

+0.04567 is represented as +4567-02

<status>: is formed by < operating status > and < error status > and separated by a space i.e.

```
<operating status><SP><error status>
```

Each of the two (<operating status> and <error status>) are formed by two characters each representing a 2 digit hex number which is one byte (8 Bits) operation status and one byte (8 Bits) error status.

These two bytes contain the information about the main operating conditions of the instrument at that instant. For details on how to interpret the status bytes refer to [Table D-1](#) and [Table D-2](#) below.

<SFKT>: is the space provided for future use for special function, it currently contains a string of ten 0's i.e. <0000000000>.

Example:

Geysitech Protocol with transmission of three concentrations (Instrument ID is 1, Operation Status is 03, Error Status is 04):

Data Query String: <STX>DA<CR>

Reply String:

$\langle \text{STX} \rangle \text{MD03} \langle \text{SP} \rangle 001 \langle \text{SP} \rangle +2578 +01 \langle \text{SP} \rangle 03 \langle \text{SP} \rangle 04 \langle \text{SP} \rangle 0000000000 \langle \text{SP} \rangle 002 \langle \text{SP} \rangle$
 $\uparrow \qquad \qquad \qquad \uparrow \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \qquad \uparrow$
 Address First Concentration(E-format)=25.78 Address+1

+5681+00<SP>03<SP>04<SP>0000000000<SP>003<SP>+1175+01<SP>03<SP>04<SP>
 ↑ ↑ ↑
 Second Concentration = 5.681 Address+2 Third Concentration=11.75

```
0000000000<SP><CR>
```

The attached concentrations are in the selected gas units. The measurements that are attached to the response if not valid in a particular mode then a value of 0.0 will be reported.

Measurements reported in response to DA command

The following measurements reported in response to DA command are for the Model 43i.

Single Range Mode

The 1 measurement reported in single range mode includes:

- SO₂

Dual/Auto Range Mode

The 2 measurements reported in dual or auto range modes include:

- low SO₂
- high SO₂

Operating and Error Status

See Table D–1 for operating status and Table D–2 for error status for the Model 43*i*.

Table D–1. Operating Status for Model 43*i*

	D7	D6	D5	D4		D3	D2	D1	D0
→ Bit	8	7	6	5		4	3	2	1
→ Hex-value	80	40	20	10		08	04	02	01
	MSB					LSB			
Operating status:									
Service Mode (On)	0	0	0	0		0	0	0	1
Maintenance (Local)	0	0	0	0		0	0	1	0
Zero gas (On)	0	0	0	0		0	1	0	0
Span gas (On)	0	0	0	0		1	0	0	0
Gas Unit Indication (ppb OR ppm)	0	0	0	1		0	0	0	0
Test LED (On)	0	0	1	0		0	0	0	0
Flash Lamp (Off)	0	1	0	0		0	0	0	0
Not used	1	0	0	0		0	0	0	0

Table D–2. Error Status for Model 43*i*

	D7	D6	D5	D4		D3	D2	D1	D0
→ Bit	8	7	6	5		4	3	2	1
→ Hex-value	80	40	20	10		08	04	02	01
	MSB					LSB			
Error status:									
Internal Temperature Alarm	0	0	0	0		0	0	0	1
Reaction Chamber Temperature Alarm	0	0	0	0		0	0	1	0
Lamp Intensity Alarm	0	0	0	0		0	1	0	0
Lamp Voltage Alarm	0	0	0	0		1	0	0	0
Pressure Alarm	0	0	0	1		0	0	0	0
Sample Flow Alarm	0	0	1	0		0	0	0	0
Permeation Gas Temperature Alarm	0	1	0	0		0	0	0	0
Not used	1	0	0	0		0	0	0	0

